

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [acer](#) /

› [Acer Predator Rolltop Gaming Backpack \(Model PBG6A0\) - Instruction Manual](#)

acer PBG6A0

Acer Predator Rolltop Gaming Backpack

MODEL: PBG6A0 - INSTRUCTION MANUAL

PRODUCT OVERVIEW

The Acer Predator Rolltop Gaming Backpack is engineered for adventurous gaming experiences and daily travel. It features versatile access and durable construction, designed to seamlessly transition between an active lifestyle and gaming needs. This backpack (NP. BAG1A. 290) is built to protect your valuable equipment.

Key Features

- Rolltop design for 15.6-inch laptops.
- Roll-up flexibility for adjustable storage capacity.
- Constructed with water-resistant fabric to protect contents.
- Padded interior compartments and pockets for enhanced protection.
- Comfortable shoulder harness for extended wear.

SETUP

Before first use, unpack the backpack and ensure all components are present. Adjust the shoulder straps to fit your body comfortably. The rolltop closure allows for flexible capacity adjustment; unroll fully for maximum space or roll down and secure with the buckles for a more compact profile.

Adjusting Shoulder Straps

1. Place the backpack on your back.
2. Pull the loose ends of the shoulder straps downwards to tighten, ensuring the backpack sits snugly against your back.
3. To loosen, lift the buckles on the shoulder straps and pull the straps upwards.
4. Utilize the chest strap for additional stability and weight distribution, especially when carrying heavier loads.

OPERATING INSTRUCTIONS

Main Compartment and Laptop Storage

- The main compartment is accessed via the rolltop closure. Unroll the top and unbuckle the side straps to open.
- A dedicated padded sleeve inside is designed to securely hold laptops up to 15.6 inches. Carefully slide your laptop into this sleeve.
- For additional items, utilize the spacious main area.
- To close, roll the top down tightly and secure the side buckles to prevent water ingress and keep contents secure.

External Pockets

- Front Zippered Pockets:** Use these for quick access to smaller items like keys, wallets, or mobile devices.
- Side Pockets:** The backpack features discreet side pockets, ideal for water bottles or other slim items. These pockets are designed to maintain the sleek profile of the backpack when not in use.

MAINTENANCE

Cleaning and Care

- Spot Cleaning:** For minor spills or dirt, use a damp cloth with mild soap. Gently rub the affected area and then wipe clean with a dry cloth.
- Water-Resistant Fabric:** While the fabric is water-resistant, it is not fully waterproof. Avoid prolonged exposure to heavy rain. If the backpack gets wet, allow it to air dry completely before storing.
- Zipper Maintenance:** Periodically check zippers for any debris and clean them gently. Avoid forcing zippers if they get stuck.
- Storage:** Store the backpack in a cool, dry place away from direct sunlight when not in use.

TROUBLESHOOTING

Common Issues and Solutions

- Zipper Malfunction:** If a zipper becomes difficult to operate, check for fabric caught in the teeth. Apply a small amount of zipper lubricant (e.g., beeswax or silicone spray) if friction is the issue.
- Laptop Fit:** Ensure your laptop is within the recommended 15.6-inch size for the dedicated sleeve. Larger laptops may fit in the main compartment but without the same level of dedicated padding.
- Discomfort During Wear:** Adjust the shoulder straps and utilize the chest strap to evenly distribute weight. Ensure the backpack is not overloaded beyond its comfortable capacity.

SPECIFICATIONS

Feature	Detail
Product Dimensions	6 x 17 x 26 inches

Item Weight	2.9 pounds
Capacity Total	25 Liters
Laptop Compatibility	Up to 15.6-inch laptops
Material	Water-resistant fabric
Model Number	PBG6A0

WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or visit the official Acer support website. Keep your proof of purchase for any warranty claims.

If you encounter any issues not covered in this manual, please contact Acer customer support for assistance.

PRODUCT IMAGES



Front view of the Acer Predator Rolltop Gaming Backpack in grey with teal accents, showing the rolltop closure and Predator logo.



Front view of the backpack, highlighting the side mesh pocket for a water bottle or other items.



Rear view of the backpack, showcasing the padded shoulder straps and back panel for comfort.



Side view of the backpack, showing the adjustable straps and buckles for securing the rolltop.



Profile view of the backpack, illustrating its sleek design and compact form.



Overhead view of the backpack with the main compartment open, showing a gaming laptop, headphones, and mouse inside.

PRODUCT VIDEOS

Official video showcasing the Acer Predator Gaming Backpack. This short video provides a dynamic overview of the backpack's design and features.

A brief product overview video from the seller, highlighting key aspects and functionality of the backpack.