Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

S-Link IP-757

S-link IP-757 10000mAh Portable Power Bank

User Instruction Manual

Model: IP-757 | Brand: S-Link

1. Introduction

The S-link IP-757 is a high-capacity 10000mAh portable power bank designed to provide reliable power for your mobile devices. Featuring a 2.1A output and a durable lithium-ion battery, it ensures your devices remain charged on the go. This manual provides essential information for the safe and efficient use of your power bank.

2. Safety Information

- Do not expose the power bank to extreme temperatures, direct sunlight, or fire.
- Avoid dropping, disassembling, or attempting to repair the device yourself.
- Keep the power bank away from water and high humidity.
- Use only compatible charging cables and adapters.
- Keep out of reach of children.
- Dispose of the power bank responsibly according to local regulations.

3. Package Contents

Please check the package for the following items:

- S-link IP-757 10000mAh Portable Power Bank
- User Manual (this document)
- Warranty Certificate



Image: S-link IP-757 Power Bank shown in its retail packaging.

4. Product Overview

The S-link IP-757 power bank features a compact design with essential ports for charging and recharging.



Image: Front view of the S-link IP-757 Power Bank, highlighting the two USB-A output ports and the central Micro-USB input port.

- **USB-A Output Ports:** Two ports for charging external devices.
- **Micro-USB Input Port:** For recharging the power bank itself.
- **LED Indicators:** (Typically located near ports) Indicate battery charge level.



Image: Angled view of the S-link IP-757 Power Bank, showcasing its white casing and the S-link brand logo.

5. Setup

Before first use, it is recommended to fully charge your S-link IP-757 power bank.

1. Connect the Micro-USB end of a compatible charging cable to the power bank's Micro-USB input port.
2. Connect the USB-A end of the cable to a USB wall adapter (not included) or a computer's USB port.

3. The LED indicators will illuminate to show the charging status. Allow the power bank to charge until all indicators are solid, indicating a full charge.

6. Operating Instructions

6.1. Charging the Power Bank

To recharge your S-link IP-757:

1. Connect the power bank to a power source using a Micro-USB cable as described in the Setup section.
2. The LED indicators will flash during charging and become solid when fully charged.

6.2. Charging External Devices

To charge your mobile phone or other USB-powered devices:

1. Connect your device's charging cable (USB-A end) to one of the power bank's USB-A output ports.
2. Connect the other end of the cable to your device.
3. The power bank will automatically begin charging your device. The LED indicators will show the remaining battery level of the power bank.
4. Disconnect your device once it is fully charged.

7. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the power bank. Do not use liquid cleaners or aerosols.
- **Storage:** Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, fully charge and discharge the power bank at least once every three months if not in regular use.

8. Troubleshooting

- **Power bank not charging:** Ensure the Micro-USB cable is securely connected to both the power bank and the power source. Try a different cable or power adapter.
- **Device not charging from power bank:** Ensure the charging cable is securely connected to both the power bank and your device. Check if the power bank has sufficient charge. Try a different USB output port or cable.
- **Slow charging:** Ensure you are using a high-quality cable. Some devices may charge slower if the power bank's output is lower than the device's maximum input, though the IP-757 provides 2.1A output.

9. Specifications




Image: Back view of the S-link IP-757 Power Bank, showing printed technical specifications.

Feature	Specification
Brand	S-Link
Model	IP-757 (Part No: 23856 IP-757)
Battery Capacity	10000 mAh

Output Current	2.1A
Input Port	Micro-USB (5pin)
Output Ports	2 x USB-A
Battery Type	Lithium-ion
Dimensions (L x W x H)	17 x 9.5 x 3 cm
Weight	340 grams
Color	White

10. Warranty and Support

Your S-link IP-757 Portable Power Bank comes with a warranty as specified in the included Warranty Certificate. Please refer to this document for details regarding warranty coverage, terms, and conditions.

For technical support, troubleshooting assistance, or warranty claims, please contact S-Link customer service through the contact information provided on the product packaging or the official S-Link website.

© 2023 S-Link. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07CRHH2WQ

More documents and user manuals: **https://manuals.plus/**