

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Craftmade](#) /

› [Craftmade F300-ABZ-LED Universal Fan 3-Light Kit Instruction Manual](#)

Craftmade F300-ABZ-LED

Craftmade F300-ABZ-LED Universal Fan 3-Light Kit Instruction Manual

INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Craftmade F300-ABZ-LED Universal Fan 3-Light Kit. Please read all instructions carefully before beginning installation and retain this manual for future reference.

IMPORTANT SAFETY INFORMATION

WARNING: To reduce the risk of electric shock, ensure electricity is turned off at the circuit breaker or fuse box before beginning installation. Do not attempt installation if you are not qualified to do so. Consult a licensed electrician.

CAUTION:

- Read and follow all instructions carefully.
- Do not install this light kit with a wall dimmer switch unless the dimmer is specifically rated for LED lighting and compatible with the light kit's specifications.
- Ensure all electrical connections are made in accordance with local codes, ordinances, and the National Electric Code (NEC).
- This product is designed for indoor use only.
- Do not use this light kit with a fan that is not designed to accept a light kit.

PACKAGE CONTENTS

Verify that all components are present before discarding packaging materials. If any parts are missing or damaged, contact Craftmade customer service.

- LED Light Kit Assembly (1)
- Glass Shades (3)
- Mounting Hardware (Screws, Washers)

- Instruction Manual (1)

No product images are available for embedding in this manual. Please refer to the product packaging for visual identification of components.

SETUP AND INSTALLATION

Before proceeding, ensure power to the ceiling fan is turned off at the circuit breaker.

1. **Prepare the Fan:** If your ceiling fan has a removable bottom cap or plug where a light kit would attach, remove it. Locate the electrical wires for the light kit, typically a white (neutral), black (hot), and green (ground) wire.
2. **Connect Wiring:** Connect the white wire from the light kit to the white wire from the fan using a wire nut. Connect the black wire from the light kit to the black or blue (hot) wire from the fan. Connect the green (ground) wire from the light kit to the green or bare copper (ground) wire from the fan. Ensure all connections are secure.
3. **Attach Light Kit:** Carefully tuck the connected wires into the fan's switch housing. Align the light kit assembly with the mounting holes on the bottom of the fan. Secure the light kit to the fan using the provided screws. Do not overtighten.
4. **Install Glass Shades:** Carefully attach the three glass shades to the light kit assembly according to the fan's design. Typically, these twist or clip into place.
5. **Restore Power:** Once installation is complete and all connections are secure, restore power at the circuit breaker.

No product images or videos are available for embedding to illustrate the installation steps. Refer to the diagrams in the physical manual if available.

OPERATING INSTRUCTIONS

This Craftmade F300-ABZ-LED light kit is designed to be controlled by the ceiling fan's existing light switch or remote control system, if applicable. The light kit features LED bulbs and is dimmable when used with a compatible LED dimmer switch or fan remote system.

- **Turning On/Off:** Use the wall switch or the light button on your fan's remote control to turn the light kit on or off.
- **Dimming (if applicable):** If your fan system or wall switch supports dimming for LED lights, press and hold the light button on your remote or adjust the dimmer switch to change the light intensity.

No product videos are available for embedding to demonstrate operation.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your light kit.

- **Cleaning:** To clean the light kit, ensure power is off. Wipe the metal parts with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these can damage the finish. Clean glass shades with a mild glass cleaner and a soft cloth.
- **Bulb Replacement:** This light kit uses integrated LED lighting. The LEDs are designed for long life and are generally not user-replaceable. If the LEDs fail, contact Craftmade customer service for assistance.

- **Tightening:** Periodically check all screws and connections for tightness. Do not overtighten.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Light kit does not turn on.	No power to the fan. Loose wire connections. Faulty wall switch or remote.	Check circuit breaker. Verify all wire connections are secure (ensure power is off first). Test with a known working switch or remote.
Lights flicker or dim unexpectedly.	Incompatible dimmer switch. Loose connections.	Ensure dimmer is rated for LED lighting and compatible. Check all wire connections.
Light kit makes humming noise.	Incompatible dimmer switch. Loose mounting.	Replace dimmer with an LED-compatible model. Ensure light kit is securely mounted to the fan.

SPECIFICATIONS

Feature	Detail
Brand	Craftmade
Model	F300-ABZ-LED
Light Source Type	LED
Number of Light Sources	3
Total Watts	25.5 Watts
Special Feature	Dimmable
Finish Type	Brushed (Aged Bronze)
Product Dimensions	6.5 x 6.5 x 3 inches
Item Weight	1.1 Pounds
UPC	647881186623

WARRANTY AND SUPPORT

This Craftmade F300-ABZ-LED Universal Fan 3-Light Kit is covered by a manufacturer's warranty. For specific warranty terms and conditions, please refer to the documentation included with your purchase or visit the official Craftmade website. For technical support, missing parts, or warranty claims, please contact Craftmade customer service directly.

