

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Warehouse of Tiffany](#) /

› [Warehouse of Tiffany Bopelo Faux Wood Grain Metal 3-Light Semi-Flush Ceiling Lamp Instruction Manual](#)

Warehouse of Tiffany CM021/3

Warehouse of Tiffany Bopelo Faux Wood Grain Metal 3-Light Semi-Flush Ceiling Lamp Instruction Manual

Model: CM021/3

INTRODUCTION

This manual provides essential information for the safe installation, operation, and maintenance of your Warehouse of Tiffany Bopelo Faux Wood Grain Metal 3-Light Semi-Flush Ceiling Lamp. Please read this manual thoroughly before installation and retain it for future reference.

The Bopelo semi-flush ceiling lamp features a strong, caged metal bowl with a realistic faux wood grain finish, designed to add character to various indoor settings such as dining rooms, entryways, or industrial spaces.

SAFETY INFORMATION

WARNING: RISK OF ELECTRIC SHOCK. Disconnect power at the circuit breaker or fuse box before installation or servicing.

This fixture must be hard-wired. Professional installation is recommended to ensure proper wiring and safety.

Ensure all electrical connections comply with local codes and ordinances, as well as the National Electric Code (NEC).

Do not exceed the maximum wattage specified for the light bulbs.

Always handle glass components with care.

Keep flammable materials away from the lamp when in operation.

PACKAGE CONTENTS

Carefully unpack your fixture and check that all parts are included. If any parts are missing or damaged, do not attempt to assemble or install the fixture.

- Fixture Assembly (1)
- Metal Shade (1)
- Installation Wiring (Pre-attached)
- Instruction Manual (This document)
- Mounting Hardware (Screws, wire nuts, mounting plate)

Note: Three (3) 60-watt E12 light bulbs are NOT included and must be purchased separately.

SETUP AND INSTALLATION

Tools Required: Phillips screwdriver, flathead screwdriver, wire strippers, electrical tape, ladder, safety glasses.

1. **Turn Off Power:** Locate the circuit breaker or fuse box that controls the power to the light fixture location. Turn off the main power supply to prevent electric shock. Verify power is off using a voltage tester.
2. **Prepare Mounting:** Remove the old fixture if applicable. Attach the mounting plate to the junction box in the ceiling using the provided screws. Ensure the plate is securely fastened.
3. **Wire Connections:** Carefully connect the fixture's wires to the house wires using wire nuts. Match the wires as follows:
 - Black (Live) fixture wire to Black (Live) house wire.
 - White (Neutral) fixture wire to White (Neutral) house wire.
 - Green or Bare Copper (Ground) fixture wire to Green or Bare Copper (Ground) house wire.

Secure each connection with a wire nut and wrap with electrical tape for added safety.

4. **Mount Fixture:** Carefully tuck the wires into the junction box. Align the fixture with the mounting plate and secure it using the provided screws. Ensure the fixture is flush against the ceiling.
5. **Install Bulbs:** Screw three (3) E12 base, 60-watt maximum incandescent bulbs (not included) into the sockets. Do not overtighten.
6. **Restore Power:** Turn the main power supply back on at the circuit breaker or fuse box. Test the light fixture.



Image: Front view of the Bopelo Semi-Flush Ceiling Lamp, showcasing its faux wood grain metal cage and three light sockets.



Image: The Bopelo Semi-Flush Ceiling Lamp installed in a room, demonstrating its appearance when mounted on a ceiling.

OPERATING INSTRUCTIONS

Once properly installed and wired, the Warehouse of Tiffany Bopelo Semi-Flush Ceiling Lamp operates via a standard wall switch (not included). Simply toggle the wall switch to turn the light fixture on or off.

This fixture is designed for indoor use only.

MAINTENANCE

Cleaning

To clean the fixture, ensure the power is turned off at the circuit breaker. Use a soft, dry cloth to wipe down the metal surfaces. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish.

Bulb Replacement

Before replacing bulbs, turn off the power to the fixture at the circuit breaker. Allow bulbs to cool completely before touching them. Unscrew the old bulb and screw in a new E12 base bulb, ensuring it does not exceed 60 watts. Restore power after replacement.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture. Bulb is loose or burned out. Incorrect wiring.	Check circuit breaker. Tighten or replace bulb. Verify wiring connections (consult a professional if unsure).
Flickering light.	Loose bulb. Loose wiring connection. Incorrect bulb type.	Tighten bulb. Check wiring connections (ensure power is off). Ensure bulb is E12 base and within wattage limits.
Fixture hums.	Loose components. Incompatible dimmer switch (if applicable).	Ensure all screws and nuts are tight. If using a dimmer, ensure it is compatible with incandescent lighting.

SPECIFICATIONS

Model:	CM021/3
Brand:	Warehouse of Tiffany
Dimensions:	15.75 inches (Diameter) x 15.75 inches (Height)
Material:	Metal
Finish:	Imitation Wood / Brown Painted
Shade Material:	Metal
Number of Lights:	3
Bulb Type:	E12 (Candelabra)
Max Wattage per Bulb:	60 Watts
Voltage:	120 Volts
Power Source:	AC (Hard-wired)
Indoor/Outdoor	
Usage:	Indoor
Certifications:	UL Listed, CSA Listed, ETL Listed
Assembly Required:	Yes



Image: A detailed view of the Bopelo Semi-Flush Ceiling Lamp, highlighting the faux wood grain finish and structural elements.

WARRANTY AND SUPPORT

The manufacturer states "No." for warranty description in the provided data. For specific warranty details or support inquiries, please contact Warehouse of Tiffany directly.

For further assistance or replacement parts, please visit the official Warehouse of Tiffany store or contact their customer service.

Warehouse of Tiffany Store: [Visit Store](#)



© 2024 Warehouse of Tiffany. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.