

[Manuals.plus](#) /

> [NutriBullet](#) /

> NutriBullet Personal Blender for Shakes, Smoothies, Food Prep, and Frozen Blending, 24 Ounces, 600 Watt, Gray, (NBR-0601) Clear One Cup

NutriBullet NBR-0601WM

NutriBullet Personal Blender User Manual

Model: NBR-0601WM

INTRODUCTION

Welcome to the world of quick and easy nutrition with your new NutriBullet Personal Blender. This powerful 600-watt appliance is designed to effortlessly transform fruits, vegetables, and other ingredients into delicious and nutritious smoothies, helping you achieve a healthier lifestyle with minimal effort. Its intuitive design ensures a seamless blending experience, delivering key nutrients to your body in under 60 seconds.

IMPORTANT SAFETY INFORMATION

Please read all instructions and safety warnings carefully before operating your NutriBullet Personal Blender. Failure to do so may result in injury or damage to the appliance.

- Always refer to the user manual before use for detailed safety guidelines.
- This product is built to North American & Canadian Electrical standards.
- Do not immerse the motor base in water or other liquids.
- Ensure the unit is unplugged when not in use, before assembling or disassembling parts, and before cleaning.
- Avoid contact with moving parts.
- Do not blend hot liquids or carbonated beverages.
- Do not overfill the cup beyond the MAX line.
- Do not operate the blender with an empty cup.
- Keep hands and utensils out of the blending cup while blending to prevent personal injury.

WHAT'S INCLUDED

Your NutriBullet Personal Blender package includes the following components:

- (1) 600W Motor Base
- (1) Extractor Blade
- (1) 24 oz Cup
- (1) To-Go Lid
- (1) Lip Ring
- Recipe Book



Image: The NutriBullet Personal Blender showcasing its main components, including the motor base, blending cup filled with fresh produce, extractor blade, and travel accessories.

SETUP

Follow these simple steps to set up your NutriBullet Personal Blender for first use:

1. Unpack all components and remove any packaging materials.
2. Wash the 24 oz cup, extractor blade, to-go lid, and lip ring with warm, soapy water before initial use. Rinse thoroughly and dry.
3. Place the motor base on a clean, dry, and level surface.

4. Ensure the motor base is unplugged from the power outlet before proceeding.



Image: The NutriBullet motor base, empty blending cup, and blade assembly, illustrating the components ready for initial setup.

OPERATING INSTRUCTIONS

Using your NutriBullet Personal Blender is quick and easy:

1. Add your desired ingredients to the 24 oz cup. Ensure ingredients do not exceed the MAX fill line.
2. Twist the extractor blade onto the cup until it is securely tightened.
3. Invert the cup and place it onto the 600W motor base, aligning the tabs.
4. Press down firmly on the cup to activate the blending action. The blender will operate as long as you apply pressure.
5. For continuous blending, press down and twist the cup clockwise until the tabs lock into place.
6. Blend until your desired consistency is achieved. Most smoothies are ready in under 60 seconds.
7. Once blending is complete, release pressure or twist the cup counter-clockwise to unlock and stop the motor.
8. Carefully remove the cup from the motor base, then twist off the extractor blade.
9. You can attach the to-go lid or lip ring to the cup for immediate consumption or portability.



Simple, intuitive design.

Just push, twist and blend. It's that easy.

Image: A user demonstrating the simple, intuitive design of the NutriBullet by placing the filled blending cup onto the motor base for operation.



Nutrition in no time.

Make smoothies in under 60 seconds
to fit nutritious food into your busy day.

Image: The NutriBullet in action, showing how quickly and easily nutritious blends can be prepared, fitting into a busy day.

MAINTENANCE AND CLEANING

Cleaning your NutriBullet Personal Blender is effortless:

- **Extractor Blade:** Simply twist off the extractor blade from the cup. Rinse it under running water with soap immediately after use. Use a brush to clean around the blades if necessary.
- **Cups and Lids:** The 24 oz cup, to-go lid, and lip ring are dishwasher safe. Place them on the top rack of your dishwasher for convenient cleaning.
- **Motor Base:** Wipe the motor base clean with a damp cloth. Never immerse the motor base in water or any other liquid.
- Ensure all parts are completely dry before storing.



Cleans like a dream.

Rinse the blades with soap and water,
and put the cups on the top rack of the dishwasher.

Image: A hand rinsing the NutriBullet blending cup under running water, highlighting the ease of cleaning the components.

TROUBLESHOOTING

If you encounter any issues with your NutriBullet Personal Blender, refer to the table below for common problems and solutions:

Problem	Possible Cause	Solution
Blender does not turn on.	Not plugged in; cup not properly engaged; motor overheating.	Ensure power cord is securely plugged in. Twist cup firmly onto base until engaged. Unplug and let motor cool for 15-20 minutes if overheated.
Ingredients are not blending smoothly.	Too little liquid; too many ingredients; ingredients are too large.	Add more liquid. Reduce the amount of ingredients. Cut larger ingredients into smaller pieces.

Problem	Possible Cause	Solution
Cup is difficult to open after blending.	Vacuum seal created by blending; coldness of cup.	Grip the cup with a towel for better traction. Twist firmly counter-clockwise. If still stuck, try running warm water over the blade assembly (avoiding the blade itself) for a few seconds.
Leakage from the cup.	Blade not tightened properly; cup overfilled; gasket issue.	Ensure extractor blade is twisted on securely. Do not fill past the MAX line. Check if the gasket is properly seated in the blade assembly.

SPECIFICATIONS

Key technical specifications for your NutriBullet Personal Blender:

Feature	Detail
Brand	NutriBullet
Model Number	NBR-0601WM
Power Source	Corded Electric
Voltage	110-120 Volts
Capacity	24 Fluid Ounces
Blade Material	Plastic, Stainless Steel
Special Feature	Dishwasher Safe (cups and lids)
Product Dimensions	6.85"D x 11.61"W x 12.28"H
Item Weight	5.5 pounds
Country of Origin	China
UPC	818049020817

WARRANTY AND SUPPORT

Your NutriBullet Personal Blender comes with a Limited Warranty. For specific details regarding warranty coverage, terms, and conditions, please refer to the official documentation included with your product or visit the manufacturer's website.

For further assistance, troubleshooting, or to purchase replacement parts, please visit the official NutriBullet support website or contact their customer service. You can also refer to the comprehensive [User Manual \(PDF\)](#) for more detailed information.

