

Outsunny 84C-050

Outsunny 10' x 13' Patio Gazebo

USER MANUAL - MODEL 84C-050

[Introduction](#) [Setup](#) [Operating](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. Introduction

This manual provides essential information for the assembly, operation, and maintenance of your Outsunny 10' x 13' Patio Gazebo. Please read these instructions carefully before beginning assembly and retain them for future reference.

The Outsunny Patio Gazebo is designed to provide a shaded and comfortable outdoor space. It features a durable steel frame, a vented canopy roof, and removable curtains for privacy and weather protection.

Important Safety Information:

- Always assemble the gazebo on a flat, stable surface.
- Ensure all connections are secure before use.
- **Warning: Not recommended for use in extreme weather conditions such as storms or heavy winds/rain. Disassemble or secure the gazebo during severe weather to prevent damage or injury.**
- Keep children and pets away from the assembly area.
- Do not hang heavy objects from the frame.



Figure 1.1: The Outsunny 10' x 13' Patio Gazebo in Khaki, featuring its two-tier canopy and privacy curtains.

2. Setup and Assembly

Assembly of this gazebo typically requires two to three adults. Follow the steps below for proper installation.

2.1 Unpacking and Component Check:

Carefully unpack all components and verify against the parts list (not provided in this manual, refer to your product packaging for a complete list). Ensure all parts are present and undamaged before proceeding.

2.2 Frame Assembly:

Begin by assembling the powder-coated steel frame. Connect the main support beams and upright poles according to the provided diagrams. Ensure all connections are finger-tight before fully tightening.



Figure 2.1: The robust powder-coated steel frame provides the primary structure for the gazebo.

2.3 Canopy Installation:

Once the frame is assembled, carefully drape the 180g coated polyester canopy over the top. The double-tier roof design allows for proper airflow and helps prevent wind accumulation. Ensure the canopy is centered and evenly distributed.

2-Tier Canopy Top



Figure 2.2: Detail of the 2-tier canopy top, designed for improved ventilation and weather resistance.

2.4 Curtain Attachment:

Attach the zippered curtains to the frame using the integrated hook and loop straps. These straps allow for convenient fixing of the curtains to the structure. The curtains can be zipped together for full enclosure or tied back for an open feel.

Zippered Curtains

Detachable zippered curtains adjust for private space or airy environment



Figure 2.3: The zippered curtains offer flexibility to create either a private or airy environment.



Figure 2.4: Curtains are easily attached to the frame using integrated rings and straps.

2.5 Securing the Gazebo:

For added stability, utilize the 12 included stakes. Insert them through the feet of the 6 upright poles and into the ground. The metal railing throughout the patio gazebo also adds extra support.



Figure 2.5: Key stability features include the powder-coated steel frame, 6 upright poles, and 12 additional stakes for ground anchoring.

3. Operating the Gazebo

3.1 Canopy Functionality:

The gazebo features a double-tier roof designed to facilitate proper airflow, reducing wind pressure and heat buildup underneath. The 180g coated polyester fabric provides UV protection and is water-resistant. Built-in grommets throughout the fabric help ensure proper water drainage, preventing pooling on the canopy.

3.2 Curtain Usage:

The detachable zippered curtains offer versatility. They can be fully closed to provide privacy and additional shade, or tied back to the poles using the attached straps for an open, airy environment. Adjust them as needed based on sunlight, wind, or desired privacy.



Figure 3.1: The gazebo provides a spacious outdoor gathering area, adaptable with its adjustable curtains.

4. Maintenance

Regular maintenance will extend the life of your Outsunny gazebo.

4.1 Cleaning:

- **Canopy and Curtains:** Clean with mild soap and water. Do not use harsh detergents or bleach. Allow to air dry completely before storing to prevent mildew.
- **Frame:** Wipe down the steel frame with a damp cloth to remove dirt and debris. The powder-coated finish helps resist rust, but regular cleaning is recommended.

4.2 Storage:

While the gazebo is built to last, it is not designed for extreme weather. During periods of heavy rain, strong winds, snow, or other severe weather conditions, it is highly recommended to remove the canopy and curtains, or completely disassemble the gazebo to prevent damage. Store components in a dry, protected area.

4.3 Inspection:

Periodically inspect all frame connections, canopy grommets, and curtain straps for wear and tear. Tighten any loose bolts or connections as needed.

5. Troubleshooting

Problem	Possible Cause	Solution
Gazebo feels unstable or wobbly.	Not properly anchored; loose frame connections.	Ensure all 12 stakes are firmly inserted into the ground. Check and tighten all bolts and connections on the frame. Consider additional weights for legs in moderate wind conditions.
Water pooling on canopy.	Canopy not taut; drainage grommets blocked.	Ensure the canopy is stretched tightly over the frame. Clear any debris from the drainage grommets to allow water to flow freely.
Curtains do not close completely.	Zipper misalignment; fabric caught.	Carefully align the zippers before zipping. Ensure no fabric is caught in the zipper mechanism.

6. Specifications

Brand:	Outsunny
Model Number:	84C-050
Material:	Alloy Steel, Polyester
Product Dimensions (L x W x H):	157.5" x 118.1" x 110.2" (13' x 9.8' x 9.2')
Item Weight:	71.5 Pounds
Frame Material:	Alloy Steel
Water Resistance Level:	Water Resistant
Ultraviolet Light Protection:	Yes
Occupancy:	12 Person
Color:	Khaki
UPC:	842525119627
Floor Area:	129.2 Square Feet




Figure 6.1: Detailed dimensions of the Outsunny Patio Gazebo.

7. Warranty & Support

For specific warranty information, please refer to the documentation included with your purchase or contact the retailer. Outsunny products are designed for quality and durability.

Customer Support:

If you encounter any issues or have questions regarding your Outsunny Patio Gazebo, please contact Outsunny customer support. You may also refer to the [Outsunny Store on Amazon](#) for additional product information and support resources. This product typically includes a 30-day easy return policy from the point of purchase. Please check with your seller for details.