#### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- VTech /
- > VTech Switch & Go Dinos 2-Pack: T-Don and Tonn Instruction Manual

#### VTech 80-204750

# VTech Switch & Go Dinos 2-Pack: T-Don and Tonn Instruction Manual

Model: 80-204750

#### INTRODUCTION

This manual provides essential information for the safe and proper operation of your VTech Switch & Go Dinos 2-Pack, featuring T-Don the Pteranodon and Tonn the Stegosaurus. Please read these instructions thoroughly before use and retain them for future reference.

The VTech Switch & Go Dinos are 2-in-1 toys that transform between a dinosaur and a vehicle. They feature an LCD screen for customizable animations and play various sounds and phrases.

### PACKAGE CONTENTS

- 1 x VTech Switch & Go Dino T-Don the Pteranodon
- 1 x VTech Switch & Go Dino Tonn the Stegosaurus
- 4 x AAA Batteries (pre-installed)



Image: T-Don (red Pteranodon) and Tonn (yellow Stegosaurus) in their dinosaur forms.

## **S**ETUP

# **Battery Installation and Replacement**

Each Switch & Go Dino requires 2 AAA batteries. Batteries are pre-installed for demonstration purposes. For optimal performance, it is recommended to replace them with new alkaline batteries.

- 1. Locate the battery compartment on the underside of the toy.
- 2. Using a screwdriver, loosen the screw on the battery cover.
- 3. Remove the old batteries (if any) and dispose of them properly.
- 4. Insert 2 new AAA batteries, ensuring correct polarity (+/-).
- 5. Replace the battery cover and tighten the screw.

## **Important Battery Information:**

- · Use only new AAA alkaline batteries.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Remove exhausted batteries from the toy.
- Remove batteries if the toy will not be used for an extended period.

## **OPERATING INSTRUCTIONS**

#### Power On/Off

To turn the toy on, locate the On/Off switch, usually on the underside or side of the toy, and slide it to the "On" position. To turn off, slide the switch to "Off".

#### **Transformation: Dinosaur to Vehicle and Vice Versa**

Each Switch & Go Dino is designed for easy transformation. Follow these general steps:

- 1. **From Dinosaur to Vehicle:** Carefully fold and tuck away the dinosaur's limbs, head, and tail. Extend the wheels and vehicle body panels until the vehicle shape is complete.
- 2. **From Vehicle to Dinosaur:** Extend the dinosaur's limbs, head, and tail from the vehicle body. Fold in the wheels and vehicle panels until the dinosaur shape is complete.

The transformation process is intuitive and designed for repeated use. Refer to the specific toy's molded details for guidance.



Image: Tonn the Stegosaurus (yellow) shown in both dinosaur and vehicle modes, with an arrow indicating transformation.



Image: T-Don the Pteranodon (red) shown in both dinosaur and vehicle modes, with an arrow indicating transformation.

## **LCD Screen Functions**

Each dino features an LCD screen that displays various animations:

- Dinosaur Mode: Displays customizable dinosaur eyes.
- Vehicle Mode: Displays driver animations.

The animations change dynamically with play and button presses.



Image: A finger pressing a button on Tonn the Stegosaurus, demonstrating how the LCD screen displays different eye animations.

#### **Button Functions**

Press the various buttons on the dino to activate different features:

- Dinosaur Facts: Learn interesting facts about each dinosaur.
- Sound Effects: Hear realistic dinosaur roars, vehicle sounds, and other sound effects.
- Phrases: Listen to over 50 unique sounds and phrases.

Experiment with different buttons and modes to discover all the interactive elements.

#### **Volume Control**

Some models may include a volume control switch, typically located near the battery compartment or power switch. Adjust to your preferred sound level.

## **M**AINTENANCE

## Cleaning

To clean the toy, wipe it with a slightly damp cloth. Do not use harsh chemicals or abrasive cleaners. Ensure the toy is completely dry before storage or further use.

#### Caution:

- Do not immerse the toy in water or any other liquid.
- Keep the toy away from direct sunlight and direct heat sources.

## **Storage**

When not in use for extended periods, store the toy in a cool, dry place. Remove batteries if storing for several months to prevent leakage.

## **TROUBLESHOOTING**

Problem	Possible Cause	Solution
Toy does not turn on or respond.	Batteries are low or incorrectly installed.	Check battery polarity. Replace with new AAA alkaline batteries. Ensure the On/Off switch is in the "On" position.
Sound is distorted or too low.	Low batteries or volume setting.	Replace batteries. Adjust the volume switch if available.
LCD screen is blank or flickering.	Low batteries or internal malfunction.	Replace batteries. If the issue persists, contact VTech customer support.
Difficulty transforming the toy.	Incorrect manipulation.	Refer to the transformation steps in the Operating Instructions.  Ensure all parts are aligned correctly. Do not force parts.

## **SPECIFICATIONS**

Feature	Detail
Product Model Number	80-204750
Product Dimensions	7.5 x 7.3 x 3.7 inches
Item Weight	1.13 pounds
Manufacturer Recommended Age	36 months - 8 years
Batteries Required	4 x AAA batteries (2 per dino, included)
Manufacturer	VTech
Release Date	May 2, 2018

# **WARRANTY INFORMATION**

VTech products are manufactured with high-quality materials and undergo rigorous testing. For specific warranty details, please refer to the warranty card included with your product or visit the official VTech website. Keep your

purchase receipt as proof of purchase.

#### **CUSTOMER SUPPORT**

If you have any questions, require assistance, or encounter issues not covered in this manual, please contact VTech Customer Support. Contact information can typically be found on the VTech official website or on the product packaging.

Online resources and FAQs may also be available on the VTech website.

© 2023 VTech. All rights reserved.

## Related Documents - 80-204750



#### VTech SWITCH & GO DINOS Slam the Stegosaurus Parent's Guide

This Parent's Guide for the VTech SWITCH & GO DINOS Slam the Stegosaurus provides comprehensive instructions on setup, features, care, and troubleshooting for this interactive transforming toy.



#### VTech Switch & Go Dinos Soar the Pteranodon Parent's Guide

Parent's guide for the VTech Switch & Go Dinos Soar the Pteranodon toy, detailing its features, transformation, battery installation, care, troubleshooting, and consumer services. Includes safety and disposal information.



## VTech Switch & Go Dinos Tremor the T-Rex Instruction Manual

Official instruction manual for the VTech Switch & Go Dinos Tremor the T-Rex toy. Learn how to use, combine, care for, and troubleshoot your 2-in-1 T-Rex and super car toy.




#### VTech Switch & Go Dinos Thorn The Triceratops Instruction Manual

Official instruction manual for the VTech Switch & Go Dinos Thorn The Triceratops, a 2-in-1 transforming toy. Includes setup, features, combination, care, and troubleshooting guides.



## VTech Switch & Go Dinos Hatch & Roaaar Egg Stegosaurus Hot Rod Instruction Manual

Comprehensive instruction manual for the VTech Switch & Go Dinos Hatch & Roaaar Egg Stegosaurus Hot Rod toy, detailing assembly, features, switching between modes, care, and troubleshooting.



# VTech Switch & Go Dinos Stegosaurus Hot Rod Instruction Manual

Complete instruction manual for the VTech Switch & Go Dinos Hatch & Roaaar Egg Stegosaurus Hot Rod toy, covering assembly, operation, features, battery information, and troubleshooting.