

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Toyota](#) /

› [2018 Toyota Yaris iA Owner's Manual](#)

Toyota Yaris iA

2018 Toyota Yaris iA Owner's Manual

Your comprehensive guide to operating and maintaining your vehicle.

INTRODUCTION

This owner's manual provides detailed information regarding the safe and efficient operation, maintenance, and care of your 2018 Toyota Yaris iA. Please read this manual thoroughly to ensure a complete understanding of your vehicle's features and capabilities. Keep this manual in your vehicle for future reference.

The publication number for this manual is **OM99Q46z**. This number can be used for reference when ordering replacement manuals or seeking specific documentation.




Image: Front cover of the 2018 Toyota Yaris iA Owner's Manual. The cover is predominantly gray with a vertical red stripe on the right side, and a white section to its right. A barcode and publication number "OM99Q46z" are visible on the lower left.

GETTING STARTED (SETUP)

Before operating your 2018 Toyota Yaris iA, familiarize yourself with the basic controls and features. This section guides you through initial setup and understanding your vehicle's environment.

Vehicle Familiarization

- **Dashboard Layout:** Understand the location of the speedometer, tachometer, fuel gauge, and warning lights.
- **Steering Wheel Controls:** Identify buttons for audio, cruise control, and hands-free communication.
- **Seat Adjustments:** Learn how to adjust your seat for optimal driving position, including height, recline, and fore-aft.
- **Mirror Adjustments:** Properly adjust side mirrors and the rearview mirror for maximum visibility.

Key and Ignition System

Your Yaris iA uses a smart key system or a traditional key. Refer to the specific section in your manual for detailed instructions on starting the engine and using the remote functions.

OPERATING YOUR VEHICLE

This section covers the essential procedures for driving and utilizing the various systems within your Toyota Yaris iA.

Driving Controls

- **Starting the Engine:** Insert the key and turn to START, or press the ENGINE START/STOP button while pressing

the brake pedal.

- **Transmission Operation:** Understand the gear selector positions (P, R, N, D, L/S) and their functions.
- **Braking System:** Information on the foot brake, parking brake, and anti-lock braking system (ABS).
- **Lighting System:** How to operate headlights, high beams, turn signals, and fog lights.

Infotainment System

Your Yaris iA is equipped with an infotainment system for audio, navigation, and communication. Consult the dedicated section in your manual for pairing Bluetooth devices, using the radio, and accessing other features.

Climate Control

Learn how to adjust temperature, fan speed, air distribution, and activate the air conditioning or defroster functions for optimal cabin comfort.

MAINTENANCE

Regular maintenance is crucial for the longevity and performance of your 2018 Toyota Yaris iA. Follow the recommended service schedule.

Routine Checks

- **Engine Oil:** Check oil level regularly and ensure it is within the recommended range.
- **Coolant Level:** Verify the coolant level in the reservoir.
- **Brake Fluid:** Inspect the brake fluid level.
- **Tire Pressure:** Maintain correct tire pressure as specified on the driver's side door jamb.
- **Wiper Blades:** Inspect wiper blades for wear and replace as needed.

Scheduled Service

Adhere to the maintenance schedule outlined in this manual or by your authorized Toyota dealer. This includes oil changes, tire rotations, filter replacements, and other inspections.

TROUBLESHOOTING

This section provides guidance for common issues you might encounter with your vehicle.

Warning Lights

- **Check Engine Light:** If illuminated, it indicates a potential engine or emission control system issue. Consult a qualified technician.
- **Oil Pressure Warning Light:** Stop the vehicle immediately and check the engine oil level.
- **Battery Charge Warning Light:** Indicates a problem with the charging system.
- **Tire Pressure Warning Light:** Check tire pressures and inflate to recommended levels.

Engine Starting Issues

- **Engine Cranks but Won't Start:** Check fuel level, ensure the correct key is used, and consult the manual for specific procedures.
- **Engine Does Not Crank:** Check battery terminals, ensure the transmission is in Park (P) or Neutral (N).

SPECIFICATIONS

Key specifications for the 2018 Toyota Yaris iA Owner's Manual document.

Specification	Detail
ASIN	B07CV4K265
Publisher	Toyota
Publication Date	January 1, 2018
Language	English
Item Weight	12.6 ounces
Dimensions	8.5 x 5.5 x 0.75 inches

WARRANTY INFORMATION

Warranty coverage for your 2018 Toyota Yaris iA is provided separately from this owner's manual. Please refer to the dedicated Warranty and Maintenance Guide that came with your vehicle for complete details on coverage, terms, and conditions. This manual does not contain warranty specifics.

SUPPORT

For further assistance, technical support, or to locate an authorized service center, please contact Toyota Customer Service or visit the official Toyota website. Ensure you have your vehicle's VIN (Vehicle Identification Number) readily available for faster service.

- **Toyota Official Website:** www.toyota.com
- **Customer Service:** Refer to your vehicle's documentation for the most current contact numbers.