

## Accutime SPD4452

# Marvel Spider-Man Digital Kids Watch Instruction Manual

Model: SPD4452 | Brand: Accutime

## INTRODUCTION

Welcome to your new Marvel Spider-Man Digital Kids Watch! This manual provides essential information for setting up, operating, and maintaining your watch. Designed for young Spider-Man fans, this durable digital watch features a clear display, interactive elements, and an adjustable strap for comfortable wear.

## KEY FEATURES

- **Digital Display:** Clear and easy-to-read digital time display.
- **Spider-Man Graphics:** Vibrant Spider-Man character graphics on the watch face.
- **Interactive Lights:** Features interactive lights for added fun.
- **Adjustable Strap:** Comfortable and adjustable plastic strap with Spider-Web details.
- **Durable Design:** Built to withstand active play.
- **Pre-installed Battery:** Comes with a watch battery already installed.

## SETUP

### Initial Power-On

Your watch comes with a battery pre-installed. To activate the display, remove any plastic tab from the crown or button if present.

## Setting the Time

The watch typically has buttons on the side for setting the time. Refer to the specific button functions on your watch for precise instructions.

1. Locate the "MODE" or "SET" button (often on the bottom right or left). Press it repeatedly until the time display starts flashing or you enter the time setting mode.
2. Use the "ADJUST" or "SELECT" button (often on the top right or left) to change the hour.
3. Press the "MODE" button again to move to the minutes, then use the "ADJUST" button to set the minutes.
4. Continue this process for any other settings like AM/PM, date, or year if available.
5. Once all settings are correct, press the "MODE" button one last time to exit the setting mode.

## Adjusting the Strap

The watch features a standard buckle closure. Adjust the strap to fit comfortably on the wearer's wrist by selecting the appropriate hole.



Image: Side view of the watch demonstrating the adjustable strap and buckle mechanism.

## OPERATING INSTRUCTIONS

### Reading the Digital Display

The watch features a clear digital display showing the time in hours and minutes.

### Using Interactive Features

Press the button (often on the top left or right) to activate the interactive lights on the watch face. These lights illuminate the Spider-Man graphic.

Your browser does not support the video tag.

Video: Demonstration of the Marvel Spider-Man watch, showcasing its design and digital display. This video is provided by the merchant.

## CARE AND MAINTENANCE

### Cleaning

To clean the watch, wipe it gently with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials.

### Water Resistance

**IMPORTANT: This watch is NOT waterproof. Avoid exposing it to water, including swimming, showering, or heavy rain, to prevent damage.**

### Battery Replacement

The watch uses 1 Product Specific battery (included). When the display dims or stops working, the battery may need replacement. It is recommended to have battery replacement performed by a qualified technician to ensure proper sealing and function.

## TROUBLESHOOTING

### Watch Not Displaying Time

Check if the battery is properly installed or needs replacement. If the watch is new, ensure any protective plastic tabs have been removed.

### Difficulty Setting Time

Ensure you are pressing the correct buttons in the sequence described in the "Setting the Time" section. Some watches require a long press to enter setting mode. If issues persist, the internal mechanism might be stuck or damaged.

### Lights Not Working

Verify the battery level. If the battery is low, the light function might be affected before the main time display.

## PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Accutime
Model Number	SPD4452
Department	Boys
Material	Plastic
Case Diameter	37mm
Batteries	1 Product Specific battery (included)

Feature	Detail
Manufacturer Recommended Age	6 years and up
Country of Origin	China
First Available	June 6, 2018
Water Resistance	Not waterproof



Image: Rear view of the watch displaying manufacturer information and safety symbols.

## WARRANTY AND SUPPORT

This Accutime watch comes with a One Year Warranty from Accutime Watch. For warranty claims or support, please contact Accutime Watch customer service directly.

## ADDITIONAL RESOURCES

### Product Images



Front view of the watch.



Another front view of the watch.



Close-up of the watch face.



Watch in its themed tin packaging.



Features highlighted: glowing strap LEDs, snug silicone strap, kid-tough design.



Child wearing the watch.