

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Hoover](#) /
- › [Hoover Power Scrub Elite Carpet Cleaner FH50250 User Manual](#)

Hoover FH50250

Hoover Power Scrub Elite Carpet Cleaner FH50250 User Manual

Model: FH50250

INTRODUCTION

The Hoover Power Scrub Elite Carpet Cleaner FH50250 is engineered for superior cleaning performance and efficient drying. This powerful carpet cleaner features HeatForce technology for faster drying, along with Quick and Deep Clean Modes to effectively lift embedded dirt and stains. The Wash/Rinse Mode ensures thorough removal of cleaning solution residue, providing a comprehensive clean for your carpets. Designed for homes with children and pets, it helps you maintain clean carpets quickly, allowing you to focus on what matters most.

PRODUCT OVERVIEW




Image: Hoover Power Scrub Elite Carpet Cleaner with its various attachments and a sample cleaning solution bottle.

Included Components:

- Hoover Power Scrub Elite Carpet Cleaner Unit
- Crevice Tool
- Stair Tool
- Upholstery Tool
- 8 ft. Hose
- Sample Bottle of Cleaning Solution
- Accessory Bag

SETUP

Before first use, ensure all components are present and the unit is properly assembled.

1. **Handle Assembly:** Insert the handle into the main body of the cleaner until it clicks securely into place.
2. **Clean Water Tank:** Remove the clean water tank from the unit. Fill it with warm tap water up to the indicated fill line.
3. **Solution Tank:** Fill the separate solution tank with Hoover cleaning solution according to the instructions on the solution bottle. Do not overfill.
4. **Attach Tanks:** Securely place both the clean water tank and the solution tank back onto the unit.
5. **Power Cord:** Unwind the power cord and plug the cleaner into a grounded electrical outlet.

OPERATING INSTRUCTIONS

The Hoover Power Scrub Elite offers versatile cleaning modes to suit your needs.

Cleaning Modes:

- **Quick Clean Mode:**
Ideal for rapid surface cleaning of rugs, entryways, and living rooms. In this mode, carpets can dry in less than 45 minutes, thanks to HeatForce technology. Simply turn the Clean Mode dial to "Quick Clean" for light spills and quick refreshes.
- **Deep Clean Mode:**
Designed to lift and remove deeply embedded dirt and stubborn stains. For a more thorough clean, turn the Clean Mode dial to "Deep Clean." This mode provides a more intensive wash for heavily soiled areas.
- **Wash/Rinse Mode:**
After washing, switch to the "Rinse" setting to remove any residual cleaning solution from your carpets. This helps to extend the life of your carpets and prevent dirt from being attracted to leftover detergent.

SpinScrub Brush System:

The patented SpinScrub Brush System features multiple rotating brushes that gently yet effectively agitate and clean carpet fibers. This system is designed to tackle tough messes without causing damage to your carpet.

Using Attachments:

For cleaning upholstery, stairs, and hard-to-reach areas, connect the 8 ft. hose and desired tool (Crevice Tool, Stair Tool, or Upholstery Tool) to the cleaner's hose port. Ensure the main cleaning nozzle is disengaged or lifted when using attachments.

Product Demonstration Video:

Your browser does not support the video tag.

Video: Official Hoover demonstration of the Power Scrub Elite Carpet Cleaner's features and operation, including quick clean, deep clean, and SpinScrub technology.

MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your carpet cleaner.

- **Emptying and Cleaning Dirty Water Tank:** After each use, remove the dirty water tank and empty its contents. Rinse the tank thoroughly with clean water.
- **Cleaning Brushes:** The SpinScrub brushes can be removed for easy cleaning. Detach the nozzle cover and remove the brush assembly. Rinse under running water to remove debris and hair.
- **Filter Maintenance:** Check and clean the filter located in the dirty water section regularly to maintain suction power. Rinse the filter with water and allow it to air dry completely before reinserting.
- **Storage:** Store the cleaner in a dry, indoor area. Ensure all tanks are empty and clean before storage.

TROUBLESHOOTING

If you encounter issues with your Hoover Power Scrub Elite, refer to the following common solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No Power	Not plugged in; tripped circuit breaker; power switch off.	Ensure unit is securely plugged in. Check circuit breaker. Turn power switch to ON.
No Suction	Dirty water tank full; clogged nozzle/hose; dirty filter.	Empty dirty water tank. Clear any blockages in nozzle or hose. Clean the filter.
Poor Cleaning Performance	Insufficient cleaning solution; dirty brushes; incorrect mode.	Refill solution tank. Clean SpinScrub brushes. Ensure correct cleaning mode is selected.
Leaking	Tanks not seated properly; damaged seals.	Ensure clean and dirty water tanks are securely latched. Check seals for damage.

SPECIFICATIONS

Feature	Detail
Model	FH50250
Item Weight	8.39 Kilograms
Form Factor	Upright
Capacity (Clean Water Tank)	1.4 Liters
Power Source	Corded Electric
Cord Length	20 Ft
Assembly Required	Yes
Batteries Required	No
Included Accessories	Crevice Tool, Stair Tool, Upholstery Tool, 8 ft. Hose, Sample Cleaning Solution, Accessory Bag

WARRANTY AND SUPPORT

This Hoover Power Scrub Elite Carpet Cleaner is backed by a manufacturer's warranty. For specific warranty details, including coverage period and terms, please refer to the warranty card included with your product or visit the official Hoover website.

For technical assistance, replacement parts, or further inquiries, please contact Hoover Customer Support:

- **Online Support:** Visit the Hoover official website for FAQs, product registration, and online support resources.
- **Phone Support:** Refer to your product packaging or the Hoover website for customer service contact numbers in your region.

When contacting support, please have your model number (FH50250) and purchase date readily available.

