

JBL JBLXTREME2BLKAM

JBL Xtreme 2 Portable Bluetooth Speaker User Manual

Brand: JBL | Model: JBLXTREME2BLKAM

INTRODUCTION

The JBL Xtreme 2 is a powerful and versatile portable Bluetooth speaker designed to deliver immersive sound experiences. With its robust build and advanced features, it is ideal for both indoor and outdoor use, providing high-quality audio wherever you go.

Key Features:

- Wireless Bluetooth streaming
- 15 hours of playtime
- IPX7 waterproof
- Durable fabric and rugged material
- USB charging port for external devices

SETUP

Charging the Speaker

Before first use, fully charge your JBL Xtreme 2 speaker. The speaker features a 10,000mAh Li-ion battery, providing up to 15 hours of playtime on a single charge. Use the provided power adapter to charge the speaker.



Image: JBL Xtreme 2 speaker with its power adapter and charging cable.

Initial Bluetooth Pairing

To connect your device to the JBL Xtreme 2 via Bluetooth:

1. Power on the JBL Xtreme 2 speaker by pressing the power button.
2. The Bluetooth indicator light will begin to flash, indicating it's in pairing mode.
3. On your mobile device, enable Bluetooth and search for 'JBL Xtreme 2' in the list of available devices.
4. Select the speaker to establish the connection. Once connected, the Bluetooth indicator will glow solid blue.



Image: JBL Xtreme 2 speaker next to a smartphone, demonstrating Bluetooth pairing.

OPERATING INSTRUCTIONS

Controls Overview

The top panel of the JBL Xtreme 2 features intuitive controls for easy operation:

- **Power Button:** Turns the speaker on or off.
- **Bluetooth Button:** Initiates Bluetooth pairing mode.
- **Volume Down (-):** Decreases the volume.
- **Volume Up (+):** Increases the volume.
- **Play/Pause Button:** Plays or pauses audio playback.
- **Skip Track Button:** Skips to the next track (double-press).



Image: Top view of the JBL Xtreme 2 speaker, highlighting its control buttons.

Connectivity Ports

The rear of the speaker houses various ports for extended connectivity:

- **3.5mm Stereo Audio Input:** For wired connection to audio sources.
- **Micro USB (Service):** For service and firmware updates only.
- **USB-A Output:** Functions as a power bank to charge external devices.
- **Power Input:** For connecting the power adapter to charge the speaker.



Image: Rear view of the JBL Xtreme 2 speaker, revealing its connectivity ports.

JBL Connect+ (PartyBoost)

The JBL Xtreme 2 supports JBL Connect+, allowing you to wirelessly link multiple JBL Connect+ enabled speakers together for an amplified listening experience. Refer to the official user guide for detailed instructions on enabling this feature.

MAINTENANCE AND CARE

Waterproofing (IPX7)

The JBL Xtreme 2 is IPX7 waterproof, meaning it can be submerged in water up to 1 meter (3 feet) for up to 30 minutes. This makes it suitable for use by the pool, at the beach, or in rainy conditions. Ensure all port covers are securely closed before exposing the speaker to water.



Image: JBL Xtreme 2 speaker near a swimming pool, highlighting its waterproof design.

Cleaning

To clean your JBL Xtreme 2, use a soft, damp cloth. Avoid using harsh chemicals or abrasive materials, as these may damage the speaker's finish or fabric. Ensure the speaker is dry before charging or opening any port covers.

TROUBLESHOOTING

If you encounter any issues with your JBL Xtreme 2 speaker, try the following basic troubleshooting steps:

- **No Power:** Ensure the battery is charged. Connect the speaker to the power adapter.
- **Bluetooth Not Connecting:** Make sure the speaker is in pairing mode (flashing blue light). Turn off and on your device's Bluetooth. Forget the speaker from your device's Bluetooth list and try pairing again.
- **No Sound:** Check the volume levels on both the speaker and your connected device. Ensure the correct audio input is selected if using a wired connection.
- **Poor Sound Quality:** Move the speaker closer to your Bluetooth device to reduce interference. Ensure there

are no obstructions between the speaker and the device.

For more detailed troubleshooting or persistent issues, please refer to the official user guide or contact JBL customer support.

SPECIFICATIONS

Feature	Detail
Model Name	JBL Xtreme 2
Dimensions (D x W x H)	7.9"D x 12.1"W x 18.1"H
Item Weight	5.27 Pounds
Speaker Type	Outdoor
Special Feature	Wireless, Portable, Waterproof
Connectivity Technology	Bluetooth
Bluetooth Version	4.2
Bluetooth Range	10 Meters
Power Source	Battery Powered
Battery Life	15 Hours
Battery Capacity	10000 mAh
Charging Time	15 Hours
Water Resistance Level	Waterproof (IPX7)
Speaker Maximum Output Power	40 Watts
Frequency Response	20000 KHz

DIMENSIONES



Image: JBL Xtreme 2 speaker with its dimensions.

WHAT'S IN THE BOX

- JBL Xtreme 2 Speaker
- Power Adaptor
- Quick Start Guide
- Strap



Image: JBL Xtreme 2 speaker with its detachable shoulder strap for portability.

WARRANTY AND SUPPORT

This product comes with a Limited Warranty. For detailed warranty information and support, please refer to the official user guide.

Official User Guide (PDF): [Download Here](#)

Visit the JBL Store: [JBL Official Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question