

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [Honor](#) /
- > [Honor 10 Smartphone User Manual](#)

Honor Honor 10 (51092LYY)

Honor 10 Smartphone User Manual

Model: Honor 10 (51092LYY)

1. INTRODUCTION

This manual provides essential information for the proper setup, operation, and maintenance of your Honor 10 Dual-SIM 128GB 4G Smartphone. The Honor 10 features a 5.84-inch IPS LCD display, a powerful Kirin 970 Octa-core processor, and a dual primary camera system (16MP + 24MP B/W) with AI capabilities. It operates on Android 8.1 (Oreo) and supports dual SIM functionality for GSM networks.

2. DEVICE OVERVIEW





Figure 2.1: Front view of the Honor 10, showcasing its display and notch design.

The front of the Honor 10 features a 5.84-inch IPS LCD capacitive touchscreen with a resolution of 1080 x 2280 pixels. It includes a notch at the top housing the front-facing 24MP camera and other sensors. The display is protected by Corning Gorilla Glass.



Figure 2.2: Back view of the Honor 10, highlighting the Aurora glass design and dual camera setup.

The back of the Honor 10 features a distinctive Aurora glass design that reflects vivid colors. It houses the dual primary cameras (16MP + 24MP B/W) with LED flash and the Honor brand logo.



Figure 2.3: Side view of the Honor 10, illustrating the button placement.

The side of the Honor 10 typically features the power button and volume rocker for easy access and control of the device's functions.

3. SETUP

3.1. Inserting SIM Cards

The Honor 10 supports Dual-SIM functionality. Locate the SIM card tray on the side of the device. Use the provided SIM

ejector tool to open the tray. Carefully place your Nano-SIM cards into the designated slots, ensuring proper orientation. Insert the tray back into the phone until it clicks into place.

3.2. Initial Power On and Network Compatibility

Press and hold the power button until the Honor logo appears. Follow the on-screen instructions to complete the initial setup, including language selection, Wi-Fi connection, and Google account setup. This smartphone is designed to work with GSM networks such as AT&T and T-Mobile in the USA. It is not compatible with CDMA networks like Verizon or Sprint. For specific 2G, 3G, and 4G/LTE band compatibility, please consult your network provider.

3.3. Charging the Device

Connect the USB Type-C cable to the charging port at the bottom of the phone and the other end to the power adapter. Plug the adapter into a wall outlet. The phone supports fast charging. A full charge typically takes approximately 1.5 to 2 hours. The battery indicator on the screen will show charging progress.

4. OPERATING YOUR HONOR 10

4.1. Basic Navigation

The Honor 10 features a responsive touchscreen for navigation. Use gestures such as tapping, swiping, pinching, and spreading to interact with applications and menus. The fingerprint sensor, located on the front, also functions as a home button and navigation key.

4.2. Camera Usage

Your Honor 10 is equipped with a dual primary camera (16MP + 24MP B/W) and a 24MP front camera. The AI camera feature automatically optimizes settings for various scenes. To take a photo, open the Camera app and tap the shutter button. Explore different modes like Portrait, Night, and Pro for enhanced photography.

4.3. Storage and Performance

The device comes with 128GB of internal storage and 4GB of RAM, providing ample space for apps and media, and smooth multitasking performance. There is no memory card slot for expandable storage.

4.4. Security Features

Unlock your phone using the fast fingerprint sensor or facial recognition. To set up these features, navigate to *Settings > Security & privacy > Fingerprint ID or Face Unlock* and follow the on-screen instructions. You can also set a PIN or pattern for additional security.

4.5. Audio

The Honor 10 includes a 3.5mm audio jack for connecting headphones. Adjust volume using the physical volume buttons on the side of the device.

5. MAINTENANCE

5.1. Battery Care

To prolong battery life, avoid exposing your phone to extreme temperatures. Use only Honor-approved chargers and cables. For optimal performance, it is recommended to keep the battery charge between 20% and 80% when possible.

5.2. Cleaning Your Device

Use a soft, lint-free cloth to clean the screen and body of your phone. Avoid using abrasive materials or harsh chemicals.

For stubborn smudges, slightly dampen the cloth with water. Ensure no liquid enters ports or openings.

5.3. Software Updates

Regularly check for system updates to ensure your device has the latest features, security patches, and performance improvements. Navigate to *Settings > System > Software update* to check for and install available updates. Updates may improve aspects such as fingerprint sensor performance.

6. TROUBLESHOOTING

6.1. Common Issues and Solutions

- **Phone not turning on/charging:** Ensure the charger and cable are securely connected and functional. Try a different outlet. If the battery is completely drained, it may take a few minutes for the charging indicator to appear.
- **Poor call quality/speaker issues:** Check if the speaker is obstructed. Ensure volume is set appropriately. If issues persist, try restarting the device.
- **Network connectivity problems:** Verify that your SIM card is correctly inserted and active. Check your network settings (*Settings > Wireless & networks > Mobile network*). Ensure you are within network coverage. Remember, this phone is GSM-only and will not work with CDMA carriers.
- **Device overheating:** Excessive use of demanding applications or prolonged charging can cause the device to warm up. Close background apps and allow the phone to cool down. If overheating is persistent, contact support.
- **Fingerprint sensor not responding:** Ensure your finger is clean and dry. Re-register your fingerprints if the issue persists. Software updates have been noted to improve sensor performance.

6.2. Factory Reset

If you experience persistent software issues, a factory reset may resolve them. **Warning:** This will erase all data on your phone. Back up important data before proceeding. To perform a factory reset, go to *Settings > System > Reset > Factory data reset* and follow the prompts.

7. SPECIFICATIONS

Feature	Detail
Model Name	HONOR 10
Item Model Number	51092LYY
Brand	Honor (Manufactured by Huawei)
Operating System	Android 8.1 (Oreo)
Processor	Hi Silicon Kirin 970, Octa-core (4x2.4 GHz Cortex-A73 & 4x1.8 GHz Cortex-A53)
Display Size	5.84 Inches
Display Type	IPS LCD capacitive touchscreen
Resolution	1080 x 2280 pixels
RAM	4 GB
Internal Storage	128 GB (No Memory Card Slot)

Feature	Detail
Primary Camera	Dual: 16MP (f/1.8) + 24MP B/W, phase detection autofocus, LED flash
Secondary Camera	24MP, f/2.0
Battery	Lithium Polymer (included), 25 Hours Talk Time
Connectivity	Wi-Fi, Cellular (GSM Only)
Audio Jack	3.5 mm
Dimensions	2.8 x 5.89 x 0.3 inches
Item Weight	5.4 ounces (153 Grams)
Color	Phantom Blue

8. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or visit the official Honor support website. Keep your proof of purchase for warranty claims. The manufacturer of this product is Honor.

