

[Manuals.plus](#) /

> [EPtech](#) /

> EPtech AC/DC Adapter Instruction Manual for NordicTrack E6.3 Elliptical (Models 23946-MX0, 831.239460, 831.239461, 831.239462, 831.239463)

EPtech A1805061044

EPtech AC/DC Adapter Instruction Manual

For NordicTrack E6.3 Elliptical (Models 23946-MX0, 831.239460, 831.239461, 831.239462, 831.239463)

Model: A1805061044

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your EPtech AC/DC Adapter. This adapter is specifically designed to provide power to NordicTrack E6.3 elliptical models, including 23946-MX0, 831.239460, 831.239461, 831.239462, and 831.239463. Please read this manual thoroughly before using the product and retain it for future reference.

Durable & Compact Design



Image 1: The EPtech AC/DC Adapter highlighting its durable and compact design, suitable for various environments.

2. SAFETY INFORMATION

Your safety is paramount. Observe the following precautions to prevent injury or damage to the product and connected devices:

- **Risk of Electric Shock:** This device operates with electricity. Do not open the adapter casing.
- **Dry Location Use Only:** Use this adapter in dry indoor environments. Avoid exposure to water, moisture, or high humidity.
- **Ventilation:** Ensure adequate ventilation around the adapter during use. Do not cover it with cloths or place it in enclosed spaces.
- **Temperature:** The adapter may become warm during normal operation. If it becomes excessively hot, disconnect it immediately and contact support.
- **Cable Integrity:** Do not use the adapter if the cord is damaged. Avoid bending, twisting, or pinching the power cord.
- **Proper Connection:** Ensure the adapter is fully inserted into both the wall outlet and the elliptical's power port.
- **Children and Pets:** Keep the adapter and its cord out of reach of children and pets.



Image 2: Front view of the EPtech AC/DC Adapter, showing input specifications and safety cautions printed on its surface.

Safety Design with Multiple Protections



Image 3: Visual representation of the adapter's built-in safety features, including over-temperature, over-voltage, over-current, and short-circuit protection.

3. SETUP

Follow these steps to set up your AC/DC adapter:

1. **Unpack:** Carefully remove the adapter from its packaging. Inspect it for any visible damage.
2. **Connect to Elliptical:** Locate the power input port on your NordicTrack E6.3 elliptical. Insert the barrel connector of the adapter firmly into this port.
3. **Connect to Power Outlet:** Plug the adapter's two-prong plug into a standard 100-240VAC 50/60Hz wall outlet. Ensure the outlet is easily accessible.
4. **Verify Power:** Once connected, your elliptical should receive power. Refer to your elliptical's manual for specific power indicators.



Image 4: The EPtech AC/DC Adapter connected to a power strip, demonstrating a typical setup for use with an elliptical machine.

4. OPERATING

The EPtech AC/DC Adapter is designed for simple plug-and-play operation. Once properly connected to a power source and your NordicTrack E6.3 elliptical, it will continuously supply the necessary power. There are no user-adjustable settings on the adapter itself.

5. MAINTENANCE

Proper care ensures the longevity and safe operation of your adapter:

- **Cleaning:** Disconnect the adapter from the power outlet before cleaning. Wipe the adapter with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Cable Care:** Regularly inspect the power cord for any signs of wear, cuts, or damage. Avoid sharp bends or kinks in the cable. Do not place heavy objects on the cable.
- **Storage:** When not in use for extended periods, store the adapter in a cool, dry place, away from direct sunlight and

extreme temperatures. Coil the cable loosely; do not wrap it tightly around the adapter.

High Quality Power Cable Design



Image 5: An illustration detailing the construction of a high-quality power cable, emphasizing the copper wire and PVC insulation jacket for durability.

6. TROUBLESHOOTING

If you encounter issues with your adapter, try the following steps:

- **No Power to Elliptical:**
 - Ensure the adapter is securely plugged into both the elliptical and the wall outlet.
 - Check if the wall outlet is functional by plugging in another device.
 - Inspect the adapter cable for any visible damage. If damaged, discontinue use.
- **Adapter Feels Warm:** It is normal for the adapter to feel warm during operation. If it becomes excessively hot to the touch or emits a burning smell, immediately unplug it and contact customer support.

7. SPECIFICATIONS

Feature	Detail
Model Number	A1805061044
Input Voltage	100-240VAC, 50/60Hz
Output	Compatible with NordicTrack E6.3 Elliptical (Specific voltage/current designed for listed models)
Cable Length	Approximately 6.5 feet (2 meters)
Connector Type	Barrel Connector

Safety Features	Over current protection, Total power protection, Over voltage protection, Short Circuit Protection
Certifications	FCC, CE, RoHS
Compatible Devices	NordicTrack E6.3 Elliptical (Models 23946-MX0, 831.239460, 831.239461, 831.239462, 831.239463)
Manufacturer	EPtech

8. WARRANTY AND SUPPORT

EPtech products are manufactured with high-quality materials and undergo rigorous testing. For any questions, problems, or support inquiries regarding your AC/DC adapter, please contact our customer service team.

Contact Information:

Email: epcustomerservice@yahoo.com