

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Moukey](#) /
- › [Moukey Keyboard Piano MEK-200 User Manual](#)

Moukey MEK-200

Moukey Keyboard Piano MEK-200 User Manual

Comprehensive guide for your Moukey 61-Key Electric Piano, Model MEK-200.

1. PRODUCT OVERVIEW

The Moukey MEK-200 is a full-size 61-key electronic keyboard piano designed for beginners and experienced players alike. It features a comprehensive set of functions including teaching modes, recording capabilities, and a wide array of voices and rhythms to enhance your musical journey. This kit provides everything needed to start playing, including a sturdy stand, comfortable bench, and headphones for private practice.



Figure 1.1: Complete Moukey MEK-200 Keyboard Kit setup.

2. WHAT'S IN THE BOX

Your Moukey Keyboard Piano MEK-200 package includes the following components:

- 61-Key Electronic Keyboard Piano (MEK-200)
- Adjustable Keyboard Stand
- X-braced Collapsible Stool (Bench)
- Headphones
- Sheet Music Holder
- Keyboard Sticker (for key labeling)
- Power Supply Adapter



Figure 2.1: All components included in the Moukey MEK-200 package.

3. SETUP GUIDE

Follow these steps to set up your Moukey Keyboard Piano:

- 1. Assemble the Keyboard Stand:** The adjustable X-braced stand is designed for easy assembly. Secure all connections firmly to ensure stability. Adjust the height to a comfortable playing position using the locking mechanisms on the stand.
- 2. Place the Keyboard:** Carefully place the Moukey MEK-200 keyboard onto the assembled stand. Ensure it is centered and stable.
- 3. Set up the Bench:** Unfold the X-braced collapsible stool and place it in front of the keyboard. The padded seat provides comfort for extended playing sessions.
- 4. Attach the Music Stand:** Insert the sheet music holder into the designated slots on the top of the keyboard. This provides a convenient place for your sheet music or a tablet.
- 5. Apply Keyboard Stickers (Optional):** For beginners, the included keyboard stickers can be applied to the keys to help identify notes. Refer to the sticker sheet for proper placement.
- 6. Connect Power:** Plug the power supply adapter into the DC IN port on the back of the keyboard and then into a standard electrical outlet.
- 7. Connect Headphones/Microphone (Optional):**
 - To practice privately, plug the included headphones into the **PHONES** output jack. The built-in speakers will automatically mute when headphones are connected.
 - To sing along while playing, connect a microphone (not included) to the **MIC** jack.



Figure 3.1: The Moukey MEK-200 fully assembled on its stand with the bench.

Support Multiple Devices



Figure 3.2: Connectivity ports on the Moukey MEK-200.

4. OPERATING THE KEYBOARD

The Moukey MEK-200 offers a variety of functions accessible via its intuitive control panel and LED screen.

4.1 Power On/Off and Volume Control

- To power on the keyboard, press the **POWER** button located on the left side of the control panel.
- Adjust the overall volume using the **MASTER VOLUME** knob.

4.2 Voices and Rhythms

The keyboard features 300 preset voices and 300 rhythms. Use the dedicated **VOICE** and **RHYTHM** buttons, along with the numeric keypad or arrow buttons, to select your desired sound or beat.

♫ Rich Sound

Enjoy in your huge music library

300

Rhythms

50

Demo Songs

08

Precussion Sounds



Figure 4.1: Control panel for voice and rhythm selection.

4.3 Teaching Modes

The MEK-200 includes teaching functions to assist beginners. Refer to the manual's specific instructions for activating and utilizing the "One Key Teaching" and "Follow Teaching" modes displayed on the LED screen.



Figure 4.2: The keyboard's teaching modes are designed for learning.

4.4 Recording and Playback

Use the **RECORD** function to capture your performances and the **PLAYBACK** function to listen to them. This allows for self-assessment and creative composition.

4.5 Percussion Sounds

The keyboard features 8 dedicated percussion pads for adding drum sounds to your music. These can be played independently or integrated with rhythms.



8 Percussion Sounds

Independent percussion sound which can insert to the music

Figure 4.3: Dedicated percussion pads for rhythmic accompaniment.

4.6 Keyboard Split Function

The keyboard supports a split function, allowing different voices to be assigned to different sections of the keyboard simultaneously. This is useful for playing bass lines with one hand and melodies with the other.

4.7 Pitch Bend Function

Utilize the pitch bend wheel to smoothly alter the pitch of notes, adding expressive nuances to your playing.

4.8 Demonstration Video

Watch the official seller demonstration video below for a visual guide on operating the Moukey MEK-200 and exploring its various features.

Your browser does not support the video tag.

Video 4.1: Demonstration of Moukey Keyboard Piano features by a seller.

5. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your Moukey Keyboard Piano:

- **Cleaning:** Use a soft, dry cloth to wipe down the keyboard and stand. Avoid abrasive cleaners or solvents that could damage the finish. For keys, a slightly damp cloth can be used, followed by a dry one.
- **Storage:** When not in use, store the keyboard in a cool, dry place away from direct sunlight, extreme temperatures, and excessive humidity. Consider covering it with a dust cover to protect it from dust and debris.
- **Handling:** Always handle the keyboard with care. Avoid dropping it or subjecting it to strong impacts. When moving, ensure the stand is properly disassembled or secured.
- **Power Supply:** Use only the provided power adapter. Disconnect the power supply during electrical storms or when the unit will be unused for extended periods.

6. TROUBLESHOOTING

If you encounter any issues with your Moukey Keyboard Piano, refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
No Sound	Power not connected or turned on. Volume too low. Headphones plugged in.	Ensure power adapter is securely connected and power is on. Increase MASTER VOLUME. Unplug headphones if you want sound from speakers.
Keys Not Responding	Keyboard may be in a specific mode (e.g., teaching mode). Internal software issue.	Check the current mode on the LED screen and switch to a standard playing mode. Try turning the keyboard off and on again.
Distorted Sound	Volume too high. Interference from other electronic devices.	Lower the MASTER VOLUME. Move the keyboard away from other electronics.

If the problem persists after trying these solutions, please contact Moukey customer support for further assistance.

7. SPECIFICATIONS

Feature	Detail
Brand	Moukey
Model Name	Moukey 61 Key Piano Keyboard
Model Number	MEK-200
Number of Keys	61
Product Dimensions	14.8"D x 37.48"W x 5.12"H

Feature	Detail
Item Weight	11.88 pounds (5.4 Kilograms)
Color	Black
Power Source	Battery Powered (Adapter included)
Headphones Jack	Exists (3.5mm)
Microphone Jack	Exists
Connectivity	USB to Host, USB to Device, MIDI In/Out
Voices	300 Preset Voices
Rhythms	300 Rhythms
Percussion Sounds	8 Kinds
Skill Level	Beginner
Special Feature	Portable





8. WARRANTY AND SUPPORT

Moukey is committed to providing high-quality products and customer satisfaction. For specific warranty details and support inquiries regarding your MEK-200 Keyboard Piano, please refer to the warranty card included in your product packaging or visit the official Moukey website. You can also contact their customer service team directly for assistance with product registration, technical support, or replacement parts.

© 2023 Moukey. All rights reserved.

Related Documents - MEK-200

	<p><u>Moukey MEP-110 88 Key Portable Digital Piano Instruction Manual</u></p> <p>Comprehensive instruction manual for the Moukey MEP-110 88 Key Portable Digital Piano, covering setup, specifications, functions, troubleshooting, and maintenance for optimal performance and user safety.</p>
	<p><u>Moukey MAMP1 Amplifier Safety Instructions and Cautions</u></p> <p>Comprehensive safety instructions and cautions for the Moukey MAMP1 amplifier, covering power, operation, maintenance, and important warnings for safe use.</p>

	<p>Moukey MAMP1 Troubleshooting Guide</p> <p>Troubleshooting common issues with the Moukey MAMP1 amplifier, including sound quality, compatibility, product not working, and buzzing feedback.</p>
	<p>Moukey MAMP1 Troubleshooting Guide</p> <p>Troubleshooting common issues with the Moukey MAMP1 amplifier, including sound quality, compatibility, product not working, and buzzing feedback.</p>
	<p>Moukey MPA-M1 Portable PA System User Manual</p> <p>Comprehensive user manual for the Moukey MPA-M1 Multi-position PA system, detailing its features, functions, safety guidelines, troubleshooting tips, and technical specifications for optimal performance.</p>
	<p>MOUKEY MAMX1 4-Channel Line Stereo Mixer: Overview, Specs, and Safety</p> <p>Comprehensive guide to the MOUKEY MAMX1, a compact 4-channel line stereo mixer. Features include input/output details, technical specifications, application examples, and essential safety precautions.</p>