Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

FRANKE FMA807BK

Franke Maris FMA 807 BK Wall-Mounted Hood User Manual

Model: FMA807BK

Introduction

This manual provides comprehensive instructions for the installation, operation, and maintenance of your Franke Maris FMA 807 BK wall-mounted hood. Please read this manual carefully before using the appliance to ensure safe and efficient operation. Keep this manual for future reference.

Safety Information

Always adhere to local regulations regarding the discharge of air. Ensure adequate ventilation in the room when the range hood is used simultaneously with appliances burning gas or other fuels. The safety distance between the lower edge of the hood and the cooking hob must be at least 400 mm.

- Disconnect the appliance from the power supply before any cleaning or maintenance.
- Do not flambé under the range hood.
- Regularly clean the grease filters to prevent fire hazards.
- Ensure proper installation by a qualified technician.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Product Overview

The Franke Maris FMA 807 BK is a head-free wall-mounted hood designed for efficient extraction of cooking fumes. It features a sleek black glass design and intuitive touch controls.



Figure 1: Franke Maris FMA 807 BK Wall-Mounted Hood. This image shows the front view of the black glass hood with its touch control panel visible at the top center and the Franke logo.

Components:

- Hood Body (Black Glass)
- Touch Control Panel
- LED Spotlights (2x 1W, 4000°K, Neutral White)
- Metal Grease Filters (Dishwasher safe)
- Active Carbon Filter (included for recirculation mode)

Setup and Installation

The Franke Maris FMA 807 BK is designed for wall mounting. Installation should be performed by a qualified professional in accordance with all applicable local and national building and electrical codes.

Pre-Installation Checks:

- Verify that the power supply voltage matches the appliance's requirements (220-240 V).
- Ensure the wall structure is strong enough to support the hood's weight (21 kg).
- Maintain a minimum safety distance of 400 mm between the bottom edge of the hood and the cooking hob.
- Decide between extraction (ducted) or recirculation (ductless) mode. The hood supports both. For recirculation, ensure the

active carbon filter is installed.

Mounting Steps (General Guidance):

1. Mark the drilling points on the wall according to the provided template (if applicable) and the required safety distance.
2. Drill holes and insert wall plugs suitable for your wall type.
3. Secure the mounting bracket(s) to the wall.
4. Carefully lift and hang the hood onto the mounting bracket(s).
5. Connect the ducting for extraction mode or install the active carbon filter for recirculation mode.
6. Connect the appliance to the electrical supply.
7. Install the telescopic shaft (if purchased separately) to cover the ducting.

For detailed installation diagrams and specific measurements, refer to the separate installation guide provided with your product.

Operating Instructions

The hood is operated via a touch control panel located on the front glass surface.

Control Panel Functions:

- **Power On/Off:** Touch the power symbol to turn the hood on or off.
- **Fan Speed Selection:** The hood offers 3 normal fan speeds and 1 intensive speed. Touch the corresponding number (1, 2, 3) to select the desired speed. Touch the intensive speed symbol for maximum extraction.
- **Lighting Control:** Touch the light bulb symbol to turn the LED spotlights on or off. The lights provide neutral white illumination (4000°K).
- **Automatic Run-on Function:** This feature allows the fan to continue operating for a set period after cooking to ensure complete air purification. Activate this function via the control panel (specific symbol not detailed in input, but implied by "Nachlaufautomatik").

The display color for indicators is Amber.

Maintenance

Regular maintenance ensures optimal performance and longevity of your range hood.

Cleaning the Metal Grease Filters:

The metal grease filters are designed to trap grease particles from cooking fumes. They are dishwasher safe.

1. Turn off the hood and disconnect it from the power supply.
2. Remove the grease filters by releasing their latches.
3. Wash the filters in a dishwasher or by hand using hot water and a mild detergent.
4. Ensure filters are completely dry before re-installing.
5. Re-install the filters, ensuring they are securely latched.

Clean the metal grease filters at least once a month, or more frequently depending on cooking habits.

Replacing the Active Carbon Filter (for Recirculation Mode):

If your hood operates in recirculation mode, the active carbon filter removes odors from the air. This filter is not washable and must be replaced periodically.

- The active carbon filter (Franke part number 112.0016.755) is included with the product.
- Replacement frequency depends on usage, typically every 3-6 months.
- Refer to the specific instructions provided with the replacement filter for installation details.

General Cleaning:

Clean the exterior surfaces of the hood with a soft cloth and a non-abrasive cleaner. Avoid harsh chemicals or abrasive materials that could damage the black glass finish.

Troubleshooting

Before contacting customer service, please check the following common issues:

Problem	Possible Cause	Solution
Hood does not turn on.	No power supply.	Check power cord connection and circuit breaker.
Low extraction performance.	Clogged grease filters or saturated active carbon filter.	Clean grease filters or replace active carbon filter.
Excessive noise.	Improper installation or loose components.	Ensure proper installation and check for loose parts. Consult a professional if noise persists.
Lights not working.	Faulty LED spotlight.	Contact customer service for replacement.

Specifications

Feature	Detail
Model	FMA807BK
Type	Wall-mounted, Head-free Hood
Material	Glass (Black)
Width	80 cm
Energy Efficiency Class	A+
Annual Energy Consumption	40 kWh/year
Fan Speeds	3 + Intensive
Max. Extraction Rate (Intensive)	720 m^3/h
Max. Extraction Rate (Normal)	400 m^3/h
Min. Extraction Rate	220 m^3/h
Noise Level (Intensive)	70 dB(A)
Noise Level (Max)	57 dB(A)
Noise Level (Min)	47 dB(A)
Total Power	272 W
Voltage	220-240 V
Control Type	Touch Control
Lighting	2x 1W LED Spots, 4000°K (Neutral White)

Feature	Detail
Safety Distance to Hob	400 mm (minimum)
Weight	21 Kilograms
Dimensions (D x W x H)	35 x 60 x 47 cm
Included Components	Dunstabzugshaube (Range Hood), Active Carbon Filter (112.0016.755)

Warranty and Support

For warranty information and technical support, please refer to the warranty card included with your product or visit the official Franke website. Keep your proof of purchase for any warranty claims.

Recycling and Disposal:

This product contains electrical and electronic components that should not be disposed of with household waste. Please dispose of the appliance at designated collection points for the recycling of electrical and electronic equipment. For information on recycling lamps and disposing of broken or damaged lamps, consult local regulations or recycling centers.

© 2024 Franke. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07CXN28FZ

More documents and user manuals: **https://manuals.plus/**