

[Manuals.plus](#) /

› [RISEPRO](#) /

› RISEPRO Portable Camping Shower GFS1203 User Manual

RISEPRO GFS1203

RISEPRO Portable Camping Shower User Manual

Model: GFS1203

INTRODUCTION

Thank you for choosing the RISEPRO Portable Camping Shower. This device is designed to provide a convenient and portable showering solution for various outdoor and indoor activities. It features a rechargeable battery and can draw water from any bucket or water source, making it ideal for camping, hiking, pet cleaning, and car washing.

Please read this manual carefully before using the product to ensure proper operation and maintenance.

PACKAGE CONTENTS

Verify that all components are present in your package:

- Shower Head
- Hose
- Pump with On/Off Switch and Charging Socket
- Filter and Filter Cover
- USB Charging Line
- Suction Cup
- Hook
- Holder



Figure 1: All components included in the package.

SETUP

1. **Connect the Hose:** Attach one end of the hose to the pump's outlet connector and the other end to the shower head's inlet connector. Ensure connections are secure.
2. **Install the Filter:** Ensure the filter is properly seated inside the pump's inlet and the filter cover is securely attached.
3. **Prepare Water Source:** Place the pump into a bucket or container filled with water. Ensure the pump is fully submerged.
4. **Mount the Shower Head:** Use the provided suction cup to attach the shower head to a smooth surface, or use the hook to hang it from a branch or other suitable fixture. The holder can be used to secure the shower head when not in use or for hands-free operation.



Figure 2: Shower head mounted using the hook.

CHARGING

The RISEPRO Portable Camping Shower is equipped with a rechargeable 2200mAh lithium battery, providing up to 60 minutes of continuous use on a full charge. Charge the device before first use and whenever the battery is low.

There are three methods to charge the shower pump:

1. **Mobile Phone Charger:** Connect the USB charging line to a standard mobile phone charger (not included) and then to the pump's charging socket.
2. **USB Output from Laptop:** Connect the USB charging line to a laptop's USB port and then to the pump's charging socket.
3. **USB Output from Car:** Connect the USB charging line to a car's USB port or a car charger adapter and then to the pump's charging socket.



Figure 3: Charging methods for the portable shower.

Ensure the socket cover is closed when not charging to protect the charging port from water and debris.

OPERATION

1. **Submerge Pump:** Ensure the pump is fully submerged in water before turning it on. Operating the pump dry can cause damage.
2. **Activate Shower:** Press the On/Off switch located on the pump to start the water flow.
3. **Water Flow:** The shower head delivers water at approximately 2 liters per minute. A 10-liter (2.5 gallons) water source can provide 5-7 minutes of shower time.
4. **Deactivate Shower:** Press the On/Off switch on the pump again to stop the water flow.

Water flows at approx. 2 Litres per minute

Up to 5 - 7 minutes shower time with

10 litres (2.5 gallons) water

70 INCHES (180 CM) Long Hose

Rechargeable 2200mAH Lithium Battery

Works up to 60 minutes at full charge



Figure 4: Portable shower in operation, drawing water from a bucket.

Important Usage Tips:

- Always ensure the pump is submerged in water before turning it on.
- Avoid using extremely muddy or sandy water, as this can clog the filter and damage the pump.
- For optimal battery life, fully charge the device before extended use.



Figure 5: Examples of personal use in outdoor settings.



Figure 6: Portable shower being used for pet cleaning.

MAINTENANCE

- **Filter Cleaning:** Regularly check and clean the filter located at the bottom of the pump to prevent blockages and maintain optimal water flow. Remove the filter cover, rinse the filter under clean water, and reassemble.
- **Drying:** After each use, remove the pump from the water source, allow the hose and shower head to drain completely, and wipe down all components with a dry cloth.
- **Storage:** Store the portable shower in a dry, cool place away from direct sunlight when not in use. Ensure the battery is partially charged before long-term storage to preserve battery health.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No water flow or weak flow	• Pump not submerged • Filter clogged • Low battery • Hose kinked	• Ensure pump is fully submerged • Clean the filter • Recharge the battery • Straighten the hose
Pump does not turn on	• Battery is completely drained • On/Off switch malfunction	• Charge the battery for several hours • Ensure the On/Off switch is fully pressed. If issue persists, contact support.
Water leaks from connections	• Loose hose connections	• Tighten all hose connections securely

SPECIFICATIONS

- **Brand:** RISEPRO
- **Model:** GFS1203
- **Color:** Green
- **Material:** Plastic (Pump, Shower Head), Brass (Handle Material)
- **Item Weight:** 0.76 Kilograms
- **Item Dimensions (LxWxH):** 9.84 x 7.87 x 3.94 inches
- **Water Flow Rate:** Approx. 2 Liters per minute
- **Battery:** 2200mAh Lithium Battery
- **Continuous Use Time:** Up to 60 minutes (on full charge)
- **Hose Length:** 70 inches (180 cm)
- **Mounting Type:** Suction Cup, Hook

WARRANTY AND SUPPORT

For warranty information, technical support, or assistance with your RISEPRO Portable Camping Shower, please contact the manufacturer directly. Refer to the product packaging or the official RISEPRO website for contact details.