

[manuals.plus](#) /

› [LOVENSE](#) /

› [LOVENSE Lush 2 Remote Vibrator with App, Long Distance Remote Controlled G-spot Stimulator Egg Vibrators Bluetooth Adult Sex Toys & Games Powerful Vibrations for Women Couples Discreet Pleasure User Manual](#)

LOVENSE Lush 2

LOVENSE Lush 2 User Manual

Model: Lush 2 | Brand: LOVENSE

INTRODUCTION

The LOVENSE Lush 2 is an advanced remote-controlled vibrator designed for versatile pleasure. It features app control for customizable vibration patterns, long-distance connectivity, and discreet operation. Crafted from soft silicone and fully waterproof, the Lush 2 offers a comfortable and hygienic experience for both solo and partnered use.



Image: The LOVENSE Lush 2 device shown alongside a smartphone running the LOVENSE app, illustrating its remote control capabilities.

SAFETY INFORMATION

- Clean the device thoroughly before and after each use with warm water and mild soap or a toy cleaner.
- Do not use with silicone-based lubricants, as they may damage the silicone material. Use water-based lubricants only.
- Store in a cool, dry place away from direct sunlight and extreme temperatures.
- Keep out of reach of children.
- If you experience any discomfort or irritation, discontinue use immediately.

PACKAGE CONTENTS

Verify that all items are present in your LOVENSE Lush 2 package:

- 1 x LOVENSE Lush 2 Vibrator
- 1 x USB Charging Cable
- 1 x User Manual
- 1 x Storage Pouch



Image: The LOVENSE Lush 2 product box, the vibrator, USB charging cable, user manual, and a black storage pouch, indicating the

complete package contents.

Discreet Package



Image: A four-step diagram illustrating the discreet packaging process, from the product box to the plain brown shipping box, ensuring privacy for the customer.

1. Charging the Device

Before first use, fully charge your Lush 2. Connect the USB charging cable to the charging port on the device and plug the other end into a USB power source (e.g., computer, wall adapter). The indicator light will show charging status.

2. Downloading the LOVENSE App

The LOVENSE Lush 2 is primarily controlled via the LOVENSE app. Download the official LOVENSE app from your device's app store:

Download on the App Store (iOS)

Get it on Google Play (Android)

The app is compatible with iPhone/iPad Air/iPad Mini/iPod Touch iOS 14.2 and later, and Android 5.0 and later (with Bluetooth 4.0 enabled). For Windows PC, a Lovense USB Bluetooth Adapter is required.

Lovense Remote app features



Compatible with

iPhone/iPad Air/iPad Mini/iPod Touch iOS 14.2 and later
Android 5.0 and later (with Bluetooth 4.0 enabled)

Mac (with Bluetooth 4.0 enabled)

Windows PC (needs a Lovense USB Bluetooth Adapter to connect)



Any Lovense toy connects directly to Windows PC using a Lovense USB Bluetooth Adapter



Image: A graphic detailing the compatibility of the Lovense Remote app with various operating systems and the requirement for a Lovense USB Bluetooth Adapter for PC connection.

3. Connecting to the App

1. Turn on your Lush 2 by pressing and holding the power button until it vibrates.
2. Enable Bluetooth on your smartphone or device.
3. Open the LOVENSE app. The app will automatically search for and connect to your Lush 2.
4. Once connected, the device will appear in the app's "My Toys" section.

OPERATING THE LOVENSE LUSH 2

App Control

The LOVENSE app offers extensive control over your Lush 2:

- **Remote Control:** Adjust vibration intensity and patterns with a simple swipe.
- **My Patterns:** Create and save custom vibration patterns.
- **Control Link:** Share control of your device with a partner, even long-distance.

- **Music Sync:** Sync vibrations to your favorite music.
- **Sound-Activated:** Device can respond to ambient sounds.
- **Alarm Function:** Set the device to vibrate at a specific time.

Image: An overview of the LOVENSE Lush 2 and its key features, including close-range and long-distance control, unlimited vibration patterns, music sync, and sound-activated vibrations, all managed via the app.



Image: A woman enjoying music with headphones, while the Lovense Lush 2 and a smartphone screen demonstrating the music synchronization feature are displayed.




Image: A visual representation of ten distinct vibration patterns available for the Lovense Lush 2, illustrating the variety of sensations it can provide.




Image: A split image showing two individuals in different cities (New York and Berlin) connected through a video call on the Lovense app, highlighting the long-distance control feature of the Lush 2.




Image: A woman stretching in bed, with a smartphone displaying the Lovense app's alarm function, suggesting the device can be used for timed experiences.




Image: A visual representation of two individuals communicating via chat messages on their phones, with one message indicating the Lovense toy is ready, highlighting the app's online chat functionality for interactive play.

Manual Control

The Lush 2 also features a physical button for basic control:

- Press the power button to cycle through 7 built-in vibration patterns.
- Press and hold the power button to turn the device On/Off.




Image: A comparison illustrating the extensive control offered by the Lovense app (over 10,000 patterns) versus the 7 built-in patterns accessible via the device's physical button.

Discreet Use

The Lush 2 is designed for discreet use, featuring low noise levels and a comfortable, wearable design.



Image: A woman discreetly using the Lovense Lush 2 in an outdoor setting, accompanied by a graphic comparing its low noise level ($\leq 45.5\text{dB}$) to common sounds like a car (100dB) or an alarm clock (50dB), emphasizing its quiet operation.

Discreet Public Play



Image: A woman smiling and engaged in conversation in a public outdoor cafe setting, suggesting the discreet nature of the product allows for use in various environments.

MAINTENANCE

Cleaning

The Lush 2 is IPX7 waterproof, making it easy to clean. Wash the device with warm water and a mild, toy-safe soap before and after each use. Rinse thoroughly and pat dry with a lint-free cloth.



Image: The Lovense Lush 2 vibrator partially submerged in water, with ripples around it, visually confirming its waterproof design for easy cleaning.

Storage

Store your Lush 2 in the provided storage pouch in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid storing with other toys made of different materials to prevent material degradation.

Troubleshooting

Problem	Possible Solution
Device not turning on.	Ensure the device is fully charged. Press and hold the power button for a few seconds.
Device not connecting to app.	• Ensure Bluetooth is enabled on your device. • Make sure the Lush 2 is turned on and within range. • Close and reopen the LOVENSE app. • Restart your smartphone/device. • Check app permissions for Bluetooth.
Vibrations are weak or inconsistent.	Recharge the device. Ensure the app is updated to the latest version.
App crashes or freezes.	Update the app to the latest version. Clear the app's cache or reinstall it.

Specifications

Feature	Detail
Model	Lush 2
Material	Body-safe Silicone
Dimensions	3 x 1.5 x 5.2 inches (76 x 37 x 133 mm)
Weight	7.05 ounces
Battery	1 Lithium Ion battery (included)
Run Time	2.5-3 hours of continuous use
Water Resistance	IPX7 Waterproof
Connectivity	Bluetooth 4.0



Image: A detailed diagram illustrating the dimensions of the Lovense Lush 2 vibrator in both inches and millimeters, along with a visual representation of its ON/OFF and 7 pattern functions.




Image: A visual comparison of the Lovense Lush 2's size relative to a smartphone, alongside a list of included package details such as the user manual, charging cable, and storage pouch.

WARRANTY & SUPPORT

Warranty Information

The LOVENSE Lush 2 comes with a 1-Year Warranty. Please retain your proof of purchase for warranty claims.

Customer Support

For any questions, concerns, or technical assistance, please contact LOVENSE Official Store customer support. Our support team is available to assist you within 24 hours.

Visit the official LOVENSE Store for more information: [LOVENSE Official Store](#)




Image: A graphic highlighting the key features of the Lovense Lush 2, such as 2.5-3 hours of continuous use, body-safe materials, waterproof design, hands-free operation, USB rechargeability, and a 1-year warranty.

Related Documents - Lush 2

	Lovense Lush User Manual: Setup, Features, and Support Comprehensive guide for the Lovense Lush personal massager by LOVENSE, covering setup, charging, connection, partner features, troubleshooting, specifications, and warranty information.
	Lovense Lush Personal Massager User Guide and Specifications Discover the Lovense Lush, a remote-controlled personal massager. This guide covers charging, operation, cleaning, app connectivity, specifications, and important safety warnings for the Lovense Lush device.
	Lovense Hyphy User Manual: Operation and Care Guide Official user manual for the Lovense Hyphy dual-end vibrator. Learn about its features, button functions, charging, cleaning, specifications, usage tips, warnings, and warranty.
	Lovense Max 2 User Manual: Features, Specs & Usage Guide Discover the Lovense Max 2, a premium Bluetooth-enabled male masturbator. This comprehensive user manual covers setup, operation, charging, cleaning, specifications, and warranty details for optimal pleasure.
	Lovense Lush 2 User Manual: Specifications and Guide User manual for the Lovense Lush 2, covering device features, specifications, charging, cleaning, usage tips, warnings, and warranty information.
	Lovense Lush 2 User Manual: Features, Specifications, and Care Guide Comprehensive user manual for the Lovense Lush 2, a Bluetooth-enabled remote control vibrator. Learn about its features, specifications, charging, cleaning, usage tips, warnings, and warranty information.