

## Dyson 967752-01

# Dyson V7 V8 Quick Release Up Top Adaptor Tool (Part 967752-01) User Manual

Your guide to effectively using and maintaining your Dyson Up Top Adaptor Tool.

## PRODUCT OVERVIEW

The Dyson Quick Release Up Top Adaptor Tool is designed to extend the reach and flexibility of your Dyson V7 or V8 vacuum cleaner. It allows you to clean high, low, and awkward spaces by adjusting the angle of your attached cleaning head.



An image showing the Dyson Quick Release Up Top Adaptor Tool, a silver-colored, articulated accessory designed to connect to Dyson vacuum wands and adjust its angle for reaching high or awkward spaces. It features a red quick-release button and a circular pivot point.

## SETUP

- 1. Ensure Compatibility:** Verify that your Dyson vacuum is a V7 or V8 model. This adaptor is specifically designed for these series.
- 2. Attach to Wand:** Locate the quick-release end of your Dyson vacuum wand. Align the adaptor tool with

the wand until it clicks securely into place. The red quick-release button on the adaptor should align with the corresponding slot on the wand.

3. **Attach Cleaning Head:** Connect your desired Dyson cleaning head (e.g., soft dusting brush, crevice tool) to the other end of the Up Top Adaptor Tool. Ensure it clicks securely.

The tool is now ready for use. Always ensure all connections are secure before operating your vacuum.

## OPERATING INSTRUCTIONS

The Up Top Adaptor Tool features multiple adjustable angles to facilitate cleaning in hard-to-reach areas.

1. **Adjusting the Angle:** The tool has a pivot point that allows it to bend. Gently push or pull the two sections of the adaptor to change its angle. It will lock into several predefined positions, typically including a straight (180-degree) position and a 90-degree angled position.
2. **Cleaning High Surfaces:** For cleaning tops of shelves, ceiling fan blades, or light fixtures, adjust the adaptor to an acute angle (e.g., 90 degrees) to position the cleaning head appropriately.
3. **Cleaning Low or Awkward Spaces:** The adaptor can also be used to reach under furniture or around obstacles by adjusting its angle to suit the space.
4. **Extension:** When set to the straight (180-degree) position, the adaptor acts as an extension, adding approximately 7-8 inches to your vacuum's reach.

Always ensure the adaptor is securely locked into a position before applying pressure during cleaning to prevent accidental movement.

## MAINTENANCE

To ensure the longevity and optimal performance of your Up Top Adaptor Tool, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the exterior of the adaptor with a dry or slightly damp cloth. Do not immerse the tool in water.
- **Inspect Connections:** Periodically check the quick-release mechanisms for any debris or damage that might prevent a secure connection.
- **Storage:** Store the adaptor in a clean, dry place away from extreme temperatures.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Tool does not attach securely.	Debris in connection point; incorrect alignment; incompatible model.	Clean connection points. Ensure proper alignment until a click is heard. Confirm vacuum is a V7 or V8 model.
Adaptor does not hold its angle.	Not fully locked into position; excessive force applied.	Ensure the adaptor is pushed or pulled until it clicks into a locked position. Avoid applying excessive leverage.

## SPECIFICATIONS

- **Model Number:** 967752-01
- **Compatibility:** Dyson V7, Dyson V8 series vacuum cleaners
- **Material:** Durable plastic and metal components
- **Adjustable Angles:** Multiple fixed positions, including 90-degree and 180-degree (straight)
- **Approximate Dimensions:** 11.81 x 11.42 x 2.05 inches (Package Dimensions)
- **Approximate Weight:** 14.39 ounces (Package Weight)




## WARRANTY AND SUPPORT


For information regarding product warranty, please refer to the documentation provided with your original Dyson vacuum cleaner or visit the official Dyson website.

If you require further assistance or have questions about your Dyson Quick Release Up Top Adaptor Tool, please contact Dyson Customer Support:

- **Dyson Official Website:** [www.dyson.com](http://www.dyson.com)
- **Customer Service:** Refer to the contact section on the Dyson website for phone numbers and live chat options specific to your region.

## Related Documents - 967752-01

 <p>In the box Getting started LEDs Using your hair dryer Regular filter cleaning</p>	<p><a href="#">Dyson Supersonic Hair Dryer User Manual</a></p> <p>Comprehensive user manual for the Dyson Supersonic hair dryer, covering setup, usage, LED indicators, attachments, and filter cleaning.</p>
 <p>In the box Getting started LEDs Using your hair dryer Regular filter cleaning</p>	<p><a href="#">Dyson Supersonic Hair Dryer User Manual and Guide</a></p> <p>Comprehensive user manual for the Dyson Supersonic hair dryer, covering setup, features, attachments, LED indicators, diagnostics, and filter cleaning for optimal performance.</p>
 <p>In the box Getting started LEDs Using your hair dryer Regular filter cleaning</p>	<p><a href="#">Dyson Supersonic User Manual - Features, Attachments, and Maintenance Guide</a></p> <p>Comprehensive user manual for the Dyson Supersonic hair dryer, covering setup, features, attachments, LED indicators, and filter maintenance. Learn how to use and care for your Dyson Supersonic.</p>

 <p><b>supersonic r</b> Dyson Supersonic™ hair dryer User manual</p> <p>Contents In the box Features Getting started dyson dyelectric</p>	<p><a href="#">Dyson Supersonic r™ Hair Dryer User Manual: Operation and Maintenance</a></p> <p>Comprehensive user manual for the Dyson Supersonic r™ hair dryer, covering in-box contents, functions, getting started, usage, and filter cleaning instructions. Learn how to operate and maintain your Dyson Supersonic r™.</p>
 <p><b>dyson v12 detect slim</b> User manual</p> <p>Contents In the box Features Getting started dyson dyelectric</p>	<p><a href="#">Dyson V12 Detect Slim User Manual - Comprehensive Guide</a></p> <p>Your comprehensive guide to the Dyson V12 Detect Slim cordless vacuum cleaner. Learn how to set up, operate, clean, and maintain your vacuum for optimal performance, including detailed instructions for all included tools and accessories.</p>
 <p>1 2 3 4 5</p>	<p><a href="#">Dyson V11/V15 Vacuum Cleaner Dust Bin Attachment Guide</a></p> <p>Step-by-step instructions for securely attaching the dust bin assembly to Dyson V11, V15, SV14, SV15, and SV22 vacuum cleaner models. Includes visual guidance and safety tips.</p>