Rii X8

Rii X8 Mini Wireless Keyboard User Manual

Model: X8

1. Introduction

The Rii X8 Mini Wireless Keyboard is a compact and versatile input device designed for seamless control across various platforms. Featuring a full QWERTY keyboard layout, a multi-touch touchpad, and RGB backlighting, it offers an intuitive and efficient user experience for your entertainment and computing needs.
This manual provides detailed instructions for setting up, operating, and maintaining your Rii X8 Mini Wireless Keyboard.

2. Package Contents

- 1 x Rii X8 Mini Wireless Keyboard
- 1 x USB Dongle (2.4GHz receiver)
- 1 x USB Charging Cable
- 1 x Lithium Polymer Battery (pre-installed or separate)
- 1 x User Manual (this document)




Figure 1: Package Contents - Rii X8 Mini Wireless Keyboard, USB dongle, charging cable, and user manual.

3. Specifications

Feature	Description
Model	X8
Connectivity	2.4GHz Wireless (via USB Dongle)
Keyboard Layout	QWERTY
Touchpad	Multi-touch with Left/Right mouse buttons
Backlight	8-Color RGB Backlit
Battery	Rechargeable Lithium Polymer (BL-5B type)
Dimensions	7.17 x 4.17 x 0.98 inches

Weight	6.4 ounces
Compatible Devices	Laptop, Gaming Console, PC, Television (Android TV Box, Raspberry Pi, HTPC, Mac, Nvidia Shield)

4. Setup Guide

4.1 Initial Charging

Before first use, fully charge the keyboard using the provided USB charging cable. Connect the micro USB end to the keyboard's charging port (located on the side) and the USB-A end to a powered USB port (e.g., computer, USB wall adapter).



Figure 2: Charging the Rii X8 Mini Keyboard.

4.2 Connecting to Your Device (2.4GHz Wireless)

1. Locate the USB dongle: The USB dongle is stored in the battery compartment on the back of the keyboard. Gently slide open the battery cover to access it.



Figure 3: USB Dongle storage location.

2. Insert the USB dongle: Plug the USB dongle into an available USB port on your target device (e.g., PC, Android TV Box, Smart TV).
3. Turn on the keyboard: Locate the power switch on the keyboard (usually on the side or top edge) and slide it to the

"ON" position.

4. Automatic connection: The keyboard should automatically connect to your device within a few seconds. No additional drivers are typically required for most operating systems (Plug and Play).

Note: For Amazon Fire TV 4K and Amazon Fire Stick, a Micro USB host OTG cable may be required to connect the USB dongle.

5. Operating Instructions

5.1 Keyboard Functions

The Rii X8 features a full QWERTY keyboard layout, providing all standard alphanumeric keys. Function keys (F1-F12) are accessible by pressing the **Fn** key simultaneously with the corresponding number key.




Figure 4: Rii X8 Mini Keyboard layout and key functions.

5.2 Touchpad Usage

The integrated multi-touch touchpad allows for precise cursor control and gesture-based navigation.

- **Single Finger Tap:** Left mouse click.

- **Two Finger Tap:** Right mouse click.
- **Two Finger Scroll:** Slide two fingers up or down on the touchpad to scroll content.
- **Single Finger Drag:** Move your finger across the touchpad to control the cursor.



Figure 5: Touchpad gestures for the Rii X8 Mini Keyboard.

5.3 Multimedia and Navigation Buttons

Dedicated multimedia and navigation buttons are located around the touchpad and on the top edges for quick access to common functions.

- **Direction Keys (D-Pad):** For menu navigation and precise movement.
- **OK Button:** Confirms selections.
- **Scroll Wheel:** Provides an alternative method for scrolling through content.
- **Volume Controls:** Adjust audio output.
- **Home Button:** Returns to the home screen of compatible devices.



Figure 6: Detail of the scroll wheel and multimedia controls.

5.4 RGB Backlighting

The keyboard features 8-color RGB backlighting for improved visibility in low-light conditions. To activate or change the backlight color, press the **Fn** key simultaneously with the **Win** key (which typically has a light bulb icon).



Figure 7: Rii X8 Mini Keyboard with RGB backlighting.



Figure 8: Activating and changing backlight colors using Fn + Win key.

5.5 Power Saving Mode

The keyboard is designed with an automatic sleep mode to conserve battery life. If inactive for a period, it will enter sleep mode. Press any key to wake it up.

5.6 IR Learning Function (If applicable to specific models)

Some Rii X8 models may feature an IR learning function, allowing you to program certain keys to control your TV's power or volume using infrared signals. Refer to your specific model's supplementary documentation for detailed instructions on IR learning, as this feature is not universal across all X8 variants.
Typically, this involves entering a learning mode on the keyboard, then aligning it with your TV remote and pressing the desired buttons to transfer the IR signal.

6. Maintenance and Care

- **Cleaning:** Use a soft, dry cloth to clean the keyboard surface. For stubborn dirt, a slightly damp cloth with mild soap can be used, ensuring no liquid enters the device.
- **Storage:** Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge it regularly. If storing for a long period, charge it to about 50% every few months.

7. Troubleshooting

Problem	Possible Solution
Keyboard not responding	1. Ensure the keyboard is turned ON. 2. Check if the USB dongle is securely plugged into the device. 3. Try plugging the USB dongle into a different USB port. 4. Ensure the keyboard battery is charged. 5. Re-pair the keyboard by turning it off and on, and re-inserting the USB dongle.
Cursor erratic or unresponsive	1. Clean the touchpad surface. 2. Ensure your fingers are dry and clean when using the touchpad. 3. Check for any obstructions around the touchpad.
Backlight not working	1. Ensure the keyboard is turned ON. 2. Press **Fn** + **Win** (light bulb icon) to activate or cycle through colors. 3. Charge the keyboard battery.
Short battery life	1. Ensure the keyboard is fully charged. 2. Turn off the keyboard when not in use. 3. Reduce backlight brightness or turn it off when not needed.

8. Warranty and Support

Rii products typically come with a standard manufacturer's warranty. Please refer to the warranty card included in your package or visit the official Rii website for detailed warranty terms and conditions.
For technical support, product inquiries, or warranty claims, please contact Rii customer service through their official website or the contact information provided in your product packaging.
You can also visit the Rii Store on Amazon for more information and product updates.

© 2024 Rii. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I change the Rii X8 keyboard layout to AZERTY?

The Rii X8 Mini Wireless Keyboard is physically designed with a QWERTY layout. To make the keyboard function as AZERTY, you must change the input settings on the device it is connected to (e.g.,...

Read full answer

How do I reset the Rii X8 Mini Wireless Keyboard?

The Rii X8 Mini Wireless Keyboard does not have a dedicated physical reset button. To resolve connection issues or "reset" the device's link to your computer or TV box, follow the re-pairing steps provided...

Read full answer