

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Ikea](#) /

> [Ikea Brogrund 703.285.27 Chrome Shower Shelf User Manual](#)

Ikea 703.285.27

Ikea Brogrund 703.285.27 Chrome Shower Shelf User Manual

Model: 703.285.27

1. INTRODUCTION

Thank you for choosing the Ikea Brogrund shower shelf. This manual provides essential information for the safe and correct assembly, operation, and maintenance of your new shower shelf. Please read these instructions carefully before installation and keep them for future reference.

The Ikea Brogrund shower shelf, model 703.285.27, is designed for convenient storage in your shower area. It features a durable chrome-plated ABS plastic basket and polyamide fixation components. The shelf's height can be easily adjusted on compatible shower rails or bars, and integrated drainage holes ensure water flows out easily, preventing accumulation. The hard, durable chrome surface is also easy to clean.

2. SAFETY INFORMATION

- Always ensure the shower shelf is securely mounted to prevent it from falling and causing injury or damage.
- Do not overload the shelf. Exceeding its weight capacity may cause it to detach or break.
- Keep small children away from the installation area during assembly.
- Regularly check the shelf's attachment for any signs of loosening or wear.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- 1 x Brogrund Shower Shelf (Chrome-plated ABS plastic basket)
- Fixation components (Polyamide)

If any parts are missing or damaged, please contact your retailer.

4. SETUP AND INSTALLATION

This product requires assembly. Follow these steps for proper installation:

- 1. Prepare the Shower Rail:** Ensure your shower rail or bar has a diameter between 2.5 cm and 3.5 cm. Clean the section of the rail where the shelf will be installed.
- 2. Attach Fixation Components:** Secure the polyamide fixation components to the back of the shower shelf basket according to the included diagram (if provided with the physical product). These components

are designed to grip the shower rail.

3. **Mount the Shelf:** Position the shelf onto the shower rail at your desired height. The flexible support allows for easy adjustment. Ensure the fixation components are firmly gripping the rail.
4. **Secure in Place:** Once the desired height is achieved, tighten any securing mechanisms on the fixation components to prevent the shelf from sliding down. Test the stability of the shelf by gently pressing down on it.



Image 1: The Ikea Brogrund shower shelf installed on a shower rail, demonstrating its placement within a shower environment.

5. OPERATING INSTRUCTIONS

The Ikea Brogrund shower shelf is designed for straightforward use:

- **Storage:** Place your shower essentials such as soap, shampoo bottles, sponges, and brushes directly into the shelf basket.
- **Height Adjustment:** To adjust the shelf's height, loosen the fixation components, slide the shelf to the new desired position on the shower rail, and then re-tighten the components securely.
- **Drainage:** The integrated holes at the bottom of the shelf allow water to drain away, keeping your items dry and preventing water accumulation.



Image 2: Close-up view of the shower shelf in use, holding soap and a brush, highlighting its drainage design.



Image 3: The shower shelf holding a sponge and pumice stone, demonstrating its capacity for various shower items.

6. MAINTENANCE

To ensure the longevity and appearance of your Ikea Brogrund shower shelf, follow these maintenance guidelines:

- **Cleaning:** The chrome surface is hard, durable, and easy to clean. Wipe the shelf regularly with a soft cloth dampened with water or a mild, non-abrasive cleaning solution.
- **Avoid Harsh Cleaners:** Do not use abrasive powders, scouring pads, ammonia-based cleaners, or acidic cleaners, as these can damage the chrome finish.
- **Rinse and Dry:** After cleaning, rinse thoroughly with clean water and dry with a soft, clean cloth to prevent water spots and maintain shine.
- **Drainage Holes:** Periodically check and clear the drainage holes at the bottom of the shelf to ensure proper water flow.

7. TROUBLESHOOTING

If you encounter any issues with your shower shelf, refer to the following common solutions:

- **Shelf is sliding down:** Ensure the fixation components are correctly positioned and securely tightened on the shower rail. The rail diameter must be within the specified range (2.5 cm to 3.5 cm).
- **Water pooling in the shelf:** Check if the drainage holes are clear of debris. Clean them if necessary.
- **Shelf appears loose:** Re-check all attachment points and tighten any loose components. Avoid overloading the shelf.

8. SPECIFICATIONS

Feature	Detail
Brand	Ikea
Model Number	703.285.27
Manufacturer	Ikea Brogrund
Product Dimensions (L x W x H)	11 x 25 x 11 cm
Product Weight	274 grams
Material	Chrome-plated Acrylonitrile Butadiene Styrene (ABS) plastic, Polyamide (fixation)
Shape	Rectangular
Mounting Type	Attaches to shower rail (compatible with 2.5 cm to 3.5 cm diameter rails)
Special Features	Lightweight, Adjustable Height, Drainage Holes
Usage	Shower
Date First Available	April 26, 2022

9. WARRANTY INFORMATION

The Ikea Brogrund shower shelf comes with a 3-year warranty. For full terms and conditions, please refer to the warranty brochure provided with your purchase or visit the official Ikea website. This warranty covers defects in materials and workmanship under normal use.

10. CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report a missing or damaged part, please contact Ikea customer service or your local retailer. Please have your model number (703.285.27) and proof of purchase ready when contacting support.

For more information, visit www.ikea.com.