

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Bayer Design](#) /
- › [Bayer Design 18125AA City Neo Doll Stroller Instruction Manual](#)

Bayer Design 18125AA

Bayer Design 18125AA City Neo Doll Stroller Instruction Manual

Model: 18125AA

1. INTRODUCTION

This manual provides essential instructions for the safe assembly, operation, and maintenance of your Bayer Design 18125AA City Neo Doll Stroller. Please read this manual thoroughly before use and retain it for future reference.

2. SAFETY INFORMATION

Warning! Not suitable for children under 3 years. Small parts. Choking hazard!

Warning! For safety reasons, remove all labels, plastics and/or elastic loops, labels, strings, and mounting accessories before giving this toy to a child.

- Always supervise children during play.
- Ensure all parts are securely assembled before use.
- Do not allow children to climb on or stand in the stroller.
- This product is a toy and is not intended for transporting real infants or pets.

3. PACKAGE CONTENTS

Verify that all components are present in the package:

- Stroller frame
- Convertible bassinet/seat unit
- Diaper bag
- Shopping basket
- Wheels (4 pieces)
- Instruction Manual

4. SETUP AND ASSEMBLY

Assembly is required. Follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Unfold the Frame:** Locate the locking mechanisms on the stroller frame. Release them and unfold the frame until it clicks into place, ensuring it is fully extended and stable.
3. **Attach the Wheels:** Insert each wheel into its designated axle on the stroller frame until it locks securely. Ensure all four wheels are firmly attached and rotate freely.
4. **Attach the Bassinet/Seat Unit:** Align the connectors on the bassinet/seat unit with the corresponding slots on the stroller frame. Press down firmly until it clicks into place. Verify that the unit is securely fastened.
5. **Attach the Shopping Basket:** Secure the shopping basket to the designated hooks or clips on the underside of the stroller frame.
6. **Attach the Diaper Bag:** Hang the diaper bag on the handle of the stroller using its straps.



Figure 4.1: Fully assembled doll stroller in bassinet configuration with diaper bag.

5. OPERATING INSTRUCTIONS

5.1. Adjusting the Handle Height

The stroller handle is adjustable to accommodate different user heights (59 cm - 79 cm). Locate the adjustment buttons on either side of the handle. Press these buttons simultaneously and slide the handle up or down to the desired height. Release the buttons to lock the handle in position.

5.2. Converting from Bassinet to Sports Stroller

The City Neo doll stroller can be easily converted between a bassinet and a sports stroller configuration.

1. **To Convert to Sports Stroller:** Locate the recline adjustment mechanism on the side or back of the

bassinet unit. Adjust the recline to an upright or semi-upright position. The footrest section may also need to be adjusted downwards.

2. **To Convert to Bassinet:** Adjust the recline mechanism to a flat, horizontal position. Ensure the footrest is raised to create an enclosed bassinet space.



Figure 5.1: Doll stroller configured as a bassinet.



Figure 5.2: Doll stroller configured as a sports stroller.

5.3. Using the Shopping Basket and Diaper Bag

The integrated shopping basket located under the seat provides storage for small items. The included diaper bag can be used to carry doll accessories and can be hung on the stroller handle.

5.4. Folding for Transport

To fold the stroller for storage or transport, ensure the bassinet/seat unit is in a compact position. Locate the folding mechanisms (typically near the handle or on the frame joints). Engage these mechanisms according to the visual instructions provided with the product to collapse the frame. Always ensure fingers are clear of moving parts during folding.

6. MAINTENANCE

6.1. Cleaning

- **Fabric Parts:** Wipe fabric surfaces with a damp cloth and mild soap. Allow to air dry completely. Do not machine wash or tumble dry.
- **Frame and Wheels:** Clean the metal frame and plastic wheels with a damp cloth. Avoid abrasive cleaners.

6.2. Storage

Store the doll stroller in a clean, dry place away from direct sunlight and extreme temperatures to prevent material degradation.

7. TROUBLESHOOTING

- **Stroller does not fold/unfold smoothly:** Check for any obstructions in the folding mechanism. Ensure all locking levers are disengaged before attempting to fold, and fully engaged when unfolding.
- **Wheels do not turn freely:** Inspect wheels for debris (hair, lint, etc.) and remove if present. Ensure wheels are correctly attached and locked into place.
- **Unit feels unstable:** Verify that all assembly steps have been completed correctly and all locking mechanisms (frame, seat unit, wheels) are securely engaged.

8. SPECIFICATIONS



Figure 8.1: Product dimensions.

Feature	Detail
Model Number	18125AA
Product Dimensions (L x W x H)	79 cm x 38.5 cm x 82 cm

Feature	Detail
Item Weight	3.79 kg
Recommended Age	36 months - 7 years
Suitable Doll Size	Up to 52 cm
Adjustable Handle Height	59 cm - 79 cm
Material Type	Metal, Polyester
Material Composition	55.72% steel, 15.65% 300D polyester, 13.28% PP/EVA, 12.21% PP, 0.9% nylon, 0.63% polyester
Assembly Required	Yes
Batteries Required	No
Wheel Type	Swivel
Educational Goals	Social behavior

9. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the contact details provided on the product packaging or visit the official Bayer Design website. Keep your proof of purchase for any warranty claims.