

Lenco Xemio-768

Lenco Xemio-768 Digital Media Player Instruction Manual

Model: Xemio-768 | Brand: Lenco

INTRODUCTION

This instruction manual provides detailed guidance for the safe and efficient use of your Lenco Xemio-768 Digital Media Player. Please read this manual thoroughly before operating the device and retain it for future reference. The Lenco Xemio-768 is a versatile digital media player capable of playing MP3/MP4 files, displaying photos, reading e-books, and recording voice memos. It features Bluetooth connectivity for wireless audio and an expandable memory via Micro SD card.

PACKAGE CONTENTS

- Lenco Xemio-768 Digital Media Player
- USB Cable
- In-Ear Headphones
- 8GB Micro SD Card (pre-installed or included separately)
- Instruction Manual (this document)

DEVICE OVERVIEW

Familiarize yourself with the various parts and controls of your Xemio-768 player.



Image 1: Front view of the Lenco Xemio-768 Digital Media Player. The screen displays the Bluetooth menu option. Below the screen are the Lenco logo and a circular control pad with playback buttons (previous, next, play/pause) and a menu button (M). A Bluetooth symbol is also visible on the bottom left of the device.

Key Controls and Ports:

- **1.8-inch TFT LCD Screen:** Displays menus, media, and settings.
- **Control Pad:** Navigation and playback controls (Play/Pause, Next/Fast Forward, Previous/Rewind, Menu).
- **Micro USB Port:** For charging and data transfer.
- **Micro SD Card Slot:** For memory expansion (supports up to 32GB).
- **3.5 mm Headphone Jack:** For wired headphone connection.
- **Built-in Microphone:** For voice recording.

SETUP

1. Charging the Device

1. Connect the small end of the included USB cable to the Micro USB port on the player.
2. Connect the larger end of the USB cable to a powered USB port on a computer or a USB wall adapter (not included).
3. The battery indicator on the screen will show charging status. A full charge typically takes approximately 3 hours.
4. Disconnect the USB cable once fully charged.

2. Inserting a Micro SD Card (Optional)

The player comes with an 8GB Micro SD card. If you wish to expand the storage, you can replace it with a card up to 32GB.

1. Locate the Micro SD card slot on the side of the player.
2. Gently insert the Micro SD card with the gold contacts facing down until it clicks into place.
3. To remove, gently push the card in until it clicks, then release, and it will spring out.

3. Connecting Headphones

- **Wired Headphones:** Plug the 3.5 mm jack of the included in-ear headphones (or your own compatible headphones) into the headphone port on the player.
- **Bluetooth Headphones/Speakers:** Refer to the "Bluetooth Connectivity" section under Operating for wireless connection instructions.

4. Transferring Files

1. Connect the player to your computer using the USB cable.
2. The player will appear as a removable disk drive on your computer.
3. Drag and drop your desired music (MP3, WMA), videos (AMV, AVI), photos (JPG, BMP, GIF), or e-books (TXT) into the appropriate folders on the player's internal memory or Micro SD card.
4. Once files are transferred, safely eject the removable disk from your computer before disconnecting the USB cable.

OPERATING INSTRUCTIONS

Power On/Off

- To power on, press and hold the Power button (usually on the side) until the screen lights up.
- To power off, press and hold the Power button until the device shuts down.

Menu Navigation

- Use the directional buttons on the control pad to navigate through menu options.
- Press the central button (often Play/Pause) to select an option.
- Press the 'M' (Menu) button to go back to the previous menu or to access context-sensitive options during playback.

Music Playback

1. From the main menu, select "Music".
2. Browse through your folders and files to find the desired track.
3. Press the central button to play the selected track.
4. Use the **Previous** and **Next** buttons to skip tracks.
5. Press the central button again to pause/resume playback.

Video Playback

1. From the main menu, select "Video".
2. Navigate to your video files (AMV, AVI format).
3. Select a video to begin playback.

Photo Viewer

1. From the main menu, select "Photos".
2. Browse your image files (JPG, BMP, GIF format).
3. Select an image to view it.

E-book Reader

1. From the main menu, select "E-book".
2. Navigate to your text files (TXT format).
3. Select a file to open and read.

Voice Recording

1. From the main menu, select "Recorder" or "Voice Memo".
2. Select "Start Recording" to begin.
3. Press the central button to stop recording.
4. Recordings are saved and can be accessed from the "Recordings" menu.

Bluetooth Connectivity

1. Ensure your Bluetooth headphones or speaker are in pairing mode. Refer to their respective manuals for instructions.
2. On the Xemio-768, navigate to the "Bluetooth" menu.
3. Select "Search for Devices" or "Pair New Device".
4. Once your device appears in the list, select it to initiate pairing.
5. Confirm pairing on both devices if prompted.
6. Once connected, audio will be routed wirelessly to your Bluetooth device.

MAINTENANCE

Cleaning

- Use a soft, dry, lint-free cloth to clean the device's exterior.
- Do not use abrasive cleaners, alcohol, or solvents, as these may damage the surface.
- Avoid getting moisture into any openings.

Battery Care

- To prolong battery life, avoid fully discharging the battery frequently.
- Charge the device regularly, even if not in use for extended periods.
- Store the device in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device using the provided USB cable.
Cannot connect via Bluetooth.	Bluetooth device not in pairing mode; interference; device out of range.	Ensure your Bluetooth headphones/speaker are in pairing mode. Move closer to the player. Try restarting both devices.
Files are not recognized or played.	Incorrect file format; corrupted file; Micro SD card issue.	Ensure files are in supported formats (MP3, WMA, AMV, AVI, JPG, BMP, GIF, TXT). Check if the Micro SD card is properly inserted or try another card.

Problem	Possible Cause	Solution
No sound from headphones.	Headphones not properly connected; volume too low; corrupted audio file.	Check headphone connection. Increase volume. Test with different headphones or audio files.

SPECIFICATIONS

- **Model:** Xemio-768
- **Display:** 1.8-inch TFT LCD
- **Internal Memory:** 8 GB (via Micro SD card)
- **Expandable Memory:** Up to 32 GB (Micro SD card)
- **Supported Audio Formats:** MP3, WMA
- **Supported Video Formats:** AMV, AVI
- **Supported Image Formats:** JPG, BMP, GIF
- **Supported E-book Format:** TXT
- **Connectivity:** Bluetooth, Micro USB
- **Headphone Jack:** 3.5 mm
- **Battery Type:** Lithium Polymer
- **Battery Life:** Approximately 3 hours (playback)
- **Dimensions:** 0.09 x 4.15 x 8.5 cm
- **Weight:** 28.5 g

WARRANTY AND SUPPORT




For warranty information and technical support, please refer to the warranty card included with your product or visit the official Lenco website. Keep your proof of purchase for any warranty claims.




© 2023 Lenco. All rights reserved.

Related Documents - Xemio-768

	Lenco Xemio-768/MP-208 MP3/MP4 Player User Manual Official user manual for the Lenco Xemio-768 and MP-208 MP3/MP4 players with Bluetooth. Contains detailed instructions, safety precautions, operational guides, and troubleshooting tips for the portable media device.
	Lenco Xemio-860 MP3/MP4 Player User Manual Explore the Lenco Xemio-860 MP3/MP4 Player. This user manual details its features, including Bluetooth connectivity, 8GB storage, and support for multiple audio/video formats. Learn about safe operation, technical specifications, and warranty information from Lenco.
	Lenco Xemio-768 / MP-208 Quick Guide - Portable MP3 Player Manual Concise quick start guide for the Lenco Xemio-768 and MP-208 portable MP3 player. Learn about controls, charging, Bluetooth pairing, menu navigation, and safety information.

	Lenco Xemio-668 / MP-108 User Manual Comprehensive user manual for the Lenco Xemio-668 and MP-108 portable media players, detailing setup, operation, features, safety, and troubleshooting.
	Lenco Xemio-560 Quick Guide: Features, Operation, and Specifications A comprehensive quick guide for the Lenco Xemio-560 8GB MP3/MP4 player, covering its features, technical specifications, operation for music, video, recording, and settings, along with safety and warranty information.
	Lenco Xemio-768 / MP-208 MP3 Player Quick Guide Quick guide for the Lenco Xemio-768 and MP-208 MP3 player, covering controls, connections, charging, Bluetooth, and basic operations.


Documents - Lenco – Xemio-768



[pdf] User Manual Installation Guide Instructions Guide
USER S MANUAL Owner Xemio 768 User s Manual Guide for Lenco mp3 mp4 Player Free Instruction UM XEMIO ALL central manu
lenco |||
USER S MANUAL **Xemio-768** MP3 / MP4 player with Bluetooth For more information: www.lenco.com 1 Eng
Xemio-768 CAUTION: Usage of controls or adjustments or performance of procedures other than those spe
herein may result in hazardous radiation exposure. This unit should not be adjusted or...
lang:en score:66 filesize: 2.7 M page_count: 165 document date: 2019-03-11



[pdf] User Manual
Microsoft Word XEMIO 768 UM PT Decl BT Alexandra Martins Xemio manual v2 0 Lenco Pink kopen Nu in de Officiële Shop
160a6e19b205e206400547c234c865674c2be5f1 cdn maxx nl |||
MANUAL DO UTILIZADOR **Xemio-768** BT Leitor MP3/MP4 com Bluetooth Para mais informaes: www.lenco
Precaues No coloque chamas expostas, tais como velas acesas, em cima ou perto do produto. No coloque
com liquidos, tais como vasos, em cima ou perto do produto. No utilize nem guarde este ...
lang:pt score:40 filesize: 1.93 M page_count: 28 document date: 2023-05-11




[\[pdf\]](#) User Manual

USER S MANUAL Owner Xemio 768 MP 208 manual v2 0 NL EN DE FR ES DK SE Lenco Pink kopen Nu in de Officiële Shop
03650234ad990ad3d71e4fc55afddab684948614 cdn maxx nl |||

USER S MANUAL **Xemio-768**/ MP-208 MP3 / MP4 player with Bluetooth For more information: www.lenco.com
Index English

lang:en **score:37** filesize: 3.23 M page_count: 201 document date: 2023-03-14



[\[pdf\]](#) User Manual Installation Guide Instructions

USER S MANUAL Owner Xemio 768 M E Mode d emploi Lecteur mp3 mp4 Lenco Notice gratuite en Français UM XEMIO ALL centre
manuels baladeur lenco |||

USER S MANUAL **Xemio-768** MP3 / MP4 player with Bluetooth For more information: www.lenco.com 1 En
Xemio-768 CAUTION: Usage of controls or adjustments or performance of procedures other than those spe
herein may result in hazardous radiation exposure. This unit should not be adjusted or...

lang:en **score:36** filesize: 2.7 M page_count: 165 document date: 2019-03-11




[\[pdf\]](#) User Manual Guide Declaration of Conformity

M14R mmak Lenco XEMIO 768 MP3 MP4 player with Bluetooth Manual vejledning EN afspiller med LNCO XEMIO768 doc av connet
Products |||

Model: **Xemio-768** / MP-208 Quick Guide Korte handleiding Kurzanleitung Guide rapide Gua Rpida For infor
and support, www.lenco.com Zie voor informatie en ondersteuning www.lenco.com Informationen und
Helpdesk:www.lenco.com Pour des informations et une assistance, visitez : www.lenco.com Para ms...


lang:en **score:36** filesize: 813.55 K page_count: 31 document date: 2022-07-11



[Lenco Xemio-768/MP-208 MP3/MP4 Player User Manual](#)

Official user manual for the Lenco Xemio-768 and MP-208 MP3/MP4 players with Bluetooth. Contains detail
instructions, safety precautions, operational guides, and troubleshooting tips for the portable media device.

lang:en **score:36** filesize: 2.48 M page_count: 149 document date: 2023-01-04




[\[pdf\]](#) User Manual

USER S MANUAL Owner c67ef05ef70aef062ec4c0cfb49eef142a59df5b Xemio 768 manual NL EN DE FR ES cdn maxx nl |||

USER S MANUAL **Xemio-768**/ MP-208 MP3 / MP4 player with Bluetooth For more information: www.lenco.com
Index English

lang:en **score:35** filesize: 5.63 M page_count: 152 document date: 2020-06-17



[\[pdf\]](#) User Manual

USER S MANUAL Owner Bekijk de handleiding Lenco XEMIO 768 Grey MP3 Speler met Bluetooth inclusief 8GB micro SD en sport l original media s q2rAp2n9n1Pk |||

USER S MANUAL **Xemio-768**/ MP-208 MP3 / MP4 player with Bluetooth For more information: www.lenco.com
Index English

lang:en **score:34** filesize: 1.34 M page_count: 152 document date: 2021-03-17



[\[pdf\]](#) User Manual

USER S MANUAL Owner Bekijk de handleiding Lenco XEMIO 768 Lime MP3 Speler met Bluetooth inclusief 8GB micro SD en sport l original media s vjzmxjNqNvv0 |||

USER S MANUAL **Xemio-768**/ MP-208 MP3 / MP4 player with Bluetooth For more information: www.lenco.com
Index English

lang:en **score:34** filesize: 1.34 M page_count: 152 document date: 2021-03-17




[\[pdf\]](#) Guide

M14R mmak Xemio 768 MP 208 QG v2 0 NL EN DE FR ES DK SE Lenco Pink kopen Nu in de Officiële Shop

e9f51ce6ff74d36f06cf80e91e7faa8c33fd5e64 cdn maxx nl |||

Model: **Xemio-768** / MP-208 Quick Guide Korte handleiding Kurzanleitung Guide rapide Gua Rpida Startvej| Snabbguide For information and support, www.lenco.com Zie voor informatie en ondersteuning www.lenco.com
Informationen und Helpdesk:www.lenco.com Pour des informations et une assistance, visi...

lang:en **score:33** filesize: 1 M page_count: 43 document date: 2023-03-14



[pdf] User Manual

USER S MANUAL Owner Bekijk de handleiding Lenco XEMIO 768 Pink MP3 Speler met Bluetooth® inclusief 8GB micro SD en sport original media s q2rAp2gYgX7y |||

USER S MANUAL **Xemio-768** / MP-208 MP3 / MP4 player with Bluetooth For more information: www.lenco.com Index English

lang:en score:33 filesize: 1.34 M page_count: 152 document date: 2021-03-17



[pdf] Guide

M14R mmak 96f6d08e765279738947ecc00884f1b10b8c2f88 Xemio 768 MP 208 QG v2 0 NL EN DE FR ES cdn maxx nl |||
Model: **Xemio-768** / MP-208 Quick Guide Korte handleiding Kurzanleitung Guide rapide Gua Rpida For infor and support, www.lenco.com Zie voor informatie en ondersteuning www.lenco.com Informationen und Helpdesk:www.lenco.com Pour des informations et une assistance, visitez : www.lenco.com Para ms...
lang:en score:30 filesize: 811.53 K page_count: 31 document date: 2023-01-04



[Lenco Xemio-768 / MP-208 Quick Guide - Portable MP3 Player Manual](#)

Concise quick start guide for the Lenco Xemio-768 and MP-208 portable MP3 player. Learn about controls, charging, Bluetooth pairing, menu navigation, and safety information.

lang:en score:27 filesize: 813.56 K page_count: 31 document date: 2022-07-20



[Lenco Xemio-768 / MP-208 MP3 Player Quick Guide](#)

Quick guide for the Lenco Xemio-768 and MP-208 MP3 player, covering controls, connections, charging, Blu and basic operations.

lang:en score:26 filesize: 418.74 K page_count: 31 document date: 2022-07-28



[pdf] Guide

M14R mmak Bekijk de handleiding Lenco XEMIO 768 Pink MP3 Speler met Bluetooth® inclusief 8GB micro SD en sport bol original r q87Z1Rg4M4rR |||

Model: **Xemio-768** / MP-208 Quick Guide Korte handleiding Kurzanleitung Guide rapide Gua Rpida For infor and support, www.lenco.com Zie voor informatie en ondersteuning www.lenco.com Informationen und Helpdesk:www.lenco.com Pour des informations et une assistance, visitez : www.lenco.com Para ms...

lang:en score:26 filesize: 418.74 K page_count: 31 document date: 2022-07-28



[pdf] Guide

M14R mmak Bekijk de handleiding Lenco XEMIO 768 Lime MP3 Speler met Bluetooth® inclusief 8GB micro SD en sport bol original | 9X1gWr2zP33x |||

Model: **Xemio-768** / MP-208 Quick Guide Korte handleiding Kurzanleitung Guide rapide Gua Rpida For infor and support, www.lenco.com Zie voor informatie en ondersteuning www.lenco.com Informationen und Helpdesk:www.lenco.com Pour des informations et une assistance, visitez : www.lenco.com Para ms... lang:en **score:26** filesize: 418.74 K page_count: 31 document date: 2022-07-28



[pdf] Guide

M14R mmak Bekijk de handleiding Lenco XEMIO 768 Grey MP3 Speler met Bluetooth® inclusief 8GB micro SD en sport bol original | AON1pDNKgQpp |||

Model: **Xemio-768** / MP-208 Quick Guide Korte handleiding Kurzanleitung Guide rapide Gua Rpida For infor and support, www.lenco.com Zie voor informatie en ondersteuning www.lenco.com Informationen und Helpdesk:www.lenco.com Pour des informations et une assistance, visitez : www.lenco.com Para ms... lang:en **score:26** filesize: 418.74 K page_count: 31 document date: 2022-07-28



[pdf]

Microsoft Word XEMIO768 ET annika MP3 плеер с bluetooth Lenco Xemio 768 8GB черный зеленый Expert 777c04cf7c51ef3e67f2dfd01eac9517e8aa90d3 89b5ed73ebb443ef442367d42cf4fb7a filename* UTF 8 777c04cf7c51ef3e67f2dfd01e expert ee Attachment DownloadFile Id 4686 |||


Kasutusjuhend **Xemio-768** MP4 mngija Informatsioon ja kasutajatugi: www.lenco.com 1 EESTI KEEL Xemio HOIATUS: Seadme kasutamine teisiti kui juhendis osutatud vib tekitada ohtliku kiirgusega kokkupuutumise c Seadet ei tohi modifitseerida ega remontida keegi peale tootja poolt volitatud remon... lang:et **score:25** filesize: 1.24 M page_count: 17 document date: 2018-10-22



[pdf] Datasheet Accessories

Xemio 768 MP3 MP4 player with Bluetooth® lenco Subject to changes without prior notice MICRO V1 28 03 2018 SD USB SLOT EN Bluetooth V2 1 8 4 5 cm TFT LCD display 12161004511 expert technomarkt de datasheets |||

Xemio-768 MP3/MP4 player with Bluetooth 41.5MM 85MM EN Bluetooth V2.1 1,8 4,5 cm TFT LCD display , formats: MP3, WAV, APE, FLAC Photo formats: JPG, BMP and GIF E-book function supports TXT files Voic recording function Integrated Lithium Polymer rechargeable battery 3.7V, 250mAh ... lang:nl **score:23** filesize: 405.2 K page_count: 1 document date: 2018-03-28



[pdf] User Manual Installation Guide

USER'S MANUAL Owner USER'S MANUAL< b> 2 Install in accordance with the supplied user manual< 3 Keep device away from heat sources such as radiators heaters stoves candles and other heat-generating products or naked flame The apparatus can only be used in moderate climates Extremely cold warm environments should be avoided Working temperature between original media s-bol wkAnyE3kf USER S MANUAL **Xemio-768/ MP-208 MP3 / MP4 player with Bluetooth** For more information: www.lenco.com Index English

lang:en score:22 filesize: 1.34 M page_count: 152 document date: 2021-03-17



[pdf] Borchure Catalog

Catalogi Commaxx Group2025 Lenco the complete collection brochure 2025cdn shopify s files 1 0265 0148 0511 2025 v 173754120 THE COMPLETE COLLECTION 2025 Lenco has been synonymous with Swiss engineering precision in the sfunktion USB-C-Anschluss Spielzeit im Musikmodus max. 18 Stunden 155 Xemio-280BU 8GB MEMORY **X 768** 8GB SD CARD MP3-Player MP3 players MP3 players MP3-Player Xemio-280 Specifications Blu...

lang:de score:16 filesize: 7.29 M page_count: 119 document date: 2025-01-22



[pdf]

UE 2023 indb Publications en ligne SECOMP AG 231 sch consumerelectronics secomp.ch file 1070 cms publikationen online ||| ConsumerElectronics 2023/24 Audio- / Video Anschluss Technik / Multimedia / Foto / Zubehör Ihre indivi ... Spi im Videomodus ca. 3 Stunden Inklusiv: USB-Kabel, Kopfhörer, 8GB SD card Lenco MP4 Player **XEMIO-768**, Lenco MP4 Player **XEMIO-768**, Grau Lenco MP4-Player Bluetooth 4.2* 1,8 4,5 cm TFT...

lang:de score:11 filesize: 67.61 M page_count: 90 document date: 2023-03-22