

[Manuals.plus](#) /

> [Picun](#) /

> Picun Hybrid Active Noise Cancelling Headphones User Manual - Model P26-1

Picun P26-1

Picun Hybrid Active Noise Cancelling Headphones User Manual

MODEL: P26-1

INTRODUCTION

Thank you for choosing Picun Hybrid Active Noise Cancelling Headphones. This manual provides comprehensive instructions for setting up, operating, and maintaining your headphones to ensure optimal performance and longevity. Please read this manual carefully before using the product and retain it for future reference.

SAFETY INFORMATION

- Do not expose the headphones to extreme temperatures, humidity, or corrosive substances.
- Avoid dropping or subjecting the headphones to strong impacts.
- Do not disassemble or attempt to repair the headphones yourself. This will void the warranty.
- Clean the headphones with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- Adjust volume to a moderate level to prevent hearing damage. Prolonged exposure to loud sounds can cause permanent hearing loss.
- Do not use headphones while driving, cycling, or in situations where you need to hear your surroundings.

PACKAGE CONTENTS

Please check the package for the following items:

- Picun Hybrid Active Noise Cancelling Headphones (P26-1)
- USB-C Charging Cable
- 3.5mm Audio Cable
- User Manual (This document)
- Carrying Case (if included with your model)



Familiarize yourself with the various parts and controls of your Picun headphones:

- **Power Button:** Used to power the headphones on/off and initiate Bluetooth pairing.
- **ANC Button:** Toggles Active Noise Cancelling (ANC) and Transparency Mode.
- **Volume Up/Next Track Button:** Increases volume with a short press, skips to next track with a long press.
- **Volume Down/Previous Track Button:** Decreases volume with a short press, skips to previous track with a long press.
- **Multi-function Button (MFB):** Play/Pause, Answer/End calls.
- **USB-C Charging Port:** For charging the headphones.
- **3.5mm Audio Jack:** For wired connection.
- **LED Indicator:** Shows power, charging, and pairing status.
- **Microphones:** For calls and noise cancellation.

SETUP

1. Charging the Headphones

Before first use, fully charge your headphones. Connect the supplied USB-C charging cable to the headphone's USB-C port and the other end to a USB power adapter (not included) or a computer's USB port.

- The LED indicator will show red during charging and turn off when fully charged.
- A full charge takes approximately 2 hours.
- A quick 10-minute charge can provide up to 3 hours of playback.

2. Powering On/Off

- **Power On:** Press and hold the Power Button for 3 seconds until the LED indicator flashes blue and you hear a power-on prompt.
- **Power Off:** Press and hold the Power Button for 3 seconds until the LED indicator flashes red and you hear a power-off prompt.

3. Bluetooth Pairing

To connect your headphones wirelessly:

1. Ensure the headphones are powered off.
2. Press and hold the Power Button for 5 seconds until the LED indicator flashes red and blue alternately, indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for new devices.
4. Select "Picun P26-1" (or similar name) from the list of available devices.
5. Once connected, the LED indicator will flash blue slowly.

The headphones support Bluetooth 5.0 for stable and efficient wireless connectivity.

4. Wired Connection

You can use the headphones with the included 3.5mm audio cable when the battery is low or for devices without Bluetooth. Simply plug one end of the 3.5mm audio cable into the headphone's 3.5mm audio jack and the other end into your audio source.

5. App Control

Download the official Picun App from your device's app store to unlock additional features and customization options, including remaining power display, low latency mode, 16 EQ modes, noise cancelling adjustment, and position tracking.

OPERATING

1. Basic Music Controls

- **Play/Pause:** Short press the Multi-function Button (MFB).
- **Volume Up:** Short press the Volume Up button.
- **Volume Down:** Short press the Volume Down button.
- **Next Track:** Long press the Volume Up button.
- **Previous Track:** Long press the Volume Down button.

2. Active Noise Cancelling (ANC) and Transparency Mode

The headphones feature advanced Hybrid Active Noise Cancelling technology to reduce ambient noise and a Transparency Mode to allow you to hear your surroundings.

- **Toggle Modes:** Short press the ANC Button to cycle between ANC On, Transparency Mode, and ANC Off.
- **ANC On:** Reduces external noise by up to 50 dB, ideal for noisy environments.
- **Transparency Mode:** Amplifies ambient sounds, allowing you to stay aware of your surroundings without removing the headphones.

3. Spatial Audio and Head Tracking

For an immersive audio experience, utilize the Spatial Audio and Head Tracking features via the Picun App.

- **Spatial Audio:** Provides a sense of movement and imminence of sound, creating a movie-like immersive experience. Activate this feature within the Picun App.
- **Head Tracking:** Adapts the surround sound automatically to your head movements, simulating a concert stage experience. This feature is controlled via the Picun App.

4. Call Functions

- **Answer/End Call:** Short press the Multi-function Button (MFB).
- **Reject Call:** Long press the Multi-function Button (MFB).
- **Activate Voice Assistant:** Double press the Multi-function Button (MFB).

MAINTENANCE

1. Cleaning

Regular cleaning helps maintain the headphones' appearance and performance.

- Wipe the earcups and headband with a soft, dry, lint-free cloth.
- Do not use liquid cleaners, sprays, or solvents.
- Ensure no moisture enters the ports or speaker grilles.

2. Storage

When not in use, store your headphones in the provided carrying case to protect them from dust, scratches, and impacts.

Store in a cool, dry place away from direct sunlight.

3. Battery Care

- Avoid fully discharging the battery frequently.
- If storing for a long period, charge the headphones to about 50% every few months to preserve battery health.
- Use only the supplied charging cable or a certified USB-C cable.

TROUBLESHOOTING

If you encounter issues with your headphones, refer to the following common problems and solutions:

Problem	Possible Solution
Headphones do not power on.	Ensure the battery is charged. Connect to a power source and try again.
Cannot pair with Bluetooth device.	◦ Ensure headphones are in pairing mode (LED flashing red/blue). ◦ Make sure Bluetooth is enabled on your device. ◦ Move headphones closer to your device. ◦ Forget "Picun P26-1" from your device's Bluetooth list and try pairing again. ◦ Restart both headphones and your device.
No sound or low volume.	◦ Increase volume on both headphones and your connected device. ◦ Ensure headphones are properly connected (Bluetooth or wired). ◦ If using wired connection, ensure the 3.5mm cable is fully inserted. ◦ Check if the audio source is playing.
ANC is not working effectively.	◦ Ensure ANC mode is activated (not Transparency Mode or Off). ◦ Check if the earcups are properly sealed around your ears. ◦ ANC is most effective for low-frequency sounds.

SPECIFICATIONS

Model Number	P26-1
Connectivity Technology	Wireless (Bluetooth 5.0), Wired (3.5mm Jack)
Battery Life	Up to 80 hours (Note: Feature bullets mention 120 hours, refer to product packaging for exact figures)
Charging Time	Approximately 2 hours
Frequency Range	20Hz - 20kHz
Item Weight	7 ounces (198.45 grams)
Product Dimensions	6.69 x 3.14 x 7.08 inches
Control Method	App, On-ear buttons
Ear Placement	Over Ear

Color	Pink
Manufacturer	Picun
UPC	659516228639

WARRANTY AND SUPPORT

Picun products are designed and manufactured to the highest quality standards. For information regarding warranty coverage, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official Picun website. You can also contact Picun customer service through the contact information provided on their website.

Website: [Visit the Picun Store on Amazon](#)

