

[Manuals.plus](#) /

› [Aigostar](#) /

› Aigostar Electric Kettle Instruction Manual

Aigostar B07D3QFD6B

Aigostar Electric Kettle Instruction Manual

Model: B07D3QFD6B

IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using this appliance and retain for future reference. Improper use may cause electric shock, fire, or serious injury.

- Do not immerse the kettle, power base, or cord in water or other liquids.
- Ensure the appliance is placed on a firm, flat, heat-resistant surface.
- Do not operate the kettle if the cord or plug is damaged, or if the kettle malfunctions or has been damaged in any way.
- Keep the appliance out of reach of children. Close supervision is necessary when any appliance is used by or near children.
- Do not overfill the kettle beyond the MAX 1.7L mark to prevent boiling water from overflowing.
- Do not operate the kettle without water (boil-dry protection is included, but it's best to avoid).
- Always ensure the lid is securely closed before operating.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.

PRODUCT OVERVIEW

The Aigostar Electric Kettle (Model B07D3QFD6B) is a 1500W cordless electric tea and hot water kettle designed for rapid boiling and ease of use. It features high borosilicate glass, LED illumination, and essential safety features like auto shutoff and boil-dry protection. Its 1.7-liter capacity is ideal for serving 3-5 family members, providing hot water in just 5 to 8 minutes.



Figure 1: Aigostar Electric Kettle in operation, showing boiling water and blue LED light.



Figure 2: Product dimensions for the Aigostar Electric Kettle.

COMPONENTS AND FEATURES

- **High Borosilicate Glass:** Durable and healthy food-grade material, allowing clear visual of boiling process.
- **1500W Heating Element:** Ensures rapid boiling of water.
- **LED Illumination:** Blue LED light illuminates when the kettle is boiling.
- **Auto Shutoff:** Automatically turns off once water has boiled.
- **Boil-Dry Protection:** Prevents damage if the kettle is accidentally turned on without water.
- **360° Rotational Base:** Allows for comfortable lifting and placing of the kettle from any angle, suitable for both left and right-handed users.
- **One-Touch Lid:** Lid opens automatically with a short touch for easy filling and cleaning.
- **Built-in Filter:** Located at the kettle mouth, suitable for preparing tea.



Figure 3: The kettle is constructed from food-grade, BPA-free borosilicate glass and stainless steel.



One Touch Lid



LED Indicator



Collectible Cord



Figure 4: Detailed view of the kettle's one-touch lid, LED indicator, and cord storage base.

SETUP AND FIRST USE

Before using your Aigostar Electric Kettle for the first time, follow these steps:

1. Unpack the kettle and its base from the packaging.
2. Wipe the exterior of the kettle with a damp cloth. Do not immerse the kettle or base in water.
3. Fill the kettle with water up to the MAX 1.7L mark.
4. Boil the water. Discard this first boiled water.
5. Repeat the boiling and discarding process 2-3 times to ensure optimal taste and cleanliness.

OPERATING INSTRUCTIONS

Using your Aigostar Electric Kettle is simple and efficient:

1. **Fill the Kettle:** Open the lid using the one-touch button and fill the kettle with the desired amount of water. Ensure the water level is between the MIN (0.5L) and MAX (1.7L) marks. Close the lid securely.
2. **Place on Base:** Place the kettle firmly onto its 360° rotational power base.
3. **Start Boiling:** Plug the power base into a standard 110-120 volt electrical outlet. Press the ON/OFF switch located on the handle downwards. The blue LED light will illuminate, indicating that the kettle is heating.
4. **Auto Shutoff:** The kettle will automatically turn off once the water reaches a rolling boil, and the blue LED light will extinguish.
5. **Pour Water:** Carefully lift the kettle from the base and pour the hot water. The cool-touch handle ensures safe handling.



Figure 5: The kettle's design allows for easy and safe pouring of hot water.



Cool Touch
Handle



Figure 6: The kettle has a maximum capacity of 1.7 liters, suitable for multiple servings.

MAINTENANCE AND CLEANING

Regular cleaning and descaling will prolong the life of your kettle and ensure optimal performance.

1. **Daily Cleaning:** Unplug the kettle and allow it to cool completely. Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
2. **Interior Cleaning:** The smooth glass surface and large opening make the interior easy to clean. You can hand wash the interior with mild soap and water. Rinse thoroughly.
3. **Descaling:** Mineral deposits (limescale) can build up over time, especially in hard water areas. Descale your kettle regularly (e.g., monthly or as needed).
 - Mix 3 tablespoons of vinegar or lemon juice with water.
 - Fill the kettle with this solution and allow it to sit for 5-8 hours, or overnight.

- Boil the solution, then discard it.
- Rinse the kettle thoroughly several times with fresh water to remove any residue or odor.



Figure 7: Visual guide for quick and easy cleaning and descaling of the kettle.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Kettle does not turn on.	Not plugged in; Power switch not pressed; Kettle not properly seated on base.	Ensure plug is firmly in outlet; Press power switch down; Re-seat kettle on base.
Water not boiling.	Kettle not turned on; Insufficient water; Kettle needs descaling.	Press power switch; Ensure water level is above MIN; Descale the kettle.
Kettle turns off too quickly.	Kettle needs descaling; Boil-dry protection activated.	Descal the kettle; Add water and restart (allow to cool if boil-dry was active).
Water has an unusual taste.	First use; Kettle needs cleaning/descaling.	Perform initial boiling cycles; Clean and descale the kettle.

SPECIFICATIONS

Feature	Detail
Brand	Aigostar
Model Name	B07D3QFD6B
Capacity	1.7 Liters
Power	1500W (110-120 Volts)

Feature	Detail
Material	High Borosilicate Glass, Stainless Steel
Special Features	Boil Dry Protection, Automatic Shut-Off, LED Illuminated
Product Dimensions	8.66"L x 7.35"W x 9.84"H
Item Weight	2.87 Pounds
Included Components	Filter

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the documentation included with your purchase or visit the official Aigostar website. You may also contact Aigostar customer service directly for assistance with any questions or concerns regarding your electric kettle.

Official Aigostar Store: [Aigostar Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07D3QFD6B>

More documents and user manuals: <https://manuals.plus/>