

Aigostar 300104LCC

Aigostar Electric Kettle User Manual

Model: 300104LCC | Brand: Aigostar

1. INTRODUCTION

Thank you for choosing the Aigostar Electric Kettle. This manual provides essential information for the safe and efficient operation of your new appliance. Please read it thoroughly before first use and retain it for future reference.

This 1500W glass electric kettle is designed for rapid heating of water, featuring a 1.7-liter capacity, durable borosilicate glass construction, and safety features like automatic shut-off and boil-dry protection. The cordless design and LED indicator enhance user convenience.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and personal injury, do not immerse cord, plugs, or the power base in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or personal injury.

- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off,” then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- The kettle is equipped with an **Automatic Shut-Off** feature that activates once water reaches boiling temperature.
- The **Boil-Dry Protection** feature automatically turns off the kettle if it operates without sufficient water, preventing damage.

Official Aigostar video demonstrating the electric kettle's features, including BPA-free materials, auto shut-off, and boil-dry protection.

3. PRODUCT COMPONENTS

Familiarize yourself with the parts of your Aigostar Electric Kettle:

- **Kettle Body:** Made of durable borosilicate glass with water level markings.
- **Lid:** Features a one-touch opening mechanism for easy filling.
- **Handle:** Ergonomically designed for a non-slip, cool-touch grip.
- **Spout with Filter:** Ensures clean pouring and prevents scale from entering your cup.
- **Power Base:** Provides cordless operation for the kettle body and includes cable storage.
- **LED Indicator:** Illuminates when the kettle is active.



The Aigostar Electric Kettle in operation, showing the transparent glass body and illuminated blue LED light during boiling.



One Touch Lid



LED Indicator



Collectible Cord



Detailed view highlighting the one-touch lid for easy access, the LED indicator light, and the convenient cord storage integrated into the power base.



Image illustrating the cool-touch handle and the filter located in the spout, designed to prevent impurities from being poured.

4. SETUP

1. **Unpack:** Carefully remove all packaging materials and ensure all components (kettle body, power base, user manual) are present.
2. **Initial Cleaning:** Before first use, fill the kettle with water to the MAX line. Add 3 tablespoons of vinegar or lemon juice. Boil the mixture, then let it sit for 5-8 hours or overnight. Discard the water and rinse the kettle thoroughly. Repeat if necessary.
3. **Placement:** Place the power base on a stable, flat, heat-resistant surface. Ensure the power cord is not dangling or in contact with hot surfaces.

5. OPERATING INSTRUCTIONS

1. **Fill the Kettle:** Press the button on the handle to open the lid. Fill the kettle with fresh water,

ensuring it is between the MIN (0.5L) and MAX (1.7L) water level indicators. Do not overfill or underfill.

2. **Place on Base:** Close the lid securely. Place the kettle body onto the power base. The kettle is cordless and can be rotated 360 degrees on the base.
3. **Start Boiling:** Plug the power base into a standard electrical outlet. Flip the ON/OFF switch located on the handle downwards. The blue LED indicator light will illuminate, signaling that the kettle is heating.
4. **Automatic Shut-Off:** The kettle will rapidly heat the water. Once the water reaches boiling point, the kettle will automatically shut off, and the blue LED light will extinguish.
5. **Pouring:** Carefully lift the kettle from its base using the cool-touch handle and pour the hot water.
6. **Re-boiling:** If you need to re-boil water, wait a few moments for the internal thermostat to reset before flipping the switch again.



The kettle demonstrating its rapid heating capability, boiling 1.7 liters of water quickly with 1500W power.



Easy to clean



Easy to add water



Wide opening



Image showing the wide opening of the kettle, making it easy to fill with water and clean.

6. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your kettle.

- **Exterior Cleaning:** Wipe the exterior of the kettle with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
- **Interior Cleaning (Descaling):** Over time, mineral deposits (limescale) may build up inside the kettle, especially in hard water areas. To descale, mix 3 tablespoons of vinegar or lemon juice with water, fill the kettle to the MAX line, boil, and let it sit for 5-8 hours or overnight. Discard the water and rinse thoroughly. Repeat if necessary.
- **Filter Cleaning:** The filter in the spout can be removed for cleaning. Rinse it under running water and gently brush away any deposits. Ensure it is properly reinserted before use.
- **Storage:** When not in use, ensure the kettle is clean and dry. The power cord can be rolled and stored at the bottom of the base.
- **Important:** The kettle body is for hand washing only. Do not immerse the kettle body or power base in water or any other liquid.

7. TROUBLESHOOTING

If you encounter any issues with your Aigostar Electric Kettle, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Kettle does not turn on.	Not plugged in; power switch not engaged; boil-dry protection activated.	Ensure power base is plugged in and switch is flipped down. If boil-dry activated, let kettle cool down before restarting.
Water not boiling.	Insufficient water; lid not closed properly.	Ensure water level is above MIN. Close the lid securely.
Kettle shuts off prematurely.	Boil-dry protection activated; excessive limescale buildup.	Check water level. Perform descaling procedure if limescale is visible.
Unusual taste in water.	First use; mineral deposits.	Perform initial cleaning or descaling procedure. Rinse thoroughly.

8. SPECIFICATIONS

- **Brand:** Aigostar
- **Model Name:** 300104LCC
- **Color:** White
- **Capacity:** 1.7 Liters
- **Power:** 1500W (Note: Product title states 1500W, feature bullets state 1100W. Please refer to product packaging for definitive power rating.)
- **Material:** Borosilicate Glass, Plastic, Stainless Steel
- **Special Features:** Automatic Shut-Off, Boil Dry Protection, LED Indicator, Cordless
- **Product Dimensions:** 8.66"L x 7.36"W x 9.84"H
- **Item Weight:** 2.9 Pounds
- **UPC:** 718356204897
- **Care Instructions:** Hand Wash (kettle body)

FOOD GRADE



• BPA free



• Borosilicate Glass



• Stainless steel



Image emphasizing the kettle's construction from food-grade, BPA-free borosilicate glass and stainless steel for safe water heating.



SAFE AND RELIABLE

· Automatic Switch-off · Dry Boiling Protection

Visual representation of the kettle's safety features, including automatic switch-off and dry boiling protection, ensuring reliable operation.

9. WARRANTY AND SUPPORT

Your Aigostar Electric Kettle comes with a **1-year assurance** from the date of purchase. This warranty covers manufacturing defects under normal household use.

For any questions, concerns, or warranty claims regarding your product, please contact Aigostar customer support. We are committed to providing assistance and ensuring your satisfaction.

Please refer to the contact information provided on the product packaging or visit the official Aigostar website for support details.