

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [KASINGS](#) /

> [KASINGS Replacement Upright Vacuum Belts for Hoover U4387, U4389-9, U4391, U4393, U4393-048, U4395, U4397 - Instruction Manual](#)

KASINGS Replacement Vacuum Belts

KASINGS Replacement Upright Vacuum Belts

Instruction Manual for Hoover Models U4387, U4389-9, U4391, U4393, U4393-048, U4395, U4397

1. INTRODUCTION

Thank you for choosing KASINGS Replacement Upright Vacuum Belts. These belts are designed to provide reliable performance for your compatible Hoover upright vacuum cleaner models, ensuring efficient operation and proper brush roll function. This manual provides essential information for the safe and correct installation and maintenance of your new vacuum belts.

2. SAFETY INFORMATION

Always observe basic safety precautions when performing maintenance on electrical appliances. Failure to do so may result in electric shock, fire, or serious injury.

- **Disconnect Power:** Always unplug the vacuum cleaner from the electrical outlet before attempting any maintenance, cleaning, or belt replacement.
- **Allow Cooling:** If the vacuum has been recently used, allow it to cool down before handling internal components.
- **Use Correct Parts:** Only use replacement parts specifically designed for your vacuum cleaner model.
- **Keep Hands Clear:** Keep hands, hair, and loose clothing away from moving parts, especially the brush roll, when the vacuum is plugged in.
- **Proper Disposal:** Dispose of old belts responsibly according to local regulations.

3. PACKAGE CONTENTS

Your package should contain the following items:

- 2 x KASINGS Upright Vacuum Belts (Replacement for Hoover models U4387, U4389-9, U4391, U4393, U4393-048, U4395, U4397)

4. INSTALLATION INSTRUCTIONS

Follow these steps to replace the drive belt on your Hoover upright vacuum cleaner. Specific steps may vary

slightly depending on your exact model, but the general procedure remains consistent.

4.1. Preparation

1. **Unplug the Vacuum:** Ensure the vacuum cleaner is completely unplugged from the wall outlet before proceeding.
2. **Clear Work Area:** Lay the vacuum cleaner on its side or back on a clean, flat surface to access the brush roll area.

4.2. Accessing the Belt and Brush Roll

3. **Remove Base Plate:** Locate the screws holding the bottom plate (also known as the sole plate or brush roll cover) in place. Use a screwdriver to remove these screws and carefully lift off the plate. Set the screws aside in a safe place.
4. **Remove Brush Roll:** Gently lift out the brush roll. The old belt will likely be stretched, broken, or still attached to the brush roll or motor shaft.

4.3. Removing the Old Belt

5. **Detach Old Belt:** Carefully remove the old belt from both the motor shaft and the brush roll. If the belt is broken, remove any remaining pieces.
6. **Clean Area:** Take this opportunity to clean any hair, debris, or dust that may have accumulated around the brush roll and belt area. This helps prevent future issues.

4.4. Installing the New Belt



Image: KASINGS Replacement Upright Vacuum Belts. This image shows two new replacement belts ready for installation.

7. **Position New Belt:** Take one of the new KASINGS replacement belts. Loop it around the motor shaft (the small metal or plastic spindle that protrudes from the vacuum body).
8. **Attach to Brush Roll:** Place the brush roll back into its housing. While doing so, stretch the new belt around the brush roll, ensuring it sits securely in the groove designed for the belt. The belt should be taut but not overly strained.
9. **Verify Placement:** Rotate the brush roll manually a few times to ensure the belt is properly seated and

moves freely without rubbing against other components.

4.5. Reassembly

10. **Replace Base Plate:** Carefully position the bottom plate back onto the vacuum cleaner, aligning it with the screw holes.
11. **Secure Screws:** Reinsert and tighten all screws removed in step 3. Do not overtighten.
12. **Test Vacuum:** Plug the vacuum cleaner back into the electrical outlet and turn it on briefly to ensure the brush roll spins correctly and the vacuum operates as expected.

5. MAINTENANCE

Regular maintenance of your vacuum belt can extend its lifespan and ensure optimal cleaning performance.

- **Regular Inspection:** Periodically inspect the belt for signs of wear, cracking, stretching, or fraying. Replace the belt if any damage is observed.
- **Clean Brush Roll:** Frequently remove hair, strings, and debris from the brush roll. Excessive build-up can put strain on the belt and motor.
- **Avoid Obstructions:** Be careful not to vacuum up large objects or thick carpets that could jam the brush roll, causing the belt to break or stretch prematurely.
- **Storage:** Store spare belts in a cool, dry place away from direct sunlight and extreme temperatures to preserve their elasticity.

6. TROUBLESHOOTING

If you encounter issues after replacing your vacuum belt, consider the following common problems and solutions:

Problem	Possible Cause	Solution
Brush roll not spinning	Belt not installed correctly, belt broken, brush roll jammed.	Unplug vacuum. Recheck belt installation. Clear any obstructions from brush roll. Replace belt if broken.
Vacuum not picking up effectively	Worn or stretched belt, brush roll not spinning at optimal speed.	Inspect belt for wear; replace if stretched or damaged. Ensure brush roll is clean and free of debris.
Burning smell	Belt slipping or overheating due to friction, brush roll jammed.	Immediately unplug vacuum. Check for brush roll obstructions. Ensure belt is correctly seated and not rubbing. Allow motor to cool.

7. SPECIFICATIONS

- **Brand:** KASINGS
- **Compatible Devices:** Hoover Upright Vacuum Cleaners (Models: U4387, U4389-9, U4391, U4393, U4393-048, U4395, U4397)
- **Item Weight (per package):** Approximately 8 ounces
- **Material:** Durable Rubber

8. WARRANTY AND SUPPORT

For any questions regarding the KASINGS Replacement Upright Vacuum Belts, or for warranty information, please contact the seller or manufacturer directly through your purchase platform. Keep your purchase receipt as proof of purchase.