#### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- Amazon Basics /
- > Amazon Basics Compact Bagless Cylinder Vacuum Cleaner with HEPA Filter, 700W, 2.0L User Manual

#### Amazon Basics VCS35A17K0A

# **Amazon Basics Compact Bagless Cylinder Vacuum Cleaner**

Model: VCS35A17K0A

#### 1. IMPORTANT SAFETY INSTRUCTIONS

Please read these instructions carefully before using the appliance. Keep this user manual for future reference.

- This appliance is for household use only. Do not use outdoors or on wet surfaces.
- Do not allow children to operate the vacuum cleaner. Close supervision is necessary when used near children.
- Always unplug the vacuum cleaner from the electrical outlet before cleaning or performing maintenance.
- Do not pick up flammable or combustible materials, hot ashes, or large, sharp objects.
- Do not use without the dust container and filters properly installed.
- Inspect the power cord and plug for damage before each use. Do not use if damaged.
- Do not pull or carry by the cord, use the cord as a handle, close a door on the cord, or pull the cord around sharp edges or corners. Keep cord away from heated surfaces.

#### 2. PRODUCT OVERVIEW

The Amazon Basics Compact Bagless Cylinder Vacuum Cleaner is designed for efficient cleaning of various surfaces, including hard floors and carpets. It features a powerful motor and a multi-stage filtration system.

#### **Key Features:**

- Powerful 700W motor for strong suction.
- Bagless design with a 2.0L dust container for easy emptying.
- Washable HEPA 12 filter captures over 99.5% of particles.
- · Adjustable suction power for different surfaces.

- Compact and lightweight design for easy maneuverability and storage.
- 8-meter operating radius with a 6-meter power cable.
- Low noise level of 72 dBA.

### **Components:**

Familiarize yourself with the parts of your vacuum cleaner:



Figure 2.1: Assembled Vacuum Cleaner

1. Main Unit (Motor Housing, Dust Container)

- 2. Flexible Hose
- 3. Telescopic Tube
- 4. Floor Head
- 5. Power Cord



Figure 2.2: Included Accessories

- 1. Crevice Tool: For narrow spaces and corners.
- 2. Upholstery Tool: For furniture and fabrics.
- 3. Dusting Brush: For delicate surfaces and curtains.

#### 3. ASSEMBLY AND INITIAL SETUP

Follow these steps to assemble your vacuum cleaner before first use:

- 1. **Attach the Flexible Hose:** Insert the end of the flexible hose into the suction inlet on the main unit until it clicks securely into place.
- Connect the Telescopic Tube: Push the wider end of the telescopic tube onto the handle of the flexible hose. Adjust the length of the telescopic tube by pressing the release button and extending or retracting it.
- 3. **Attach the Floor Head:** Push the floor head onto the narrow end of the telescopic tube until it is firmly attached.
- 4. **Install Accessories:** The crevice tool, upholstery tool, and dusting brush can be attached directly to the handle of the flexible hose or the end of the telescopic tube as needed.

#### 4. OPERATING THE VACUUM CLEANER

#### 4.1 Powering On/Off

- 1. Plug In: Extend the power cord and plug it into a suitable electrical outlet.
- 2. Power On: Press the On/Off foot pedal located on the main unit.
- 3. Power Off: Press the On/Off foot pedal again to turn off the vacuum cleaner.
- 4. **Retract Cord:** Press the cord rewind foot pedal to automatically retract the power cord. Guide the cord to prevent whipping.

#### 4.2 Adjusting Suction Power

The vacuum cleaner features an adjustable suction power control to suit different cleaning tasks and surfaces.



Figure 4.1: Suction Power Control Dial

- Rotate the dial on the main unit to increase or decrease suction power.
- Use **Min** setting for delicate surfaces like curtains or light rugs.
- Use **Max** setting for hard floors and heavily soiled carpets.

#### 4.3 Using Attachments

Select the appropriate attachment for your cleaning needs:

- **Floor Head:** Use for general cleaning of hard floors and carpets. Some floor heads have a switch to adjust for different floor types.
- Crevice Tool: Ideal for cleaning tight corners, edges, and between cushions.

- **Upholstery Tool:** Effective for cleaning sofas, chairs, and other fabric surfaces.
- Dusting Brush: Suitable for dusting shelves, blinds, and other delicate items.

## 5. Maintenance and Cleaning

Regular maintenance ensures optimal performance and extends the life of your vacuum cleaner.

#### **5.1 Emptying the Dust Container**

Empty the dust container when the 'MAX FILL' line is reached or when suction power decreases.



Figure 5.1: Dust Container with Max Fill Indicator

- 1. **Unplug:** Ensure the vacuum cleaner is unplugged from the power outlet.
- 2. **Remove Container:** Press the release button on the dust container and lift it away from the main unit.
- 3. **Empty:** Position the container over a waste bin and press the bottom release button to open the lid and empty the contents.

4. **Reattach:** Close the bottom lid securely and reattach the dust container to the main unit until it clicks into place.

#### 5.2 Cleaning the Filters

The vacuum cleaner is equipped with a washable HEPA 12 filter and a motor protection filter. Regular cleaning is crucial for maintaining suction power and air quality.



Figure 5.2: Filter Maintenance Reminder

- 1. **Unplug:** Always unplug the vacuum cleaner before accessing filters.
- 2. **Access Filters:** Remove the dust container. The HEPA filter is typically located inside the dust container or at the top. The motor protection filter is usually located between the dust container and the motor.
- 3. **Clean Filters:** Tap the filters gently over a waste bin to remove loose dust. For thorough cleaning, rinse the filters under cold running water. Do not use detergents.
- 4. **Dry Filters:** Allow filters to air dry completely for at least 24 hours before reinserting them. Do not use a hairdryer or other heating devices.
- 5. **Reassemble:** Once completely dry, reinsert the filters and reattach the dust container.

Note: Failure to clean filters regularly may result in reduced suction power and damage to the motor.

#### 6. TROUBLESHOOTING

If you encounter issues with your vacuum cleaner, refer to the following table:

Problem	Possible Cause	Solution
Vacuum cleaner does not turn on.	No power supply.	Check if the plug is securely inserted into the outlet. Check the circuit breaker.
Low suction power.	Dust container is full. Clogged filters. Blockage in hose or attachments.	Empty the dust container. Clean or replace filters. Check hose and attachments for blockages and remove them.
Unusual noise.	Blockage in the brush roll or hose. Motor issue.	Turn off and unplug the vacuum. Check for and remove any blockages. If noise persists, contact customer support.
Overheating.	Clogged filters or dust container. Blockage.	Turn off and unplug. Empty dust container and clean filters. Remove any blockages. Allow to cool down for 30 minutes before restarting.

# 7. TECHNICAL SPECIFICATIONS

Feature	Specification
Brand	Amazon Basics
Model Number	VCS35A17K0A
Color	Black/Blue
Product Dimensions (L x W x H)	36.32 x 24.71 x 30.02 cm (14.3 x 9.7 x 11.8 inches)
Weight	3.6 kg (7.94 lbs)
Capacity	2 Liters
Power	700 Watts (Note: JSON lists 240 Watts, but product title and features indicate 700W. Using 700W as per title/features for consistency.)
Voltage	240 Volts
Energy Class	A
Noise Level	72 Decibels
Special Feature	Bagless
Filter Type	Cartridge (HEPA 12)
Surface Recommendation	Carpet, Hard Floors
Power Source	Corded Electric

Feature	Specification
Cord Length	6 meters

#### 8. WARRANTY AND SUPPORT

#### **8.1 Return Policy**

This product is subject to Amazon's standard return policy. For details, please refer to the Amazon website where the product was purchased. Typically, returns are accepted within 31 days for refund or replacement.

#### 8.2 Spare Parts Availability

According to product information, spare parts for this model may not be readily available. It is recommended to contact Amazon customer support for any inquiries regarding replacement parts or service.

#### **8.3 Customer Support**

For further assistance, troubleshooting, or warranty claims, please contact Amazon customer support through your purchase history on the Amazon website.

© 2024 Amazon Basics. All rights reserved.

#### Related Documents - VCS35A17K0A



#### Amazon Basics Cylinder Bagless Vacuum Cleaner User Manual

Discover how to use and maintain your Amazon Basics Cylinder Bagless Vacuum Cleaner with this comprehensive user manual. It covers safety guidelines, operational procedures, cleaning tips, specifications, and troubleshooting for model VCS35B15KC.







#### Amazon Basics Cylinder Bagless Vacuum Cleaner 2.5 L 700 W User Manual

User manual for the Amazon Basics Cylinder Bagless Vacuum Cleaner (2.5 L, 700 W). Covers assembly, operation, cleaning, maintenance, and troubleshooting. Includes model numbers B071VNC8M4, B072FBY7L4, B07C41FMF1 and safety information.



#### Amazon Basics Cylinder Bagless Vacuum Cleaner User Manual VCM43A16H

Comprehensive user manual for the Amazon Basics Cylinder Bagless Vacuum Cleaner (Model VCM43A16H). Includes setup, operation, cleaning, maintenance, safety instructions, and specifications for household use.



#### Amazon Basics Upright Bagless Lightweight Vacuum Cleaner User Manual

Comprehensive user manual for the Amazon Basics Upright Bagless Lightweight Vacuum Cleaner (Model VUS29AE1B). Provides detailed instructions on safety, operation, assembly, cleaning, maintenance, and troubleshooting. Includes specifications and contact information for support.



#### Amazon Basics VCB46A15F Cyclonic Bagged Cylinder Vacuum Cleaner User Manual

Comprehensive user manual for the Amazon Basics VCB46A15F cyclonic bagged cylinder vacuum cleaner, covering safety instructions, product description, operation, cleaning, maintenance, troubleshooting, and specifications.



#### Amazon Basics Air Purifier User Manual

Comprehensive user manual for the Amazon Basics Air Purifier, covering setup, operation, cleaning, maintenance, troubleshooting, and specifications. Learn how to effectively use and care for your air purifier.