

[Manuals.plus](#) /

› [Bissell](#) /

› Bissell SpotClean Pet Pro Portable Carpet Cleaner User Manual

Bissell 2458

Bissell SpotClean Pet Pro Portable Carpet Cleaner

Model: 2458

INTRODUCTION

The Bissell SpotClean Pet Pro is a compact and powerful portable carpet cleaner designed for effective removal of tough spots and pet stains from various surfaces. Its combination of strong suction, specialized tools, and cleaning solution provides thorough cleaning results for carpets, upholstery, stairs, and area rugs.



Our Most Powerful Portable Carpet Cleaner

Image: The Bissell SpotClean Pet Pro Portable Carpet Cleaner, showcasing its compact design and attached hose with cleaning tool. This unit is designed for powerful spot cleaning.

SAFETY INFORMATION

Always follow basic precautions, including the following:

- Read all instructions before using your portable spot cleaner.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not immerse. Use only on surfaces moistened by the cleaning process.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only cleaning products formulated for this appliance to prevent internal component damage.

PACKAGE CONTENTS

Verify that all items are included in your package:

- Bissell SpotClean Pet Pro Unit
- Stain Trapper Tool
- 3-inch Tough Stain Tool
- Trial-size Bissell Professional Pet Urine Eliminator + Oxy formula



Image: The complete package of the Bissell SpotClean Pet Pro, showing the main unit, two specialized cleaning tools, and a bottle of cleaning solution.

SETUP

1. **Fill the Clean Water/Formula Tank:** Remove the tank from the unit. Unscrew the cap and fill the tank with warm tap water to the 'Water' fill line. Add Bissell cleaning formula to the 'Formula' fill line. Replace

the cap and secure it tightly.

2. **Attach the Cleaning Tool:** Connect the desired cleaning tool (Stain Trapper Tool or 3-inch Tough Stain Tool) to the end of the flexible hose until it clicks securely into place.
3. **Unwind the Power Cord:** Fully unwind the 22-foot power cord from the cord wrap.



Extra-large Capacity

96 oz. clean tank

Image: The SpotClean Pet Pro with its large capacity clean water tank, demonstrating how it can be easily filled for extended cleaning sessions.

OPERATING INSTRUCTIONS

1. **Power On:** Plug the unit into a grounded outlet. Press the red power button located on the top of the unit to turn it on.
2. **Pre-treat (Optional):** For heavily soiled areas, pre-treat the stain by holding the cleaning tool about 1 inch above the surface and pressing the spray trigger to apply cleaning solution. Allow the solution to sit for 3-5 minutes before proceeding.
3. **Spray and Scrub:** Hold the cleaning tool firmly against the surface. Press the spray trigger to apply

solution while slowly pulling the tool over the stain. Release the trigger and slowly pull the tool over the same area to suction up the dirty solution. Repeat until the stain is removed.

4. **Rinse (Optional):** For best results, fill the clean water tank with only warm water (no formula) and repeat step 3 to rinse the cleaned area.



Unbeatable Stain Removal¹

For professional-style results

Image: The SpotClean Pet Pro in action, demonstrating its effectiveness in removing stains from carpeted stairs using the specialized cleaning tool.

MAINTENANCE

1. **Empty and Rinse Dirty Water Tank:** After each use, remove the dirty water tank. Unlatch the lid and pour out the dirty water. Rinse the tank thoroughly with clean water.
2. **Clean Tools:** Rinse the cleaning tools under running water to remove any debris or residue.
3. **Wipe Down Unit:** Wipe the exterior of the unit with a soft, damp cloth.
4. **Store:** Wrap the power cord and hose around the designated wraps on the unit. Store the unit and tools in a cool, dry area.



Triple Action Formula

Removes stains, eliminates odors, and prevents future stains with StainProtect® Technology

Image: A bottle of Bissell Pet Pro cleaning formula, highlighting its triple action formula designed to remove stains, eliminate odors, and prevent future stains.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Reduced Spray	Clean water tank empty or not seated properly.	Refill tank or re-seat firmly.
No Suction	Dirty water tank full or not seated properly.	Empty tank or re-seat firmly. Check for clogs in hose/nozzle.
Unit Not Turning On	Power cord not plugged in or circuit breaker tripped.	Ensure unit is plugged in. Check circuit breaker.

SPECIFICATIONS

- **Brand:** Bissell
- **Model:** 2458
- **Color:** Black
- **Item Weight:** 13.2 Pounds
- **Product Dimensions:** 14"D x 10"W x 14"H
- **Clean Tank Capacity:** 96 oz (3/4 Gallon)
- **Power Source:** Corded Electric
- **Hose Length:** 4 feet
- **Power Cord Length:** 22 feet

WARRANTY AND SUPPORT

The Bissell SpotClean Pet Pro (Model 2458) comes with a **Limited 2-Year Warranty**. This warranty covers defects in materials and workmanship from the date of original purchase.

For warranty claims, technical support, or to order replacement parts, please visit the official Bissell website or contact their customer service. Keep your purchase receipt as proof of purchase.