

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [LEGO](#) /

› LEGO Harry Potter Hogwarts Express 75955 Toy Train Building Set Instruction Manual

## LEGO 75955

# LEGO Harry Potter Hogwarts Express 75955 Toy Train Building Set Instruction Manual

## INTRODUCTION

This instruction manual provides detailed guidance for assembling and understanding the features of your LEGO Harry Potter Hogwarts Express 75955 Toy Train Building Set. This set allows you to recreate iconic scenes from the Harry Potter series, featuring the Hogwarts Express train, a section of King's Cross Station's Platform 9¾, and several minifigures.

## SETUP AND ASSEMBLY

The LEGO Harry Potter Hogwarts Express 75955 set contains 801 pieces and is recommended for ages 8-14. Follow the step-by-step instructions provided in the included building guide to construct the model. Ensure all pieces are accounted for before beginning assembly. Organize pieces by bag number as indicated in the instructions for a smoother building experience.

Key components to assemble include:

- The Hogwarts Express locomotive.
- A passenger carriage with removable side panel and roof.
- A section of the railway bridge with a clock.
- Platform 9¾ with a moving brick wall entrance.

Carefully connect each brick as shown in the manual. If any pieces are missing or damaged, please refer to the 'Troubleshooting' section for assistance.

## PRODUCT FEATURES AND DETAILS

This set is designed with intricate details to enhance the building and play experience:

- **Hogwarts Express Train:** The train features a detailed locomotive and a passenger carriage. The carriage includes four seats and a removable side panel and roof for easy access to the interior.
- **King's Cross Station:** The station model includes a railway bridge with a clock, steps leading to Platform 9¾, a moving brick wall entrance, a 'Wanted' poster, and Daily Prophet newspapers.

- **Minifigures:** The set comes with several minifigures, including Harry Potter, Ron Weasley, Hermione Granger, Remus Lupin, and the Trolley Witch, along with Dementor and Scabbers figures.
- **Interactive Elements:** Recreate scenes by ordering candy from the Trolley Witch or flying the Dementor into the carriage.

## MEDIA GALLERY

### Product Images



The complete LEGO Harry Potter Hogwarts Express 75955 set, showcasing the train, King's Cross station platform, and included minifigures, alongside the product packaging.



A detailed view of the assembled Hogwarts Express train, the King's Cross station platform, and the various minifigures included in the set, ready for play.



A child engaging with the LEGO Hogwarts Express set, demonstrating the interactive play possibilities with the train and station elements.



A close-up shot highlighting the intricate details of the Hogwarts Express locomotive and the King's Cross station platform, including the archways and signage.



The rear view of the LEGO Hogwarts Express 75955 product box, illustrating key features such as the removable carriage roof and interior details.

## Official Product Videos

Your browser does not support the video tag.

This video provides a brief overview of the LEGO Harry Potter Hogwarts Express 75955 Toy Train Building Set, showcasing its main components and features.

## SPECIFICATIONS

<b>Product Dimensions</b>	21.26 x 11.1 x 3.09 inches
<b>Item Weight</b>	2.91 pounds
<b>ASIN</b>	B07D493RWR
<b>Item Model Number</b>	6212646
<b>Manufacturer Recommended Age</b>	8 - 14 years
<b>Release Date</b>	August 1, 2018
<b>Manufacturer</b>	LEGO

## SAFETY INFORMATION

No specific safety warnings are provided beyond the manufacturer's recommended age range of 8-14 years. As with all small building toys, supervise younger children to prevent choking hazards. Keep small pieces away from infants and toddlers.

## MAINTENANCE

---

To ensure the longevity of your LEGO set, follow these maintenance guidelines:

- **Cleaning:** Clean LEGO bricks with mild soap and water. Avoid harsh chemicals or abrasive materials. Rinse thoroughly and air dry.
- **Storage:** Store the assembled model or individual bricks in a cool, dry place away from direct sunlight to prevent discoloration and warping.
- **Handling:** Handle the assembled model with care, especially delicate parts of the station or train, to prevent accidental disassembly.

## TROUBLESHOOTING

---

If you encounter any issues with your LEGO Harry Potter Hogwarts Express set, consider the following:

- **Missing Pieces:** If you find any pieces missing from your new set, please contact LEGO Customer Service directly. They typically provide replacement parts.
- **Assembly Difficulties:** Double-check the instruction manual for the specific step you are on. Ensure all bricks are oriented correctly and firmly pressed together.
- **Loose Connections:** Some connections may become loose over time with play. Re-attach any loose bricks firmly.

## WARRANTY AND SUPPORT

---

LEGO products are manufactured to high-quality standards. For information regarding product warranty, replacement parts, or further support, please visit the official LEGO website or contact their customer service department. Keep your proof of purchase for any warranty claims.