

Seville Classics SHE16218WB

Seville Classics 10-Drawer Rolling Utility Organizer Storage Cart

Model: SHE16218WB - Frost White

INTRODUCTION

Thank you for choosing the Seville Classics 10-Drawer Rolling Utility Organizer Storage Cart. This manual provides essential information for the safe assembly, operation, and maintenance of your new storage cart. Please read all instructions carefully before use and retain this manual for future reference.

SAFETY INFORMATION

- Use caution when moving the cart on uneven surfaces to prevent tipping.
- Ensure drawers are properly secured before removal or when moving the cart.
- Keep the cart away from potential hazards in garages or other workspaces.
- Do not allow children to play on, with, or around the cart.
- Do not overload drawers or the top shelf. Each drawer can hold up to 3.3 lbs (1.5 kg), and the top shelf can withstand up to 16.5 lbs (7.5 kg).

PACKAGE CONTENTS

Please verify that all components are present before beginning assembly:

- 1 x Perforated Steel Top Shelf
- 10 x Polypropylene Drawers (Frost White)
- 10 x Chrome Drawer Pull Knobs
- 2 x Steel Side Frames
- 4 x Poles
- 4 x Casters (2 locking)
- Assembly Hardware (screws, wrench)

SPECIFICATIONS

Feature	Detail
Model Number	SHE16218WB
Color	Frost White
Material	Alloy Steel, Metal, Polypropylene
Frame Material	Metal (Chrome Finish)
Product Dimensions (D x W x H)	15.3" x 12.8" x 38.2" (38.8 cm x 32.5 cm x 97 cm)
Inner Drawer Dimensions (L x W x H)	13.63" x 9.5" x 2.5"
Item Weight	11.8 lbs (5.35 kg)
Number of Drawers	10
Drawer Weight Capacity	3.3 lbs (1.5 kg) per drawer
Top Shelf Weight Capacity	16.5 lbs (7.5 kg)

Note: All dimensions are approximate and may vary slightly.



Figure 1: Product Dimensions

ASSEMBLY INSTRUCTIONS

Assembly is required. Please follow these steps carefully. No additional tools are typically required beyond what is provided.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Verify all parts listed in the "Package Contents" section are present.
2. **Attach Casters:** Insert the four casters into the holes at the bottom of the two steel side frames. Two of the casters have locking mechanisms. Ensure they are securely fitted.
3. **Connect Side Frames with Poles:** Attach the four horizontal poles between the two steel side frames. Use the provided screws and wrench to tighten them securely. Ensure the frame is stable and upright.
4. **Install Top Shelf:** Place the perforated steel top shelf onto the designated area at the top of the assembled frame. It should rest securely on the top horizontal bars.

5. **Insert Drawers:** Slide each of the 10 polypropylene drawers into the metal channels on the side frames.
6. **Attach Drawer Knobs:** Screw the chrome drawer pull knobs into the pre-drilled holes on the front of each drawer. Tighten them by hand until snug.





Figure 2: Assembled Cart Overview



Figure 3: Locking Caster Detail

- **Using the Drawers:** The 10 polypropylene drawers are designed to slide in and out smoothly. They are removable, allowing you to re-order them or carry contents to a different location as needed. To remove a drawer, simply pull it out until it detaches from the frame. To reinsert, align it with the channels and push it back in.
- **Moving the Cart:** The cart is equipped with four casters for easy mobility. To move the cart, ensure the two locking casters are disengaged. Push or pull the cart using the tall handles on the top frame.
- **Securing the Cart:** To keep the cart stationary, engage the locking mechanisms on the two locking casters. This will prevent unintended movement.
- **Using the Top Shelf:** The perforated steel top shelf provides additional storage or a stable surface for items up to 16.5 lbs.



Figure 4: Drawer Functionality

MAINTENANCE

- **Cleaning the Drawers:** The polypropylene drawers are easy to clean. Use mild soap and a damp cloth to wipe them down. Wipe away any excess water and allow them to air dry completely before reinserting.
- **Cleaning the Frame:** The industrial-strength tubular steel frame with chrome finish can be wiped clean with a soft, damp cloth. Avoid abrasive cleaners that may damage the finish.
- **Regular Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary to maintain stability.

TROUBLESHOOTING

Issue: Cart feels wobbly or unstable.

Solution: Check all frame connections and ensure screws are tightened securely. Verify that the casters are fully inserted into the frame. Ensure the cart is on a flat, even surface.

Issue: Drawers are difficult to slide or get stuck.

Solution: Ensure the drawers are correctly aligned within their metal channels. Avoid overloading drawers beyond their 3.3 lbs capacity. Check for any debris in the channels that might obstruct movement. If plastic shavings appear, gently clean the channels and drawer edges.

Issue: Drawer pull knobs become loose.

Solution: Simply re-tighten the knobs by hand until they are snug. Avoid over-tightening.

Issue: Cart moves unintentionally.

Solution: Ensure the locking mechanisms on the two designated casters are fully engaged to prevent movement.

WARRANTY INFORMATION

The Seville Classics 10-Drawer Rolling Utility Organizer Storage Cart is backed by a **Limited 1-Year Manufacturer's Warranty**. This warranty covers original defects in material or workmanship under normal home or office use for the duration of the warranty period. Please retain your proof of purchase for warranty claims.

CUSTOMER SUPPORT

For further assistance, missing parts, or warranty inquiries, please contact Seville Classics customer support. Refer to the

product packaging or the official Seville Classics website for the most current contact information.

Website: www.sevilleclassics.com

© 2026 Seville Classics. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07D4L6JHL>

More documents and user manuals: **<https://manuals.plus/>**