

[Manuals.plus](#) /

› [Dilwe](#) /

› Electronic Wristwatch User Manual

Dilwe YX001

Dilwe Electronic Wristwatch User Manual

Model: YX001

1. INTRODUCTION

Thank you for choosing the Dilwe Electronic Wristwatch, Model YX001. This manual provides detailed instructions for setting up, operating, and maintaining your new watch. Designed with a durable stainless steel frame and bracelet, LED backlight, and multiple functions, this watch is perfect for daily wear and various activities.

- Durable stainless steel construction for wear and corrosion resistance.
- LED backlight for clear visibility in low light conditions.
- Functions: 12/24 hour display, date, day of the week, alarm, and chronograph.
- 30-meter water resistance for daily use.



Figure 1: Dilwe Electronic Wristwatch (Silver model).

2. SETUP

2.1 Watch Components and Buttons

Familiarize yourself with the watch's buttons and display elements:



Figure 2: Watch button functions and display indicators. The 'Light' button activates the backlight. The 'Mode' button cycles through different modes (Time, Alarm, Chronograph). The right-side buttons are used for setting adjustments.

- **Light Button:** Activates the LED backlight.
- **Mode Button:** Cycles through Time, Alarm, and Chronograph modes.
- **Right-Side Buttons:** Used for setting adjustments (e.g., changing hour, minute, date, etc.) and converting between 12/24 hour systems.

2.2 Setting Time and Date

1. Press the **Mode** button repeatedly until the time display starts flashing, indicating it's in setting mode.
2. Use the right-side buttons to adjust the flashing digit (e.g., hour, minute, seconds). One button typically increments, the other moves to the next setting field.
3. Continue pressing the **Mode** button to cycle through setting the hour, minute, PM/AM (if in 12-hour mode), month, date, and day of the week.
4. Once all settings are correct, press the **Mode** button again to exit setting mode.

2.3 Adjusting the Bracelet

The stainless steel bracelet is adjustable to fit various wrist sizes. If the bracelet is too loose, you may need to remove links. It is recommended to have this done by a professional jeweler to avoid damaging the watch or bracelet. The clasp is designed for easy use and secure fastening.



Figure 3: Detail of the stainless steel bracelet and clasp mechanism.

3. OPERATING INSTRUCTIONS

3.1 Time Display and Backlight

In normal time mode, the watch displays the current time, day of the week, and date. To illuminate the display in dark conditions:

- Press the **Light** button (typically located on the upper left side of the watch).
- The LED backlight will illuminate the display for a few seconds, allowing you to read the time comfortably.



Using high quality EL light-emitting film, you can clearly see the time by pressing the backlight button at night.

Figure 4: Left shows the normal display, right shows the display with the backlight activated for night viewing.

3.2 Alarm Function

To set and use the alarm:

1. Press the **Mode** button until "ALARM" or an alarm icon appears on the display.
2. While in alarm mode, use the right-side buttons to set the desired alarm time (hour and minute).
3. Press the **Mode** button to confirm the alarm time.
4. To turn the alarm on or off, press one of the right-side buttons while in alarm mode. An indicator (e.g., "ON" or a bell icon) will show if the alarm is active.

3.3 Chronograph (Stopwatch) Function

To use the stopwatch:

1. Press the **Mode** button until "CHRONO" or "STOPWATCH" appears on the display.
2. Use the right-side buttons to start, stop, and reset the chronograph. Typically, one button starts/stops, and another resets.

4. MAINTENANCE

4.1 Water Resistance

Your Dilwe Electronic Wristwatch is water-resistant up to 30 meters (3 ATM). This means it is suitable for daily use, such as hand washing, face washing, and light rain. It is **not** suitable for showering, bathing, swimming, diving, or any activities involving prolonged water immersion or high-pressure water exposure.



Stainless steel clasp, easy to use, not easy to fall off, simple and stylish.

Figure 5: The watch is designed for 30-meter water resistance, suitable for daily splashes.

Important: Do not operate any buttons while the watch is wet or submerged, as this can compromise the water resistance seal.

4.2 Cleaning and Care

- Wipe the watch regularly with a soft, dry cloth to remove dust and smudges.
- For the stainless steel bracelet, a slightly damp cloth can be used, followed by immediate drying.
- Avoid using chemical cleaners, solvents, or abrasive materials, as these can damage the watch's finish.
- Store the watch in a cool, dry place away from direct sunlight and extreme temperatures.

4.3 Battery Replacement

The watch uses an electronic movement with an IC chip for precise timekeeping and long battery life. When the display becomes dim or functions become erratic, it may be time to replace the battery. Battery replacement should ideally be performed by a qualified watch technician to ensure the water resistance seal is maintained.

5. TROUBLESHOOTING

Problem	Possible Cause	Solution
Display is dim or blank.	Low battery.	Replace the battery.
Time is inaccurate.	Incorrect setting; battery low.	Re-set the time; replace the battery if issue persists.
Backlight not working.	Low battery; faulty LED.	Replace the battery. If still not working, contact support.
Condensation inside the watch.	Water ingress; extreme temperature change.	Stop using the watch immediately. Seek professional repair to prevent further damage. Avoid extreme temperature changes.

If you encounter problems not listed here, or if the suggested solutions do not resolve the issue, please contact Dilwe customer support.

6. SPECIFICATIONS

Brand	Dilwe
Model Number	YX001
Material	Stainless Steel Bracelet / Zinc Alloy Plated Case / High Hardness Glass
Display Type	Digital
Watch Shape	Rectangle
Movement	Electronic

Dial Size	33 x 36 mm (approx. 1.3 x 1.4 inches)
Thickness	9 mm (approx. 0.35 inches)
Water Resistance	30 meters (3 ATM)
Weight	63 g (approx. 2.2 oz)



Figure 6: Watch dimensions: 36mm height and 33mm width.

7. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided at the time of purchase or contact your retailer. Dilwe aims to provide high-quality products, and any specific warranty terms will be outlined by the seller or manufacturer. For technical support or inquiries regarding your Dilwe Electronic Wristwatch, please contact Dilwe customer service through their official channels or the retailer from whom you purchased the product.

Note: Information regarding spare parts availability is currently unavailable.

© 2024 Dilwe. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07D4NTZSG>

More documents and user manuals: <https://manuals.plus/>