

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Hotsmtbang](#) /
- › [Hotsmtbang Replacement Remote Control for Onkyo A/V Receiver Systems User Manual](#)

Hotsmtbang Hotsmt-5697

Hotsmtbang Replacement Remote Control User Manual

Model: Hotsmt-5697

INTRODUCTION

This manual provides instructions for the Hotsmtbang Replacement Remote Control, model Hotsmt-5697. This remote is designed to be compatible with various Onkyo A/V Receiver Systems, including models such as RC-588M, RC-585M, RC-834M, HT-R667, HT-S5100S, HT-S6100, TX-SR576S, HT-S7100, TX-SR606S, TX-NR1030, HT-S3200, and HT-R570. It is pre-programmed and requires no additional setup beyond battery installation.



Figure 1: Front view of the Hotsmtbang Replacement Remote Control.

SETUP: BATTERY INSTALLATION

The remote control requires two (2) AA alkaline batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open it.
3. Insert two AA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.

4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Figure 2: Back view of the remote control with the battery compartment open, illustrating correct battery insertion.

Note: Batteries are not included with the remote control and must be purchased separately. Ensure to use new, high-quality alkaline batteries for optimal performance.

OPERATING INSTRUCTIONS

This Hotsmtbang replacement remote control is pre-programmed and ready to use with compatible Onkyo A/V Receiver Systems immediately after battery installation. No additional programming or setup is required.

- **Point and Use:** Aim the remote control directly at your Onkyo A/V receiver.
- **Button Functions:** Press the corresponding buttons for desired functions such as power, volume, input selection, and menu navigation. The button layout and functions are designed to mimic the original Onkyo remote control.

For specific functions and their corresponding buttons, refer to the user manual of your Onkyo A/V Receiver System.

MAINTENANCE AND CARE

To ensure the longevity and proper functioning of your remote control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as they may damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's responsiveness decreases or it stops functioning. Always replace both batteries at the same time with new ones.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage, which can cause damage.
- **Environment:** Avoid exposing the remote control to extreme temperatures, direct sunlight, high humidity, or liquids.

TROUBLESHOOTING

If you experience issues with your remote control, consult the following troubleshooting tips:

Problem	Solution
Remote control is not working.	<ul style="list-style-type: none"> • Ensure batteries are inserted correctly with the correct polarity (+/-). • Replace old batteries with new AA alkaline batteries. • Check if there are any obstructions between the remote control and the A/V receiver's infrared sensor. • Ensure you are within the effective range (up to 10 meters) and pointing the remote directly at the receiver.
Some buttons are not responding.	<ul style="list-style-type: none"> • Clean the remote control surface, especially around the unresponsive buttons, to remove any dirt or debris. • Replace batteries, as low power can sometimes cause intermittent button functionality.

SPECIFICATIONS

Feature	Detail
Brand	Hotsmtbang
Model Number	Hotsmt-5697
Special Feature	No Programming Required
Max Number of Supported Devices	1
Connectivity Technology	Infrared
Controller Type	Button Control

Feature	Detail
Maximum Range	10 Meters
Battery Type	2 AA Alkaline batteries (not included)

SUPPORT INFORMATION

For further assistance or inquiries regarding your Hotsmtbang Replacement Remote Control, please refer to the seller's contact information on the platform where the product was purchased. This manual provides general operational guidance; specific compatibility details for your Onkyo A/V Receiver System should be verified with your receiver's original documentation.

