

Maxi-Cosi CV364EMQ

Maxi-Cosi Lara Lightweight Ultra Compact Stroller Instruction Manual

Model: CV364EMQ

1. INTRODUCTION

The Maxi-Cosi Lara Stroller is designed for families seeking a lightweight and compact solution for travel and daily use. This ultra-compact stroller offers convenience, comfort, and essential features for your child's safety and your ease of use. It is suitable for children who can sit upright on their own, up to a maximum weight of 50 pounds.

Please read this instruction manual thoroughly before assembling or using the stroller to ensure proper operation and to prevent injury to your child.

2. SAFETY INFORMATION

Your child's safety is paramount. Always follow these safety guidelines:

- Never leave your child unattended in the stroller.
- Always use the 5-point harness system to secure your child. Ensure it is correctly adjusted and fastened.
- Do not overload the storage baskets or hang bags on the handle, as this can cause the stroller to become unstable.
- Ensure all locking devices are engaged before placing your child in the stroller.
- Do not use the stroller on stairs or escalators.
- Keep children clear of moving parts when making adjustments to the stroller.
- The stroller is not compatible for use with an infant car seat.
- Maximum weight capacity for the child is 50 pounds.

3. PRODUCT FEATURES

The Maxi-Cosi Lara Stroller includes the following features:

- **Ultra-Lightweight Design:** Weighs approximately 14 pounds for easy portability.
- **One-Hand Flash Fold:** Allows for quick and compact folding with a single hand.
- **Built-in Carry Strap:** For convenient transport when folded.
- **Dual Storage Baskets:** Two easy-to-access baskets provide ample space for essentials.
- **Parent Cup Holder:** A convenient attachment for your beverage.
- **Breathable Seat Pad:** Keeps your child comfortable and cool.

- **Plush Fabrics:** For enhanced comfort.
- **Multi-Position Recline:** Adjustable seat recline for resting or upright positions.
- **Adjustable Leg Rest:** Provides additional comfort for your child.
- **Extendable Sunshade with UPF 50:** Offers protection from the sun.
- **Peek-a-boo Window:** Allows you to check on your child without disturbing them.
- **5-Point Harness:** Ensures your child is securely fastened.
- **All-Wheel Suspension:** For a smoother ride.

4. SETUP AND ASSEMBLY

Before first use, ensure all components are present and undamaged. Assembly typically involves attaching the wheels and canopy. Refer to the visual guides below for assistance.



Figure 4.1: Front view of the Maxi-Cosi Lara Stroller in Nomad Blue. This image shows the stroller fully assembled with the canopy extended and the cup holder attached to the handle.



Figure 4.2: Close-up of the stroller's wheels, highlighting the all-wheel suspension system designed for a smooth ride.

5. OPERATING INSTRUCTIONS

5.1 Unfolding the Stroller

To unfold the stroller, release the folding latch and lift the handle until the frame locks into place. Ensure both sides are securely locked before use.

5.2 Folding the Stroller (One-Hand Flash Fold)

The Lara stroller features a convenient one-hand flash fold. Locate the folding mechanism on the handlebar. Press the button and push the handle forward to collapse the stroller. It will fold compactly for storage or transport.



Figure 5.1: A person demonstrating the one-hand folding mechanism of the Maxi-Cosi Lara Stroller, showing how it collapses into a compact form.



Figure 5.2: The Maxi-Cosi Lara Stroller in its compact, folded state, ready for storage or travel.

5.3 Using the Carry Strap

Once folded, the integrated shoulder strap allows for easy carrying. Simply sling it over your shoulder for hands-free transport.

5.4 Adjusting the Seat Recline

The seat offers multiple recline positions. To recline, locate the buckle strap at the back of the seat. Unclip the buckle to allow the seat to lower. To raise the seat, push the seat back up and re-fasten the buckle strap. Ensure the buckle is securely fastened in your desired position.

5.5 Adjusting the Leg Rest

The leg rest can be adjusted to provide optimal comfort for your child. Press the buttons on either side of the leg rest and move it to the desired position.

5.6 Using the Sunshade and Peek-a-boo Window

Extend the sunshade to protect your child from the sun. It provides UPF 50 protection. The canopy also features a mesh peek-a-boo window, allowing you to check on your child without fully opening the canopy.



Figure 5.3: A person extending the sunshade of the Maxi-Cosi Lara Stroller to provide maximum sun protection for the child.

5.7 Securing Your Child with the 5-Point Harness

Always secure your child using the 5-point harness. Insert each buckle tongue into the central buckle until it clicks. Adjust the straps for a snug, secure fit. To release, press the button on the central buckle.

5.8 Using the Storage Baskets and Cup Holder

The stroller features two easily accessible storage baskets for your belongings. The parent cup holder can be attached to the handlebar for your convenience.



Figure 5.4: Rear view of the Maxi-Cosi Lara Stroller, showcasing the two accessible storage baskets filled with baby essentials.

5.9 Engaging the Brakes

To engage the brakes, press down firmly on the brake pedal located near the rear wheels. Ensure the stroller is stationary before placing or removing your child.

5.10 Official Product Video

Your browser does not support the video tag.

Video 5.1: An official product video from Maxi-Cosi demonstrating the key features and ease of use of the Lara Lightweight Ultra Compact Stroller, including its one-hand fold and portability.

6. MAINTENANCE AND CARE

Regular maintenance ensures the longevity and safe operation of your stroller.

- **Cleaning:** The fabric seat pad can be removed for cleaning. Refer to the care label for specific washing instructions. The frame and plastic parts can be wiped clean with a damp cloth and mild soap.
- **Wheels:** Periodically check the wheels for wear and tear. Remove any debris that may accumulate around the axles.
- **Moving Parts:** Lubricate moving parts (e.g., folding mechanisms, wheel axles) with a silicone-based lubricant if they become stiff.
- **Storage:** Store the stroller in a dry place, away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

If you encounter any issues, refer to the following common solutions:

Problem	Possible Cause	Solution
Stroller does not fold/unfold smoothly.	Folding mechanism is stiff or obstructed.	Ensure all locks are disengaged. Check for obstructions. Apply silicone lubricant to moving parts if necessary.
Wheels squeak or do not turn freely.	Debris in wheel axles or lack of lubrication.	Clean wheels and axles. Apply silicone lubricant.
Seat recline is difficult to adjust.	Strap mechanism is tight or misaligned.	Ensure no weight is on the seat when adjusting. Gently pull the strap to loosen before buckling.

8. SPECIFICATIONS

- **Brand:** Maxi-Cosi
- **Model Number:** CV364EMQ
- **Color:** Nomad Blue
- **Frame Material:** Lightweight Metal/Alloy
- **Age Range (Description):** Baby (for children who can sit upright on their own)
- **Harness Type:** 5 Point
- **Maximum Weight Recommendation:** 50 Pounds
- **Fabric Type:** Plush
- **Item Weight:** 14 Pounds
- **Stroller Type:** Umbrella Stroller
- **Is Car Seat Compatible:** No
- **Seating Capacity:** 1
- **Number of Wheels:** 4
- **UPC:** 884392619824

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official Maxi-Cosi website. Please have your model number (CV364EMQ) and proof of purchase available when contacting support.

© 2023 Maxi-Cosi. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question