

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Monziteck](#) /

› [Monziteck Wall Mount for PS4 Slim Instruction Manual](#)

Monziteck Wall Mount for PS4 Slim

Monziteck Wall Mount for PS4 Slim Instruction Manual

Model: Wall Mount for PS4(PlayStation4) Slim

1. INTRODUCTION

Thank you for choosing the Monziteck Wall Mount for PS4 Slim. This product is specifically designed to securely mount your PlayStation 4 Slim console near or behind your television, optimizing space and ensuring proper ventilation. It is crafted from durable metal to provide a stable and long-lasting solution for your gaming setup.



Figure 1: Monzlteck PS4 Slim Wall Mount in use, providing a clean and organized gaming area.

2. COMPATIBILITY

This wall mount is exclusively designed for the **PlayStation 4 Slim** console. It is **not compatible** with the original PlayStation 4 (PS4) or the PlayStation 4 Pro (PS4 Pro) models.




Figure 2: Compatibility chart for Monziteck PS4 Slim Wall Mount.

3. SETUP AND INSTALLATION

The Monziteck wall mount is designed for easy installation. Please follow these steps carefully:

- 1. Identify Mounting Location:** Choose a suitable location on your wall, either near or behind your TV. Ensure the wall material is appropriate for mounting (stud or concrete).
- 2. Prepare for Mounting:** The package includes screws suitable for both stud and concrete mounting. Use the appropriate hardware for your wall type.
- 3. Secure the Mount:** Position the Monziteck wall mount on the wall and mark the drilling points. Drill pilot holes if necessary, then securely fasten the mount to the wall using the provided screws.

ONLY FIT FOR PS4 SLIM



Figure 3: Monzlteck Wall Mount components and mounting options.

4. **Insert PS4 Slim:** Once the mount is securely attached to the wall, carefully slide your PS4 Slim console into the mount from the top. The mount features thin inside padding to protect your console from scratching.

INSTALLS IN MINUTES

1



Figure 4: Step 1 of installation - Sliding the PS4 Slim into the mount.

5. **Secure the Console:** Use the provided hand knob to secure the PS4 Slim within the mount. Tighten the knob firmly but do not overtighten.

INSTALLS IN MINUTES

2



Figure 5: Step 2 of installation - Securing the console with the hand knob.

4. OPERATING AND USAGE

The Monzlteck wall mount is designed to enhance your gaming experience by providing a secure and space-saving solution for your PS4 Slim. Key operational benefits include:

- **Space Saving:** By mounting your console, you free up valuable space on your entertainment center or desk, contributing to a cleaner and more organized gaming area.
- **Protection:** The mount protects your PS4 Slim from accidental falls and impacts that might occur if it were placed on a surface.
- **Optimal Heat Dissipation:** The design ensures that all air vents of your PS4 Slim remain exposed and are not blocked. The mount also offsets the console from the wall, allowing for excellent airflow and preventing overheating, which contributes to a longer lifespan for your console.

Quick Heat Dissipation



Figure 6: Illustration of effective heat dissipation with the Monzlteck mount.



Figure 7: Example of a tidy gaming setup with the Monzlteck wall mount.

5. MAINTENANCE

The Monzlteck wall mount is constructed from durable metal and requires minimal maintenance.

- **Cleaning:** To clean the mount, simply wipe it with a soft, dry cloth. Avoid using abrasive cleaners or solvents, as these may damage the finish.
- **Inspection:** Periodically check the mounting screws to ensure they remain tight and secure.

6. TROUBLESHOOTING

If you encounter any issues with your Monzlteck wall mount, please refer to the following common

solutions:

- **Mount feels loose:** Ensure all mounting screws are properly tightened into the wall. If mounted into drywall, ensure you have used appropriate wall anchors or located a wall stud.
- **PS4 Slim does not fit:** Double-check that your console is indeed a PS4 Slim model. This mount is not compatible with the original PS4 or PS4 Pro. Refer to Figure 2 for visual confirmation.
- **Console overheating:** While the mount is designed for optimal airflow, ensure that the PS4 Slim's vents are not obstructed by dust or other objects. Ensure there is sufficient space around the console for air circulation.



7. SPECIFICATIONS

Brand	Monzlteck
Model Name	Wall Mount for PS4(PlayStation4) Slim
Color	Black
Compatible Devices	PS4 Slim Console
Mounting Type	Wall Mount
Special Feature	Customized design for PS-4 Slim, Quick heat dissipation
Material	Metal
Weight Limit	20 Pounds
Water Resistance Level	Not Waterproof

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the official Monzlteck website or contact their customer service directly. Keep your purchase receipt as proof of purchase.

For further assistance, you may visit the Monzlteck brand store on Amazon or contact Amazon customer service regarding your order.

	<p><u>Sony PlayStation 4 Slim Setup: Powering On and Connecting to TV</u></p> <p>A concise guide to setting up your Sony PlayStation 4 Slim console. Learn how to power on the system, connect to your TV via HDMI, and troubleshoot common display issues.</p>
	<p><u>P-4 Series Multifunctional Cooling Stand TP4-882 User Manual</u></p> <p>User manual for the P-4 Series Multifunctional Cooling Stand (TP4-882), detailing its features, specifications, installation, and usage for PlayStation 4 consoles and controllers. Includes cooling, charging, and game disc storage.</p>
	<p><u>Sony PlayStation 4 Pro CUH-7015B Quick Start Guide</u></p> <p>Concise guide to setting up and using the Sony PlayStation 4 Pro (CUH-7015B) console, including connections, controller setup, system features, online services, and safety information.</p>
	<p><u>PS4 Stand Cooling Fan User Manual for PS4 Slim and PS4 Pro</u></p> <p>User manual detailing the installation and features of the PS4 Stand Cooling Fan, designed for PlayStation 4 Slim and PS4 Pro consoles, including controller charging capabilities and cooling functions.</p>
	<p><u>PlayStation 4 Optical Drive Replacement Guide</u></p> <p>A comprehensive step-by-step guide for replacing the optical drive in a Sony PlayStation 4, detailing necessary tools, parts, and procedures.</p>
	<p><u>Stealth Light Up Charging Cable - Quick Start Guide & Manual</u></p> <p>Official quick start guide and manual for the Stealth Light Up Charging Cable, providing setup instructions, safety precautions, warranty information, and support contacts for DUALSHOCK 4 controllers.</p>