Homepointe 3190-41-CH-BC-MC-Z

Homepointe Homewerks Worldwide HP CHR 2-Handle Wall Mount Kitchen Faucet Instruction Manual

Model: 3190-41-CH-BC-MC-Z

Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your Homepointe Homewerks Worldwide HP CHR 2-Handle Wall Mount Kitchen Faucet. Please read this manual thoroughly before installation and retain it for future reference. This faucet features a chrome-plated finish, two handles for hot and cold water control, and is designed for wall-mount installation in kitchen environments.

The faucet is equipped with a 1.8 GPM aerator and operates with a quarter-turn mechanism for ease of use. Its brass body and waterway ensure durability and compliance with lead-free standards.

Safety Information

- Always turn off the main water supply before beginning any installation or repair work.
- Wear appropriate personal protective equipment, such as safety glasses, during installation.
- Ensure all connections are secure to prevent leaks.
- If you are unsure about any part of the installation process, consult a qualified plumber.
- Do not use harsh chemicals or abrasive cleaners on the faucet finish, as this may damage the chrome plating.

Package Contents

Verify that all components are present before beginning installation:

- Homepointe HP CHR 2-Handle Wall Mount Kitchen Faucet (Main Unit)
- Installation Hardware (Gaskets, mounting nuts, etc.)



Image: Homepointe HP CHR 2-Handle Wall Mount Kitchen Faucet, showcasing its chrome finish, two handles, and wall-mount design with a 6-inch spout.

Setup and Installation

This faucet is designed for wall-mount installation. Follow these steps carefully:

1. **Prepare the Installation Area:** Ensure the main water supply to the kitchen is turned off. Clear the area where the faucet will be mounted.
2. **Measure Center Distance:** The faucet's center distance is adjustable from 7 inches to 9 inches. Measure the distance between your existing hot and cold water supply lines on the wall to ensure compatibility. Adjust the faucet body if necessary.
3. **Connect Supply Lines:** Attach the faucet's 1/2-inch female connections to the hot and cold water supply lines extending from the wall. Use appropriate thread sealant or plumber's tape on the male threads of the supply lines to ensure a watertight seal.
4. **Mount the Faucet:** Secure the faucet to the wall using the provided installation hardware. Ensure the faucet is level and firmly attached.
5. **Check for Leaks:** Once the faucet is securely mounted and connected, slowly turn on the main water supply. Inspect all connections for any signs of leaks. Tighten connections as needed.
6. **Test Operation:** Turn on both hot and cold water handles to ensure proper flow and temperature control.

Operating Instructions

Your Homepointe kitchen faucet features a simple two-handle, quarter-turn operation:

- **Turning On/Off:** Rotate the handles a quarter turn to open or close the water flow. The left handle typically controls hot water, and the right handle controls cold water.
- **Adjusting Temperature:** Mix hot and cold water by adjusting both handles simultaneously to achieve the desired water temperature.
- **Water Flow:** The faucet is equipped with a 1.8 GPM (Gallons Per Minute) aerator, providing an efficient water flow for kitchen tasks.

Maintenance

Regular cleaning and maintenance will help preserve the finish and functionality of your faucet:

- **Cleaning the Finish:** Clean the chrome-plated finish with a soft, damp cloth and mild soap. Rinse thoroughly and dry with a soft towel to prevent water spots. Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the finish.
- **Aerator Maintenance:** If water flow decreases or becomes erratic, the aerator may be clogged. Unscrew the aerator

from the spout, clean any debris or mineral deposits, and rinse it under running water. Reattach the aerator securely.

- **Cartridge Replacement:** For replacement cartridges, refer to part numbers #31-410-HW and #31-411-HW. Consult a qualified plumber for cartridge replacement if you are unfamiliar with the process.

Troubleshooting

Problem	Possible Cause	Solution
Faucet leaks from spout	Worn cartridge or O-rings	Replace cartridges (#31-410-HW & #31-411-HW).
Low water flow	Clogged aerator or debris in supply lines	Clean or replace aerator. Flush supply lines.
Leaks at base of faucet	Loose connections or damaged gaskets	Tighten mounting nuts. Check and replace gaskets if necessary.
Water temperature not mixing properly	Issue with hot or cold water supply, or cartridge malfunction	Ensure both hot and cold water supplies are fully open. Inspect and replace cartridges if needed.

Specifications

Brand	Homepointe
Model Name	HP CHR 2Hand Kit Faucet
Item Model Number	3190-41-CH-BC-MC-Z
Finish Type	Chrome plated
Material	Brass
Mounting Type	Wall Mount
Number of Handles	2
Spout Reach	6 Inches
Aerator Flow Rate	1.8 GPM
Connection Size	1/2 inch female connections
Center Distance	Adjustable from 7" to 9"
Operation Type	Quarter turn
Item Weight	1.31 Pounds
Product Dimensions	11 x 4 x 2.63 inches
UPC	052088092149

Warranty and Support

For warranty information or technical support, please contact Homewerks Worldwide customer service. Keep your purchase receipt as proof of purchase.

Replacement cartridges are available using part numbers #31-410-HW and #31-411-HW.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question