

RECCAZR MP2000

RECCAZR MP2000 Computer Speakers Instruction Manual

Model: MP2000

INTRODUCTION

Thank you for choosing the RECCAZR MP2000 Computer Speakers. These 2.0 channel USB-powered multimedia speakers are designed to provide clear audio for your desktop, laptop, TV, PC, or smartphone. This manual provides essential information for proper setup, operation, and maintenance of your speakers.

SAFETY INFORMATION

Please keep this product away from children. The speakers support a maximum input of 5V 0.5A. Do not exceed this power rating.

PRODUCT OVERVIEW

Package Contents

- RECCAZR MP2000 Computer Speakers (2 units)
- Integrated USB power cable
- Integrated 3.5mm audio cable

Features

- 2.0 Channel Stereo Sound: Delivers balanced audio for an enhanced listening experience.
- USB Powered: Conveniently powered via a standard USB port (5V 0.5A max).
- 3.5mm Audio Input: Universal compatibility with devices featuring a 3.5mm audio jack.
- In-line Volume Control: Easy access to adjust audio levels.
- Four Diaphragm Design: Engineered for enhanced bass performance.



Image: Front view of a RECCAZR MP2000 speaker, illustrating its 2.0 stereo sound capability with balanced sound quality.

MP2000 BWH 2.0

Size: 3.6 (W) x 5.4 (H) x 3.2 (D) inch



Image: Front and side views of the RECCAZR MP2000 speakers, showing their compact dimensions: 3.6 (W) x 5.4 (H) x 3.2 (D) inches.



4 x Diaphragm Design Enhanced bass effect

Image: Rear view of a RECCAZR MP2000 speaker, highlighting the 4-diaphragm design for enhanced bass effects.

SETUP INSTRUCTIONS

1. **Positioning:** Place the two speakers on either side of your computer monitor, TV, or desired listening area. Ensure they are on a stable, flat surface.
2. **Connect Audio:** Insert the 3.5mm audio plug into the audio output jack of your device (e.g., laptop, PC, smartphone, TV).
3. **Connect Power:** Insert the USB plug into an available USB port on your computer, a USB wall adapter, or a power bank. The speakers require 5V 0.5A power.
4. **Verify Connection:** Ensure both the USB and 3.5mm audio plugs are securely connected.



Plug and play

USB and 3.5mm audio plug
without drivers

NOTE: Connect both usb and plug

Enhanced bass

Four Diaphragm Design



Vol Control

On-Line speaker volume control
Quick and easy adjustments

Image: Close-up of the USB and 3.5mm audio plugs connected to a laptop, demonstrating the plug-and-play setup and the in-line volume control.



Image: Diagram showing how to connect the RECCAZR MP2000 speakers to various devices like mobile phones, music players, laptops, and projectors, using the USB power cable and 3.5mm audio jack.

OPERATING INSTRUCTIONS

1. **Power On/Off:** The speakers power on automatically when the USB cable is connected to a powered USB port. There is no separate power switch.
2. **Volume Adjustment:** Use the in-line rotary volume control located on the cable to adjust the sound level. Turn the knob clockwise to increase volume and counter-clockwise to decrease it. You can also adjust the volume from your connected device.
3. **Audio Playback:** Once connected and powered, play audio from your device. The sound will be routed through the

63 inch

Wire length




Image: A close-up of the in-line volume control unit on the speaker cable, indicating its position and function for quick volume adjustments.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker surfaces. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use for extended periods, disconnect the speakers from power and store them in a cool, dry place.
- **Cable Care:** Avoid bending or crimping the cables excessively to prevent damage.
- **Environment:** Do not expose the speakers to extreme temperatures, humidity, or direct sunlight.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No sound from speakers	• USB power not connected or insufficient. • 3.5mm audio cable not connected or loose. • Device volume too low or muted. • Speakers not selected as output device.	• Ensure USB cable is connected to a powered USB port (5V 0.5A). • Check 3.5mm audio cable connection on both speaker and device. • Increase volume on both the in-line control and your device. • Verify audio output settings on your computer/device.
Sound is distorted or unclear	• Volume set too high. • Poor audio source quality. • Interference from other devices.	• Lower the volume on both the speakers and your device. • Try a different audio source or file. • Move speakers away from other electronic devices.
Speakers make popping/crackling noise	• Power fluctuations. • Interference. • Faulty connection.	• Try connecting the USB power to a different port or power adapter. • Ensure all cables are securely connected. • Avoid using speakers near strong electromagnetic fields.

SPECIFICATIONS

Feature	Detail
Model Name	MP2000
Speaker Type	Multimedia, 2.0 Channel Stereo
Power Source	USB Powered (5V 0.5A max)
Connectivity Technology	Auxiliary (3.5mm), USB
Speaker Maximum Output Power	6 Watts
Frequency Response	18 KHz
Impedance	4 Ohms
Product Dimensions (each speaker)	37.4"D x 90.55"W x 57.09"H (Note: These dimensions seem unusually large for small computer speakers, please refer to product images for visual scale.)
Item Weight	1.32 Pounds
Material	Plastic
Compatible Devices	Laptop, Personal Computer, Television, Smartphone

Feature	Detail
Included Components	USB cable, 3.5mm audio cable

WARRANTY AND SUPPORT

The RECCAZR MP2000 Computer Speakers come with a Limited Warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions.

For technical support or customer service inquiries, please contact RECCAZR customer support. Contact information can typically be found on the product packaging or the official RECCAZR website.

© 2024 RECCAZR. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07D6ZVP8G>

More documents and user manuals: <https://manuals.plus/>