

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Simple Deluxe](#) /
- › [Simple Deluxe 16 Inch Wall Mount Fan with Remote Control Instruction Manual](#)

## Simple Deluxe HIFANXWALLDIGIT16

# Simple Deluxe 16 Inch Wall Mount Fan with Remote Control Instruction Manual

Model: HIFANXWALLDIGIT16

Brand: Simple Deluxe

### 1. INTRODUCTION AND OVERVIEW

---

The Simple Deluxe Digital Oscillating Wall Mount Fan is designed to provide precise fan movement patterns suitable for various applications. This fan features speed control, a 4-hour increment timer, and oscillation controls. Its reliable metal gear construction ensures quiet operation. The included remote control allows for easy adjustment of settings from a distance, and can control multiple Simple Deluxe Digital Oscillating Wall Mount Fans.



Image 1: Overview of the Simple Deluxe 16 Inch Wall Mount Fan, highlighting oscillating control, 4-hour increment timer, 3-speed control, 3-mode control, and off button.

## 2. PRODUCT FEATURES

- **Three-Speed Versatility:** Choose from a gentle whisper, a steady breeze, or a strong gust of air with three distinct speed settings.
- **Dynamic Airflow Range:** Engineered with 60 degrees of vertical tilt and 92 degrees of oscillation to direct air effectively throughout the room.
- **Remote Control:** Adjust settings, switch between three operating modes, and utilize the timing function conveniently from a distance.
- **Timing Function:** Set the fan to automatically turn off after a set duration for energy saving and comfort.
- **Space-Saving Wall Mount Design:** Maximize room potential with a compact, wall-mounted design suitable for homes, offices, workshops, and garages.
- **Easy Installation:** Comes with all necessary components and straightforward instructions for a hassle-free setup.

## 3. PACKAGE CONTENTS

The package includes:

- Simple Deluxe 16 Inch Wall Mount Fan
- Remote Control
- Mounting hardware (screws and drywall anchors)

#### **4. SAFETY INSTRUCTIONS**

---


- Always unplug the fan before cleaning or performing maintenance.
- Do not insert fingers or any objects through the fan grille when the fan is operating.
- Ensure the fan is mounted securely to a wall stud or using appropriate drywall anchors.
- Keep the power cord away from heated surfaces.
- Do not operate the fan with a damaged cord or plug.
- This fan is intended for indoor use only.

#### **5. SETUP AND INSTALLATION**

---

The Simple Deluxe Wall Mount Fan is designed for easy and secure installation. Follow these general steps:

1. Select a suitable location on a wall, ensuring it is near a power outlet and provides optimal airflow.
2. Use the provided mounting bracket as a template to mark the drilling points on the wall.
3. Drill pilot holes and insert the appropriate drywall anchors if not mounting into a stud.
4. Secure the mounting bracket to the wall using the provided screws.
5. Attach the fan unit to the mounted bracket, ensuring it clicks securely into place.
6. Plug the fan into a standard electrical outlet.



**Durable  
Mounting  
Bracket**

*Image 2: Close-up view of the durable mounting bracket on the Simple Deluxe Wall Mount Fan, illustrating how it attaches to the wall.*

For a visual guide on installation and operation, please refer to the official seller video below:

[Your browser does not support the video tag.](#)

*Video 1: Official seller video demonstrating the features and operation of the Simple Deluxe Digital Wall Mount Fan with Remote Control.*

## **6. OPERATING INSTRUCTIONS**

---

The fan can be operated using the control panel on the unit or the included remote control.

### **Control Panel**



## Speed/ Mode/ Timer Control Panel

*Image 3: Close-up of the fan's control panel, showing buttons for speed, mode, timer, and oscillation.*

- **ON/OFF:** Press to turn the fan on or off.
- **SPEED:** Cycle through Low, Medium, and High-speed settings.
- **MODE:** Select between Normal, Nature, and Sleep modes.
- **TIMER:** Set the fan to operate for a specific duration (e.g., 0.5, 1, 2, 4 hours).
- **OSC (Oscillation):** Activate or deactivate the oscillation function for wider air distribution.

### Remote Control

# REMOTE CONTROL



Swing Control



4 hour Increment Timer



On/  
3-Speed Control



3-Mode Control



Off Button



Image 4: The remote control for the Simple Deluxe Wall Mount Fan, featuring buttons for power, oscillation, timer, mode, and speed adjustment.

The remote control duplicates all functions available on the fan's control panel, allowing for convenient operation from a distance. Ensure batteries are installed correctly (batteries not included).

## 7. MAINTENANCE

Regular cleaning and maintenance will ensure optimal performance and longevity of your fan.

- **Cleaning:** Disconnect the fan from the power source before cleaning. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or immerse the fan in water.
- **Grille Cleaning:** The front grille can be removed for cleaning the fan blades. Refer to the assembly instructions for safe removal and reattachment.
- **Storage:** If storing the fan for an extended period, clean it thoroughly and store it in a cool, dry place.

## 8. TROUBLESHOOTING

If your fan is not operating correctly, please check the following:

- **Fan does not turn on:** Ensure the power cord is securely plugged into a working outlet. Check if the power button on the unit or remote has been pressed.
- **No airflow or weak airflow:** Verify the speed setting is appropriate. Ensure the fan blades are not obstructed.
- **Oscillation not working:** Check if the oscillation function is activated on the control panel or remote. Ensure there are no obstructions preventing movement.
- **Remote control not working:** Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the fan's receiver.

If issues persist, contact customer support.

## 9. SPECIFICATIONS

Detailed product specifications for the Simple Deluxe 16 Inch Wall Mount Fan:

Attribute	Value
Brand	Simple Deluxe
Model Name	HIFANXWALLDIGIT16
Color	White
Electric Fan Design	Wall Mount Fan
Power Source	Corded Electric
Style	Remote
Product Dimensions	18.5"D x 30"W x 6"H
Room Type	Living Room, Garage, Meeting Room
Special Feature	Adjustable Tilt, Oscillating, Remote Controlled, Timer
Recommended Uses	Air Circulation, Cooling, Exhausting
Wattage	15 Watts
Number of Blades	3
Speed Settings	3 RPM
Voltage	120V
Included Components	Wall fan and remote control
Indoor/Outdoor Usage	Indoor
Control Method	Remote
Cable Length	6 Feet
Item Weight	12.57 pounds

Attribute	Value
Diameter	16 Inches
Batteries Required	Yes (for remote)




Image 5: Diagram showing the dimensions of the Simple Deluxe Wall Mount Fan, including 17" height and 60" power cord.

## 10. WARRANTY AND SUPPORT

This Simple Deluxe product comes with a **1-year manufacturer warranty**. For any support inquiries, troubleshooting assistance, or warranty claims, please contact Simple Deluxe customer service through their official channels or the retailer where the product was purchased.

