

- Manuals.plus /
- › Christopher Knight Home /
 - › Christopher Knight Home Caribbean Outdoor 30" Acacia Wood Barstools (Set of 2), Grey Finish - Instruction Manual

Christopher Knight Home 304143

Christopher Knight Home Caribbean Outdoor 30" Acacia Wood Barstools (Set of 2), Grey Finish

Model: 304143

1. PRODUCT OVERVIEW

Thank you for choosing the Christopher Knight Home Caribbean Outdoor Acacia Wood Barstools. This set of two 30-inch barstools is designed for outdoor use, offering a comfortable saddle seat and a durable acacia wood construction. The grey finish provides a rustic aesthetic suitable for various outdoor settings, including patios, balconies, and backyard bar areas.



Image 1.1: Christopher Knight Home Caribbean Outdoor Acacia Wood Barstools in Grey Finish.

2. PACKAGE CONTENTS

Please ensure all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Two (2) Acacia Wood Barstools (Grey Finish)
- Assembly Hardware (screws, washers, nuts)
- Assembly Tool (Allen wrench)

3. SETUP AND ASSEMBLY

Assembly of these barstools is straightforward and typically takes approximately 5-10 minutes per stool. All necessary tools and hardware are included in the package.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Attach Cross Bars:** Identify the cross bars and align them with the pre-drilled holes on the stool legs. Insert the provided screws and washers.
3. **Secure Connections:** Using the included Allen wrench, tighten all screws firmly. Ensure all connections are secure to prevent wobbling. Do not overtighten to avoid stripping the wood.
4. **Repeat for Second Stool:** Follow the same steps to assemble the second barstool.



Image 3.1: Underside view illustrating the assembly points of the barstool.

After assembly, gently test the stability of each stool before regular use. If any wobbling occurs, re-check and tighten all screws.

4. OPERATING INSTRUCTIONS

These barstools are designed for comfortable seating at outdoor bar-height surfaces. The saddle seat is ergonomically shaped for user comfort.

- **Placement:** Position the barstools on a flat, stable surface to ensure stability and prevent tipping.

- **Usage:** Use the footrests for added comfort and support.
- **Weight Capacity:** Do not exceed the maximum recommended weight capacity of 46.3 pounds per stool to ensure safety and product longevity.

5. MAINTENANCE

Proper care and maintenance will extend the life and appearance of your acacia wood barstools.

- **Regular Cleaning:** Wipe down the barstools regularly with a soft, damp cloth to remove dust and dirt. For tougher stains, use a mild soap solution and rinse thoroughly. Dry immediately to prevent water spots.
- **Wood Oiling:** Acacia wood benefits from periodic oiling (e.g., with teak oil or other outdoor wood sealants) to maintain its luster and protect against weathering. Apply oil according to the product manufacturer's instructions, typically every 3-6 months depending on exposure.
- **Protection from Elements:** While designed for outdoor use, prolonged exposure to harsh weather conditions (heavy rain, direct sunlight, extreme temperatures) can affect the wood. Consider using outdoor furniture covers or storing the barstools indoors during off-seasons or severe weather.
- **Check Hardware:** Periodically inspect all screws and connections and tighten them as needed to maintain stability.

6. TROUBLESHOOTING

Most issues can be resolved with simple adjustments.

- **Wobbly Stool:** If a stool feels wobbly, check all assembly screws. Loosen them slightly, adjust the stool on a flat surface, and then re-tighten all screws evenly.
- **Fading Finish:** Over time, outdoor wood furniture may experience some fading due to sun exposure. This is natural. Regular oiling (as described in the Maintenance section) can help restore and protect the finish.

7. SPECIFICATIONS

Feature	Detail
Product Name	Caribbean Outdoor Barstools
Brand	Christopher Knight Home
Model Number	304143
Material	Acacia Wood
Color	Grey Finish
Dimensions (D x W x H)	13" x 17.5" x 30"
Seat Height	30 Inches
Item Weight	24.2 Pounds (per stool)
Maximum Weight Recommendation	46.3 Pounds
Number of Items	2 (Set of 2)
Assembly Required	Yes



Image 7.1: Product Dimensions.

8. WARRANTY AND SUPPORT

For warranty information or assistance with your Christopher Knight Home product, please refer to the documentation included with your purchase or contact the retailer/manufacturer directly. Keep your proof of purchase for any warranty claims.

For further support, please visit the [Christopher Knight Home Store](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07D7RCRYQ>

More documents and user manuals: <https://manuals.plus/>