

ANERIMST A1

ANERIMST Outdoor Bluetooth Speaker with Flame Atmosphere

Model: A1 | Brand: ANERIMST

INTRODUCTION

The ANERIMST Outdoor Bluetooth Speaker with Flame Atmosphere is a versatile 5-in-1 device designed to enhance your outdoor and indoor experiences. It functions as a powerful Bluetooth speaker, a retro outdoor lantern, a camping light, mood lighting, and a night light. Featuring upgraded 96 LED torch lights that flicker like real flames, it creates a romantic and inviting ambiance while delivering crystal clear stereo sound. Its IP65 water-resistant design ensures durability against various weather conditions, making it perfect for parties, camping, and garden use.

WHAT'S IN THE BOX

- ANERIMST Outdoor Bluetooth Speaker with Flame Atmosphere
- USB Charging Cable
- User Manual



Image: The ANERIMST speaker shown with its packaging, highlighting the "Flame Atmosphere Speaker" label on the box.

PRODUCT SPECIFICATIONS

Brand	ANERIMST
Model Name	Jean-tan-007 (A1)
Speaker Type	Portable Bluetooth Speaker
Connectivity Technology	Bluetooth 5.0
Speaker Maximum Output Power	5 Watts
Audio Output Mode	Stereo
Water Resistance Level	IP65 (Waterproof)
Battery Life (Speaker)	Approx. 18 hours
Battery Life (Torch Light only)	Approx. 1 week
Charging Time	4-5 hours (full charge via USB)

Product Dimensions	4.7"D x 7.4"W x 4.7"H
Item Weight	1.04 pounds (0.47 Kilograms)
Control Method	Touch

SETUP

Charging the Speaker

Before first use, fully charge the speaker. Connect the provided USB cable to the Micro USB charging socket on the speaker and to a compatible USB power source (e.g., computer, USB wall adapter). The charging indicator light will show charging status and turn off when fully charged. A full charge typically takes 4-5 hours.



Image: Close-up of the speaker's top panel, indicating the Micro USB charging socket and control buttons.

OPERATING INSTRUCTIONS

Power On/Off

- To power on, press and hold the **Power button** (⏻) on the top panel until you hear an audible prompt.
- To power off, press and hold the **Power button** again until the device shuts down.

Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicated by a blinking blue light on the top panel).
2. On your mobile device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
3. Select "ANERIMST A1" (or similar name) from the list of devices.
4. Once connected, the speaker will provide an audible confirmation, and the blue light will become solid.

Note: The speaker supports Bluetooth 5.0 for stable and efficient connection.

Dual Pairing Function (TWS)

For an enhanced stereo sound experience, you can pair two ANERIMST speakers together:

1. Ensure both speakers are powered off.
2. Power on both speakers. Do not connect them to your phone yet.
3. On one speaker (this will be your primary speaker), double-press the **Play/Pause button** (🔊). The speakers will attempt to connect to each other.
4. Once successfully paired, you will hear a confirmation sound. The primary speaker's light will blink, and the secondary speaker's light will be solid.
5. Now, connect your mobile device to the primary speaker via Bluetooth as described above. Both speakers will play audio in stereo.



Image: Two ANERIMST speakers positioned to demonstrate the dual pairing feature, providing stereo sound.

Controlling Music Playback

- **Play/Pause:** Press the **Play/Pause button** (🔊).
- **Next Track:** Press the **Next/Volume + button** (🔊).
- **Previous Track:** Press the **Last/Volume - button** (🔊).
- **Volume Up:** Press and hold the **Next/Volume + button**.
- **Volume Down:** Press and hold the **Last/Volume - button**.

Light Modes

The speaker features two LED light modes: flickering flame and constant light.

- To switch between light modes or turn the light off, press the **Lamp button** (🔊) on the top panel.
- The sequence is typically: Flame Effect -> Constant Light -> Light Off.



Image: The ANERIMST speaker displaying its vibrant flame atmosphere light effect.



Image: The ANERIMST speaker with its constant light mode activated, providing steady illumination.

Your browser does not support the video tag.

Video: Official ANERIMST video demonstrating the wireless speaker with flame light effects and various uses.

MAINTENANCE

- **Cleaning:** Wipe the speaker with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Water Resistance:** The speaker is IP65 water-resistant, meaning it can withstand splashes, rain, and dust. Do not submerge it in water. Ensure the charging port cover is securely closed when exposed to water.
- **Storage:** Store the speaker in a cool, dry place when not in use for extended periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker fully.

Cannot pair via Bluetooth.	Speaker not in pairing mode; device Bluetooth off; too far from device.	Ensure speaker is blinking blue. Turn device Bluetooth off/on. Move device closer to speaker (within 10 meters).
No sound or low volume.	Volume too low on speaker or device; speaker not connected.	Increase volume on both speaker and connected device. Re-pair Bluetooth.
Dual pairing (TWS) fails.	Speakers not powered off before TWS pairing; incorrect pairing sequence.	Ensure both speakers are off, then power on and double-press Play/Pause on one speaker *before* connecting to your phone.
Flame light not working.	Light mode off; low battery.	Press the Lamp button to cycle through modes. Charge the speaker.

WARRANTY AND SUPPORT

ANERIMST products are designed for quality and reliability. For any product-related inquiries, technical support, or warranty claims, please refer to the contact information provided in your product packaging or visit the official ANERIMST brand store on Amazon.

Official ANERIMST Store: [ANERIMST Store](#)

Safety Information (PDF): [Download Safety Information](#)