

[Manuals.plus](#) /

› [AquaVault](#) /

› AquaVault 100% Waterproof Floating Smart Phone Case & Money Pouch Instruction Manual

AquaVault AV03-PhoneCase

AquaVault 100% Waterproof Floating Smart Phone Case & Money Pouch Instruction Manual

Model: AV03-PhoneCase

PRODUCT OVERVIEW

The AquaVault 100% Waterproof Floating Smart Phone Case & Money Pouch is designed to protect your smartphone and valuables from water, dirt, dust, sand, rain, and snow. Its patented floating airbag design ensures your device remains buoyant if dropped in water. The case features a super clear screen and polycarbonate lens for clear underwater photography and video recording, along with a unique rolling ziploc system and double velcro locking mechanism for maximum protection. It also includes an adjustable neck strap for convenient carrying.



Image: AquaVault Waterproof Floating Smart Phone Case in Pink.

SETUP

1. **Initial Waterproof Test:** Before first use with your device, perform a waterproof test. Insert a dry tissue into the case, seal it completely, and submerge it in water for at least 30 minutes. After removal, check the tissue for any signs of moisture. If the tissue is wet, do not use the case and contact customer support.
2. **Inserting Your Phone:** Open the double velcro and rolling ziploc system. Carefully slide your smartphone into the pouch. Ensure no sharp objects are inside the case that could puncture the material.
3. **Sealing the Pouch:**
 - Align the edges of the ziploc seal and press firmly to close it completely across the entire width.
 - Roll down the top edge of the case tightly at least three times.
 - Secure the rolled top with the double velcro straps. Ensure the velcro is firmly attached to prevent accidental opening.

4. **Attaching the Neck Strap:** Attach the adjustable neck strap to the designated loops on the case for secure carrying.

Your browser does not support the video tag.

Video: Demonstrates how to use the AquaVault case, including sealing and handling in water. This video is provided by AquaVault, Inc.

OPERATING INSTRUCTIONS

Using Your Phone in the Case

- **Touchscreen Functionality:** The transparent material allows for full touchscreen functionality. You can text, email, browse social media, and use apps while your phone is securely inside the case.
- **Taking Photos and Videos Underwater:** The super clear screen and polycarbonate lens are designed to allow for clear photo and video capture up to 30 feet underwater. Ensure your phone's camera app is open before submerging for easier operation.
- **Making Calls and Listening to Music:** You can make and receive calls, and listen to music through the case. Audio quality may be slightly reduced due to the protective layers.



Take Pictures & Videos Underwater

Image: A person using the AquaVault phone case to take photos underwater.



Image: A man talking on his phone while it is secured in the AquaVault case by a pool.

Floating Feature

The patented floating airbag design ensures that if the case is accidentally dropped in water, it will float to the surface, making it easy to retrieve your device.

A woman is swimming in a pool, and an AquaVault phone case is floating on the surface of the water. The case is black and has a clear protective cover. The text "Reinforced Corners & It Floats" is overlaid on the image in a dark grey box with white text.

Reinforced Corners & It Floats

Image: The AquaVault phone case floating on the surface of a swimming pool.

Neck Strap Usage

The adjustable neck strap provides a secure and convenient way to carry your phone case, keeping it accessible while preventing loss in active environments.



Image: A man on a jet ski wearing the AquaVault phone case around his neck.

MAINTENANCE

- **Cleaning:** After each use, especially in saltwater, rinse the case thoroughly with fresh water. Wipe it dry with a soft cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the case in a cool, dry place away from direct sunlight and sharp objects. Ensure the case is completely dry before storing.
- **Regular Inspection:** Periodically inspect the case for any signs of wear, tears, or damage to the seals. Discontinue use if any damage is found.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Water inside the case after use.	Improper sealing, damaged seal, or puncture.	Ensure the ziploc and velcro seals are completely closed. Perform a waterproof test. If damage is found, discontinue use.
Touchscreen unresponsive.	Air trapped inside, excessive pressure, or screen protector interference.	Remove excess air before sealing. Avoid pressing too hard. Some screen protectors may affect sensitivity.
Fogging inside the case.	Temperature difference between phone and environment, or humidity.	Ensure phone is dry before inserting. Avoid extreme temperature changes. A small desiccant packet can help.

SPECIFICATIONS

Feature	Detail
Brand	AquaVault
Model Number	AV03-PhoneCase
Compatible Phone Models	All smartphones
Material	Polycarbonate, Polyvinyl Chloride (PVC)
Water Resistance Level	Waterproof (up to 30 feet)
Additional Features	Floating design, RFID Blocking, Adjustable Neck Strap, Reinforced Corners
Item Dimensions	4 x 0.5 x 7.5 inches
Item Weight	0.15 Pounds
UPC	609408295362



Image: AquaVault phone cases in black, white, blue, and pink, showing dimensions.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the product packaging or visit the official AquaVault website. Keep your proof of purchase for any warranty claims.

Manufacturer: AquaVault

Seller: AquaVault, Inc.

ADDITIONAL RESOURCES

Your browser does not support the video tag.

Video: AquaVault Waterproof Floating Phone Case and Money Pouch overview. This video is provided by AquaVault, Inc.

Your browser does not support the video tag.

Video: Demo of the AquaVault Waterproof Phone Case. This video is provided by AquaVault, Inc.

Your browser does not support the video tag.

Video: AquaVault Waterproof Phone Case in action with sharks. This video is provided by AquaVault, Inc.

Your browser does not support the video tag.

Video: Overview of Best Travel Accessories by AquaVault. This video is provided by AquaVault, Inc.

© 2024 AquaVault. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07D856FTD>

More documents and user manuals: <https://manuals.plus/>