

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [AIKE](#) /
- › [AIKE Automatic Wall Mount Liquid Soap Dispenser AK1205 User Manual](#)

## AIKE AK1205

# AIKE Automatic Wall Mount Liquid Soap Dispenser AK1205 User Manual

Model: AK1205

## 1. INTRODUCTION

---

This manual provides instructions for the installation, operation, and maintenance of your AIKE Automatic Wall Mount Liquid Soap Dispenser, Model AK1205. Designed for both commercial and home use, this touchless dispenser promotes hygiene and efficiency with its durable stainless steel construction and large capacity.



*Figure 1: AIKE Automatic Wall Mount Liquid Soap Dispenser AK1205.*


## **2. SAFETY INFORMATION**

- Always ensure the dispenser is installed at the recommended height to prevent accidental dispensing.
- Use only liquid soap. Do not use foaming soap or abrasive liquids.
- Do not submerge the unit in water or expose it to excessive moisture.
- Keep batteries away from children. Dispose of used batteries responsibly.
- Avoid direct sunlight or strong light exposure to the sensor.

### 3. PACKAGE CONTENTS

Verify that all items are present in the package:

- AIKE Automatic Liquid Soap Dispenser (x1)
- Installation Panel (x1)
- Key (x1)
- Expansion Screw (x3)
- ST4X25 Screw (x3)
- Nail-free Glue (x1)
- User Manual (x1)



## What You Get

- |                     |                    |
|---------------------|--------------------|
| Dispenser X1        | Key X1             |
| Safety Screw X1     | User Guide X1      |
| ST4X25 Screw X3     | Nail-free Glue X 1 |
| Expansion Anchor X3 | Mounting Plate X1  |

Figure 2: Included components.

## 4. SPECIFICATIONS

Feature	Detail
Model Number	AK1205S
Color	Brushed Stainless Steel
Material	Acrylonitrile Butadiene Styrene (ABS), Stainless Steel
Product Dimensions (L x W x H)	4" x 4.3" x 8.86" (10.2cm x 10.9cm x 22.5cm)
Liquid Volume Capacity	700 Milliliters (25 oz)
Power Source	4 AA Batteries (not included)
Dispensing Levels	5 levels (0.5ml - 2.5ml)

## 5. SETUP & INSTALLATION


### 5.1 Installation Distance


Ensure there are no obstructions beneath the dispenser. For optimal performance, maintain the following distances from the countertop:

- **Ordinary Countertops:** > 8 inches (20cm)
- **Reflective Countertops:** > 12 inches (30cm)


## COST SAVINGS: PRECISE METERING


5-Level Adjustment (Default: Level 2)


Level 1 

Level 2 

Level 3 

Level 4 

Level 5 



Power/  
Adjustment  
Button




Figure 3: Recommended installation height.

### 5.2 Mounting Options

The dispenser offers two installation methods:

- **Drill Installation:** Secure the provided installation panel to the wall using the expansion screws and ST4X25 screws.
- **Nail-free Glue Installation:** Apply the provided nail-free glue to the back of the installation panel and firmly press it onto a clean, dry wall surface. Allow the glue to cure completely before mounting the dispenser.



## For Kids

Fun and easy handwashing builds healthy habits

Touchless

## Hassle-Free at Home



Figure 4: Dual installation options.

### 5.3 Battery Installation

The dispenser requires 4 AA batteries (not included). The sealed waterproof cavity and battery compartment with waterproof coil ensure long standby and easy maintenance.

1. Locate the battery compartment at the bottom of the dispenser.
2. Open the compartment and insert 4 AA batteries, ensuring correct polarity (+/-).
3. Close the battery compartment securely.



## For Adults

Quick, hygienic cleaning with zero effort

Touchless

## Hassle-Free at Home



Figure 5: Battery compartment.

### 5.4 Filling the Dispenser

The dispenser features a 3-in-1 integrated lid-lock mechanism and a 95-degree one-piece lid to prevent liquid tipping during filling.

1. Use the provided key to unlock the top lid.
2. Pour liquid soap into the wide opening. Do not overfill.
3. Close the lid securely and lock it if desired.



## Hassle-Free at Home

### For Seniors

No pressing required, safe and effortless to use

Touchless



Figure 6: Refilling the dispenser.

## 5.5 Installation and Refill Video

Video 1: Demonstrates the installation process and how to refill the AIKE AK1205 soap dispenser.

## 6. OPERATION

### 6.1 Power On/Off

To turn the dispenser **on** or **off**, long press the power button (typically located on the top or bottom of the unit) for 5 seconds.

### 6.2 Dispensing Volume Adjustment

The dispenser offers 5 levels of liquid dispensing, from 0.5ml to 2.5ml, allowing for precise use and money-saving. The default setting is Level 2.

1. With the dispenser powered on, short press the power/adjustment button.
2. Each short press will cycle through the 5 dispensing levels. Select your desired volume.




Figure 7: 5-level dispensing adjustment.

### 6.3 Touchless Dispensing

The touchless operation is convenient and hygienic for all family members at home and for commercial use.

1. Ensure the dispenser is powered on.

2. Place your hand directly under the sensor located at the bottom of the dispenser.
3. The sensor will detect your hand and dispense the pre-set amount of liquid soap.



Figure 8: Touchless operation.

## 6.4 Basic Operation Video

Video 2: A short demonstration of the touchless dispensing function of the AIKE soap dispenser.

## 7. MAINTENANCE

### 7.1 Refilling

Refill the dispenser with liquid soap when the level is low, visible through the transparent window on the front of the unit. Follow the steps in section 5.4.

### 7.2 Cleaning

To maintain the appearance and functionality of your dispenser:

- Wipe the exterior of the dispenser with a soft, damp cloth.
- Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the stainless steel finish.
- Periodically clean the sensor area at the bottom of the dispenser to ensure optimal responsiveness.

### 7.3 Battery Replacement

Replace the 4 AA batteries when the dispenser's performance diminishes (e.g., slower dispensing, weaker motor sound) or if any low battery indicator is present. Follow the steps in section 5.3.

## 8. TROUBLESHOOTING

- **Dispenser not activating:** Check battery levels and ensure they are correctly installed. Ensure there are no obstructions blocking the sensor. Verify the dispenser is powered on.
- **Insufficient soap dispensed:** Adjust the dispensing volume setting (see section 6.2). Check the soap level and refill if necessary. If the soap is too thick, dilute it slightly with water.
- **Leaking:** Ensure the top lid is securely closed and locked. Check for any visible damage to the unit.
- **For further assistance, please contact AIKE support.**

## 9. WARRANTY & SUPPORT

---

Your AIKE Automatic Wall Mount Liquid Soap Dispenser is covered by **one-year manufacturer warranty**.

For any questions, concerns, or support needs, please contact AIKE directly via Amazon message or through their official support email. We value your experience with our products.