

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Arctic-Pro](#) /

› **MINI DESK OSCILLATING TOWER FAN Slim and Compact Size, 2-Speed, Ultra-Quiet Operation, Convenient Carrying Handle, 75 Degrees of Oscillation For Powerful Circulation, 12 Inches, Black**

Arctic-Pro 21599

Arctic-Pro Mini Desk Oscillating Tower Fan User Manual

Model: 21599

INTRODUCTION

This manual provides important information regarding the safe operation, installation, and maintenance of your Arctic-Pro Mini Desk Oscillating Tower Fan. Please read this manual thoroughly before using the product and retain it for future reference.

The Arctic-Pro Mini Desk Oscillating Tower Fan is designed to provide personal cooling with its compact size and quiet operation. It features two speed settings and a 75-degree oscillation function for effective air circulation in small spaces such as offices, bedrooms, and cubicles.





Figure 1: Arctic-Pro Mini Desk Oscillating Tower Fan, a compact black tower fan with a silver top panel.

PRODUCT FEATURES AND COMPONENTS

Familiarize yourself with the key features and components of your fan for optimal use.

- **Whisper Quiet Operation:** Engineered to produce minimal operational noise, ensuring no distractions during work or sleep.
- **Portable and Compact Design:** Features a convenient carrying handle for easy transport between rooms. Ideal for desks, nightstands, and small spaces. Dimensions: 5 x 12 inches.
- **Two Speed Settings:** Adjustable airflow from Low to High wind via electronic touch controls with LED indicators.
- **75-Degree Oscillation:** Provides wide-angle air distribution and circulation to cool your entire area effectively.
- **Electronic Touch Controls:** Intuitive controls located on the top panel for power, speed, and oscillation.

FEATURES



Figure 2: Overview of fan components, highlighting the user controls on top, the front grill, the handle on the back, and the oscillating base.

SETUP

The Arctic-Pro Mini Desk Oscillating Tower Fan requires no assembly. Simply remove it from its packaging and place it on a stable, flat surface.

1. Unpack the fan carefully from its box.
2. Place the fan on a firm, level surface, ensuring adequate space around it for air circulation and oscillation.
3. Plug the power cord into a standard electrical outlet (AC 120V, 60Hz).

AT THE OFFICE



ArcticPRO

Figure 3: The product packaging, indicating the fan is ready to use out of the box.

OPERATING INSTRUCTIONS

The fan is operated using the touch controls located on the top panel.

EASY CONTROLS



ArcticPRO

Figure 4: Detailed view of the fan's touch control panel, showing buttons for On/Off, Speed (Low/High), and Oscillation (Swing).

1. **Power On/Off:** Press the **Power button** to turn the fan on or off. An LED indicator will illuminate when the fan is on.
2. **Adjusting Speed:** Press the **Speed button** to cycle between Low and High speed settings. Corresponding LED indicators will show the selected speed.
3. **Oscillation Control:** Press the **Swing button** to activate or deactivate the 75-degree oscillation function. When active, the fan will rotate from side to side to distribute air across a wider area.

MAINTENANCE AND CARE

Regular cleaning and proper care will ensure the longevity and efficient operation of your fan.

- **Cleaning:**

- Always unplug the fan from the power outlet before cleaning.
- Use a soft, damp cloth to wipe the exterior surfaces of the fan. Do not use abrasive cleaners or solvents.
- To clean the fan grill, use a vacuum cleaner with a brush attachment to remove dust and debris. Do not

attempt to disassemble the fan for cleaning.

- **Storage:**

- If storing the fan for an extended period, clean it thoroughly and place it back in its original packaging or a suitable box.
- Store the fan in a cool, dry place, away from direct sunlight and extreme temperatures.

Note: Do not immerse the fan in water or allow water to drip into the motor housing.

TROUBLESHOOTING

If you encounter any issues with your fan, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	Not plugged in; power outlet not working; fan switch off.	Ensure the power cord is securely plugged into a working electrical outlet. Press the Power button. Test the outlet with another device.
Weak or no airflow.	Fan speed set to low; air intake/output blocked; excessive dust buildup.	Increase the fan speed using the Speed button. Ensure nothing is obstructing the front grill or rear air intake. Clean the fan grill to remove dust.
Fan is not oscillating.	Oscillation function is off.	Press the Swing button to activate the oscillation function.
Unusual noise during operation.	Fan not on a level surface; internal obstruction.	Place the fan on a stable, level surface. Unplug the fan and check for any visible obstructions in the grill. If the noise persists, discontinue use and contact customer support.

SPECIFICATIONS

Attribute	Detail
Brand	Arctic-Pro
Model Number	21599
Product Dimensions	5"D x 5"W x 12"H (12.7 cm D x 12.7 cm W x 30.48 cm H)
Color	Black
Power Source	Corded Electric
Control Method	Touch
Special Features	Oscillating, Portable, Ultra-Quiet Operation
Item Weight	2.45 Pounds (1.11 kg)
UPC	815691021599

PACKAGE



ArcticPRO

Figure 5: Dimensions of the fan, indicating a height of 12.5 inches (31.75 cm) and a base width of 5 inches (12.7 cm).

IMPORTANT SAFETY INFORMATION

Please read and follow all safety instructions to prevent injury or damage.

- Do not operate any fan with a damaged cord or plug. Discard fan or return to an authorized service facility for examination and/or repair.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Do not route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.
- To disconnect the fan, turn controls to OFF, then remove plug from outlet.
- Do not insert or allow fingers or foreign objects to enter any ventilation or exhaust opening as it may cause an electric shock or fire, or damage the fan.
- Do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- This fan is not intended for use in wet or damp locations.

- Always place the fan on a stable, flat surface during operation to prevent tipping.
- Close supervision is necessary when any appliance is used by or near children.


CUSTOMER SUPPORT

For any questions, concerns, or assistance with your Arctic-Pro Mini Desk Oscillating Tower Fan, please contact your retailer or the manufacturer's customer service. While specific warranty details are not provided in this manual, the product is backed by a 30-day full money-back guarantee from the point of purchase, as per product information.

Please retain your purchase receipt as proof of purchase for any support inquiries.

© 2023 Arctic-Pro. All rights reserved.

Related Documents - 21599

	<p><u>Dreo Tower Fan DR-HTF003 User Manual</u></p> <p>Comprehensive user manual for the Dreo Tower Fan DR-HTF003, covering safety instructions, packing details, assembly, operation, specifications, battery replacement, cleaning, storage, and warranty information.</p>
	<p><u>J.Burrows Stilford Desk Assembly Instructions Desktop & Frame</u></p> <p>Step-by-step assembly guide for the J.Burrows Stilford Desktop and S2V1 Desk Frame. Covers models in 1200mm, 1500mm, and 1800mm sizes with various finishes. Includes hardware details and assembly tips.</p>
	<p><u>Dreo Evaporative Air Cooler & Tower Fan User Manuals</u></p> <p>Comprehensive user manuals for Dreo appliances, including the Evaporative Air Cooler (Model DR-HEC001) and the Tower Fan (Model DR-HTF002). Covers safety, assembly, operation, features, troubleshooting, maintenance, and warranty for both products.</p>
	<p><u>ZKSJ Mini Slim Aquarium Wave Maker: User Manual & Warranty</u></p> <p>Comprehensive guide to ZKSJ Mini Slim 2000 and Mini Slim 3000 aquarium wave makers, covering features, installation, operation, maintenance, and warranty information.</p>
	<p><u>Dreo 42-Inch Tower Fan User Manual - Model DR-HTF005 (Pilot Pro, Cruiser Pro T2)</u></p> <p>Comprehensive user manual for the Dreo 42-inch tower fan, model DR-HTF005, including Pilot Pro and Cruiser Pro T2 variants. Covers safety instructions, assembly, operation, maintenance, troubleshooting, and warranty information.</p>

User Manual of Product 1:
Dreo 42" Tower Fan with Remote, 2023 Upgrade Smart Tower Fan, 360° Oscillating 4-in-1 Vertical Fan, LCD Display, 12W Power, 3 Speeds, 4 Modes, Standing Floor Fan for Room Home Office, 12H Timer, 30W Light, 100W Max Power, 10000 RPM, 12 Speeds, 12H Timer

User Manual of Product 2:
Dreo Tower Fan 42 Inch Pilot Max, 2023 Upgrade Smart Fan, 360° Oscillating 4-in-1 Vertical Fan, LCD Display, 12W Power, 3 Speeds, 4 Modes, Standing Floor Fan for Room Home Office, 12H Timer, 30W Light, 100W Max Power, 10000 RPM, 12 Speeds, 12H Timer

[Dreo Tower Fan User Manual - Models DR-HTF005 \(Pilot Pro\) & DR-HTF004S \(Pilot Max\)](#)

Comprehensive user manual for Dreo 42-inch Tower Fans, including models DR-HTF005 (Pilot Pro) and DR-HTF004S (Pilot Max). Covers safety instructions, assembly, operation, cleaning, troubleshooting, and warranty information.