

Keter 9727000

Keter Tall Wardrobe Plus Instruction Manual

Model: 9727000

1. PRODUCT OVERVIEW

The Keter Tall Wardrobe Plus is a versatile and durable storage solution designed for various indoor and outdoor environments such as garages, basements, hallways, attics, storage rooms, and workshops. Constructed from high-quality resin, this wardrobe offers robust storage with adjustable shelving and lockable doors for enhanced security.



Figure 1.1: Front view of the Keter Tall Wardrobe Plus.

Key Features:

- Three (3) height-adjustable shelves, each capable of holding up to 15 kg (TÜV-certified).
- Lockable doors (padlock not included) for secure storage.
- Ergonomic soft-touch handles for comfortable use.
- Quick and easy assembly with a tool-free plug-in system.

2. SAFETY INFORMATION

Please read all safety instructions carefully before assembly and use.

- Always follow the provided assembly instructions to ensure proper and safe installation.
- Do not overload the cabinet. Each shelf has a maximum weight capacity of 15 kg. Exceeding this limit may cause damage to the product or lead to injury.
- Exercise caution when using the ergonomic handles to prevent pinching or injury.

- Ensure the wardrobe is placed on a stable, level surface to prevent tipping.
- Keep small parts away from children during assembly to avoid choking hazards.

3. SETUP AND ASSEMBLY

The Keter Tall Wardrobe Plus features a quick and easy tool-free plug-in assembly system, typically taking approximately 15 minutes to complete.

Before You Begin:

1. Unpack all components and verify that all parts are present according to the packing list (refer to the included manual for the complete list).
2. Choose a clear, flat, and stable area for assembly.
3. Familiarize yourself with the different parts and their orientation.

Assembly Steps:

While specific step-by-step diagrams are provided in the physical manual, the general assembly process involves:

- Connecting the base and top panels to the side panels using the plug-in system.
- Inserting the back panels into their designated grooves.
- Attaching the doors to the main frame using the integrated hinges.
- Installing the ergonomic handles onto the doors.
- Placing the adjustable shelves at your desired heights. Ensure shelves are securely seated.





Figure 3.1: Product dimensions for planning placement. Dimensions are approximately 68 cm (width) x 39 cm (depth) x 166 cm (height).



Figure 3.2: Example of the assembled wardrobe in a garage environment.

4. OPERATING INSTRUCTIONS

Operating the Keter Tall Wardrobe Plus is straightforward.

Opening and Closing Doors:

- Grasp the ergonomic handles firmly and pull to open the doors.
- Push the doors gently until they click into place to ensure they are fully closed.

Adjusting Shelves:

- Empty the shelf before attempting to adjust its height.
- Carefully lift the shelf from its current position.
- Re-insert the shelf into the desired slots on the side panels, ensuring it is level and securely seated on all four

supports.



Figure 4.1: Interior view of the wardrobe demonstrating adjustable shelf placement and storage capacity.

5. MAINTENANCE

To ensure the longevity and optimal performance of your Keter Tall Wardrobe Plus, follow these simple maintenance guidelines:

- **Cleaning:** Wipe down the surfaces with a damp cloth and mild soap. Avoid abrasive cleaners or harsh chemicals, as these can damage the resin material.
- **Inspection:** Periodically check all connections and ensure that the doors open and close smoothly. Tighten any loose screws if applicable (though this model uses a plug-in system, check for secure connections).
- **Weight Distribution:** Distribute items evenly on shelves to prevent warping or damage. Do not exceed the 15 kg weight limit per shelf.
- **Outdoor Use:** While suitable for outdoor use, prolonged exposure to extreme weather conditions (e.g., direct,

intense sunlight or freezing temperatures) may affect the material over time. Consider placing it in a sheltered area if possible.



Figure 5.1: The wardrobe is suitable for various environments, including sheltered outdoor spaces.

6. TROUBLESHOOTING

Here are some common issues and their potential solutions:

Problem	Possible Cause	Solution
Doors do not close properly.	Wardrobe is not level; obstruction in the door path; hinges misaligned.	Ensure the wardrobe is on a flat, level surface. Check for items blocking the doors. Verify hinges are correctly installed and aligned.
Shelves sag or are unstable.	Overloaded shelf; shelf not properly seated in supports.	Reduce the weight on the shelf (do not exceed 15 kg). Re-seat the shelf, ensuring it is fully engaged in all four support slots.

Problem	Possible Cause	Solution
Cabinet feels wobbly after assembly.	Connections not fully engaged; uneven floor.	Press firmly on all connecting points to ensure they are fully clicked into place. Move the cabinet to a level surface or use shims to stabilize it.

7. SPECIFICATIONS

Detailed specifications for the Keter Tall Wardrobe Plus (Model: 9727000):

Attribute	Detail
Brand	Keter
Model Number	9727000
Product Dimensions (D x W x H)	39 cm x 68 cm x 166 cm (approx. 11.4 kg)
Material	Resin (Kunsthars)
Color	Grey
Number of Shelves	3 (adjustable)
Shelf Weight Capacity	15 kg per shelf (TÜV-certified)
Special Features	Adjustable shelf, Lockable doors (padlock not included)
Assembly Type	Floor Mount, Tool-free plug-in system
Recommended Use	Clothing, General Storage (Garage, Basement, Hallway, Attic, Storage Room, Workshop)
Country of Origin	Italy

8. WARRANTY AND SUPPORT

For information regarding warranty coverage and customer support, please refer to the purchase documentation or contact Keter customer service directly.


Return Policy:

Products purchased through Amazon.nl typically have a return policy of 30 days from the date of receipt for a refund or replacement. Please check the specific return policy at the time of purchase for the most accurate information.

For further assistance or to report any issues not covered in this manual, please visit the official Keter website or contact their customer support line.

Note: This manual provides general instructions. Always refer to the specific assembly and safety guidelines included with your product packaging.

Related Documents

	<p><u>Keter Excellence XL Multipurpose Cabinet with Cloth Hanger Assembly Instructions</u></p> <p>Comprehensive assembly instructions for the Keter Excellence XL Multipurpose Cabinet, featuring a cloth hanger. This guide provides step-by-step directions for easy and secure setup of your Keter storage solution, including a detailed parts list and safety warnings.</p>
	<p><u>Keter Stilo - Tall Assembly Instructions</u></p> <p>Step-by-step assembly instructions for the Keter Stilo - Tall cabinet, including parts list and visual guides for each assembly stage.</p>
	<p><u>Keter 511L / 135 US GAL Outdoor Storage Box Assembly and Care Guide</u></p> <p>Comprehensive assembly instructions, features, and care guide for the Keter 511L (135 US GAL) outdoor storage box. Learn how to assemble, use, and maintain your durable Keter storage solution.</p>
	<p><u>Keter STRONGHOLD Shed User Manual: Assembly and Care Guide</u></p> <p>Comprehensive user manual for the Keter STRONGHOLD shed, covering assembly instructions, site preparation, parts identification, and care guidelines for models 10x8, 10x11.5, and 10x15.</p>