

[Manuals.plus](#) /

› [iLive Electronics](#) /

› iLive Platinum Wireless Under Cabinet Speaker with Amazon Alexa (Model IKBV378S) - Instruction Manual

iLive Electronics IKBV378S

iLive Platinum Wireless Under Cabinet Speaker with Amazon Alexa (Model IKBV378S) - Instruction Manual

Your guide to setting up and using your iLive Platinum Wireless Under Cabinet Speaker.

INTRODUCTION

The iLive Platinum Wireless Under Cabinet Speaker with Amazon Alexa is designed to provide audio entertainment and smart assistant functionality in your kitchen or other suitable areas. This speaker integrates Amazon Alexa for hands-free control, allowing you to set timers, manage smart appliances, find recipes, and more. It supports multi-room audio via Wi-Fi, Bluetooth wireless connectivity, and includes a built-in microphone for voice commands.

Key Features:

- Wireless speaker functionality
- Voice-activated Amazon Alexa integration
- Bluetooth wireless connectivity
- Built-in Wi-Fi, Wi-Fi Direct, and multi-room play capabilities
- Integrated microphone for voice commands

WHAT'S IN THE BOX

Upon unpacking, please ensure all items listed below are present:

- iLive Platinum Wireless Under Cabinet Speaker
- Mounting hardware
- AC/DC power adapter
- Built-in microphone (integrated)

SETUP

Mounting the Speaker:

The iLive Platinum speaker is designed for under-cabinet installation. Use the provided mounting hardware to securely attach the

speaker to the underside of a cabinet. Ensure the mounting surface is sturdy enough to support the speaker's weight (approximately 2.5 pounds).



Image: The iLive Platinum Wireless Under Cabinet Speaker securely mounted beneath a light-colored kitchen cabinet, showcasing its discreet placement.

Power Connection:

Connect the supplied AC/DC power adapter to the 'DC IN' port on the back of the speaker. Plug the adapter into a standard electrical outlet. This device operates on corded electric power.



Image: A close-up of the rear of the iLive Platinum speaker, highlighting the 'DC IN' port for power connection.

Initial Power On:

Once powered, the speaker's display will illuminate. Follow the on-screen prompts or refer to the operating instructions for initial setup, including time setting and network configuration.

OPERATING INSTRUCTIONS

The iLive Platinum speaker features an intuitive control panel for easy operation. Below are instructions for common functions:



Image: A detailed view of the iLive Platinum speaker's front control panel, showing various buttons for power, source, volume, and display.

Power On/Off:

- Press the **Power** button (usually marked with a circle and vertical line) to turn the unit on or off.

Source Selection:

- Press the **Source** button repeatedly to cycle through available audio sources: Bluetooth, FM Radio, and Aux Input.

Volume Control:

- Use the **Volume +** and **Volume -** buttons to adjust the audio output level.

Bluetooth Pairing:

- Select **Bluetooth** as the source. The Bluetooth indicator will flash.
- On your mobile device, enable Bluetooth and select 'iLive Platinum' from the list of available devices to pair.

Wi-Fi and Multi-Room Play:

- Refer to the dedicated Wi-Fi setup guide (if provided separately) or the device's on-screen instructions for connecting to your home Wi-Fi network and configuring multi-room audio with compatible iLive speakers.

Amazon Alexa Voice Control:

- Once connected to Wi-Fi and linked to your Amazon account, simply say "Alexa" followed by your command. The built-in microphone will capture your voice.

Timer and Alarm Functions:

- Use the **Timer** and **Alarm Set** buttons to configure countdown timers or set alarms. Follow the display prompts for setting specific times.

MAINTENANCE

Cleaning:

To maintain the appearance and functionality of your speaker, regularly wipe the exterior with a soft, dry cloth. Avoid using abrasive cleaners, waxes, or solvents as they may damage the finish. Ensure the device is powered off and unplugged before cleaning.

Storage:

If storing the speaker for an extended period, ensure it is clean, dry, and stored in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

If you encounter issues with your iLive Platinum speaker, please consult the following common solutions:

- **No Power:** Ensure the AC/DC power adapter is securely connected to both the speaker and a working electrical outlet.
- **No Sound:** Check the volume level on both the speaker and your connected device (if using Bluetooth or Aux). Ensure the correct audio source is selected.
- **Bluetooth Connectivity Issues:** Make sure the speaker is in Bluetooth pairing mode and within range of your device. Try unpairing and re-pairing the device.
- **Wi-Fi/Alexa Issues:** Verify your Wi-Fi network is active and the speaker is connected. Check your internet connection. For Alexa-specific issues, consult the Amazon Alexa app or support resources.
- **Poor FM Radio Reception:** Extend or reposition the FM antenna for better signal reception.

If problems persist after attempting these steps, please contact iLive customer support for further assistance.

SPECIFICATIONS

Feature	Detail
Model Name	Platinum Under Cabinet Speaker
Item Model Number	IKBFV378S
Brand	iLive Electronics
Connectivity Technology	Bluetooth, Wi-Fi
Wireless Communication Technology	Bluetooth, Wi-Fi
Special Feature	Radio, Voice-activated Alexa
Control Method	Voice
Speaker Type	Multi Room
Audio Output Mode	Stereo
Speaker Maximum Output Power	60 Watts
Power Source	Corded Electric
Item Weight	2.5 Pounds
Product Dimensions	10.69 x 9.61 x 3.44 inches
Mounting Type	Under Cabinet
UPC	047323378003

WARRANTY AND SUPPORT

This iLive Platinum Wireless Under Cabinet Speaker comes with a limited warranty. For detailed information regarding warranty coverage, terms, and conditions, please refer to the warranty card included in your product packaging or visit the official iLive Electronics website. For technical support, troubleshooting assistance, or service inquiries, please contact iLive customer service through their official channels.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question