

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [K-Tech](#) /

> [K-Tech Wireless Mini Speaker A5 User Manual](#)

## K-Tech A5

# K-Tech Wireless Mini Speaker A5 User Manual

Model: A5 | Brand: K-Tech

## INTRODUCTION

This manual provides comprehensive instructions for the K-Tech Wireless Mini Speaker A5. Please read this document thoroughly to ensure proper setup, operation, and maintenance of your device. This speaker is designed for portable audio amplification via a 3.5mm auxiliary connection.

## PACKAGE CONTENTS

- 1 x K-Tech Mini Portable Speaker (Model A5)
- 1 x Micro USB Charging Cable
- 1 x English User Manual (this document)

## PRODUCT OVERVIEW

Familiarize yourself with the components and features of your K-Tech Mini Speaker.



**ON/OFF**

**3.5mm Audio Jack**

Suitable for Android Phones, iPhone, Notebook/Laptop Computer, Tablet/Pad, MP3/MP4, PSP, or any device with 3.5mm headphone jack.

**Micro USB Charging Port**

Built-in rechargeable battery  
Full charging time only need 45mins,  
and playing time up to 8 hours.

**Figure 1: Speaker Components** - This image highlights the ON/OFF switch on the bottom, the 3.5mm audio jack for connecting to devices, and the Micro USB charging port.

## Wireless Concept, Compact and Neat



**Figure 2: Speaker Dimensions and Indicators** - The speaker measures 1.8 inches in depth, 1.8 inches in width, and 1.3 inches in height. It features a red LED for charging status and a blue LED to indicate active use.

## SETUP

- 1. Charge the Speaker:** Before first use, fully charge the speaker using the provided Micro USB cable. Refer to the "Charging the Speaker" section for details.
- 2. Power On:** Locate the ON/OFF switch on the bottom of the speaker (refer to Figure 1) and slide it to the "ON" position. A blue LED will illuminate, indicating the speaker is active.
- 3. Connect to Device:** Insert the 3.5mm audio jack of the speaker into the headphone or auxiliary port of your audio device

(e.g., smartphone, tablet, laptop, MP3 player).



**Figure 3: 3.5mm Audio Jack Compatibility** - The speaker connects to any device with a standard 3.5mm audio output, including various portable media players and computing devices.

## OPERATING INSTRUCTIONS

1. **Power On/Off:** Use the ON/OFF switch on the bottom of the speaker to turn it on or off.
2. **Play Audio:** Once connected to your device, begin playing audio from your device. The sound will be amplified through the K-Tech Mini Speaker.
3. **Adjust Volume:** The speaker does not have its own volume controls. Adjust the volume directly on your connected audio device.
4. **Usage Scenarios:** The speaker is suitable for enhancing audio during video watching, music listening, gaming, conference calls, and online classes.



**Figure 4: Versatile Use Cases** - The K-Tech Mini Speaker can be used to amplify audio from various devices in different settings, such as listening to music on a phone, enhancing game audio, improving video call sound on a tablet, or boosting laptop audio.

# 4 Times Louder Sound Than Your Cell Phones /Tablets



**Figure 5: Enhanced Audio Output** - The speaker is designed to provide up to four times louder sound compared to the built-in speakers of most cell phones and tablets.

## CHARGING THE SPEAKER

---

The K-Tech Mini Speaker has a built-in rechargeable battery. Follow these steps to charge it:

1. Connect the Micro USB end of the charging cable to the Micro USB Charging Port on the speaker (refer to Figure 1).
2. Connect the standard USB end of the charging cable to a USB power source (e.g., computer USB port, USB wall adapter).
3. The red LED indicator will illuminate during charging.
4. Once fully charged (approximately 45 minutes), the red LED will turn off or change color (depending on the specific unit).
5. A full charge provides up to 8 hours of playing time.

## MAINTENANCE

---

- Keep the speaker dry. Do not expose it to water or excessive moisture.
- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Store the speaker in a cool, dry place when not in use.
- Avoid dropping the speaker or subjecting it to strong impacts.
- Ensure the power switch is in the "OFF" position when storing to prevent battery drain.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound from speaker	Speaker is off. Battery is drained. Audio jack not fully inserted. Device volume is too low. Device output issue.	Ensure speaker is ON. Charge the speaker. Re-insert the 3.5mm audio jack firmly. Increase volume on the connected device. Test with another audio device.
Low volume	Device volume is too low. Speaker battery is low.	Increase volume on the connected device. Charge the speaker.
Speaker not charging	Charging cable faulty. USB power source faulty. Charging port damaged.	Try a different Micro USB cable. Try a different USB power source. Contact customer support if port is damaged.
Blue LED not lighting up	Speaker is off. Battery is drained.	Ensure speaker is ON. Charge the speaker.

## SPECIFICATIONS

Model Name	A5
Brand	K-Tech
Output Power	3 Watts
Frequency Response	50Hz-18KHz
Signal-to-Noise Ratio	80 dB
Product Dimensions (L x W x H)	1.8" x 1.8" x 1.3"
Battery Life	Up to 8 hours
Charging Time	Approximately 45 minutes
Connectivity	3.5mm Auxiliary Jack, Micro USB for charging
Material	Plastic
Item Weight	2.99 ounces

## WARRANTY AND SUPPORT

The K-Tech Wireless Mini Speaker A5 comes with a **1-Year Free Warranty**. K-Tech also provides lifetime technical support for this product.

For warranty claims, technical assistance, or any product-related inquiries, please contact K-Tech customer support through the retailer where the product was purchased or refer to the contact information provided on the product packaging.



© 2023 K-Tech. All rights reserved.