

Hermitshell Hard Travel Case

Hermitshell Hard Travel Case for Tronsmart Mega Bluetooth Speaker

Instruction Manual

INTRODUCTION

This manual provides instructions for the proper use and care of your Hermitshell Hard Travel Case. This case is specifically designed to provide robust protection for the Tronsmart Mega Bluetooth 4.2 40W Bluetooth Speaker, safeguarding it from impacts, scratches, and dust during transport and storage. Please read this manual thoroughly to ensure optimal protection for your device.

SETUP AND DEVICE PLACEMENT

To ensure your Tronsmart Mega Bluetooth Speaker is securely protected, follow these steps for proper placement within the Hermitshell Hard Travel Case:

1. **Open the Case:** Unzip the case completely using the dual zippers to fully open both halves.
2. **Insert Speaker:** Carefully place your Tronsmart Mega Bluetooth Speaker into the main compartment of the case. The case is custom-fitted to hold the speaker snugly.
3. **Store Accessories:** Utilize the internal mesh pocket located in the lid of the case to store small accessories such as charging cables or adapters. Ensure items are placed securely within the mesh to prevent them from shifting and potentially scratching the speaker.
4. **Close the Case:** Gently close the case and secure it by zipping both zippers fully. Ensure no fabric or items are caught in the zipper teeth.



Image: The empty Hermitshell case, open to reveal the custom-fitted compartment for the speaker and the mesh pocket for accessories.



Image: The Hermitshell case with a Tronsmart Mega speaker and its charging cables neatly stored inside.

OPERATING INSTRUCTIONS

The Hermitshell Hard Travel Case is designed for portability and protection. Once your speaker and accessories are securely placed inside, the case can be easily transported.

- **Carrying:** Use the integrated handle for comfortable and secure carrying.
- **Storage:** Store the case in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Protection:** The hard EVA material provides a protective barrier against impacts, dents, and scratches. Always ensure the case is fully zipped to maintain its protective integrity.



Image: A hand demonstrating how to carry the Hermitshell case using its sturdy handle.



Image: The Hermitshell case in its closed state, highlighting its compact and protective design.

CARE AND MAINTENANCE

To maintain the condition and effectiveness of your Hermitshell Hard Travel Case, please follow these care instructions:

- **Cleaning:** Wipe the exterior of the case with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used, followed by wiping with a clean, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Drying:** Allow the case to air dry completely before closing or storing. Do not expose to direct heat sources.
- **Zipper Care:** Periodically check the zippers for any debris. If zippers become stiff, a small amount of zipper lubricant can be applied.
- **Avoid Overfilling:** Do not attempt to force items into the case that exceed its capacity, as this can damage the case or its contents.

TROUBLESHOOTING

If you encounter any issues with your Hermitshell Hard Travel Case, refer to the following common solutions:

- **Speaker Does Not Fit:** Ensure you are using the correct model of speaker (Tronsmart Mega Bluetooth 4.2 40W Bluetooth Speaker). This case is custom-designed for this specific model. Verify the internal dimensions (8.1 x 3.4 x 2.4 inches) against your speaker's dimensions.

- **Zipper Difficulty:** Check for any fabric, cables, or other obstructions caught in the zipper teeth. Gently clear any blockages. Avoid forcing the zipper, as this can cause damage.
- **Case Deformed:** The case is designed to be rigid. If it appears deformed, ensure no heavy objects have been placed on it for extended periods, especially in high temperatures.

PRODUCT SPECIFICATIONS

Feature	Detail
Product Type	Hard Travel Storage Carrying Case
Compatibility	Tronsmart Mega Bluetooth 4.2 40W Bluetooth Speaker
Material	EVA (Ethylene-vinyl acetate)
Color	Black
External Dimensions	8.74 x 5.79 x 3.39 inches (Package Dimensions)
Internal Dimensions	8.1 x 3.4 x 2.4 inches
Item Weight	7.6 ounces
Shell Type	Hard



Image: A visual representation of the case's external dimensions.

WARRANTY AND SUPPORT

For any questions regarding your Hermitshell Hard Travel Case, or for support concerning potential defects, please contact the manufacturer or the seller directly through your purchase platform. Please retain your proof of purchase for any warranty claims.