

[Manuals.plus](#) /

> [Panasonic](#) /

> Panasonic SC-UA30 Speaker 300W Black - Speakers (2-way, Wired & Wireless, USB/Bluetooth, 300W, 75 Ohm, Black) User Manual

Panasonic SC-UA30E-K

Panasonic SC-UA30 Urban Audio System User Manual

Model: SC-UA30E-K

1. INTRODUCTION

Thank you for purchasing the Panasonic SC-UA30 Urban Audio System. This powerful speaker is designed to deliver rich, clear sound for various audio sources, including Bluetooth, USB, AUX, and FM radio. Please read this manual carefully before using the unit to ensure proper operation and to maximize your listening experience. Keep this manual for future reference.

2. SAFETY INFORMATION

Always observe the following safety precautions to prevent electric shock, injury, or damage to the unit.

- **Power Source:** Connect the unit only to an AC power outlet of the specified voltage.
- **Ventilation:** Ensure adequate ventilation. Do not block ventilation openings.
- **Water and Moisture:** Do not expose the unit to rain, moisture, or dripping/splashing liquids. Do not place objects filled with liquids on the unit.
- **Heat:** Keep the unit away from heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- **Cleaning:** Unplug the unit from the power outlet before cleaning. Use a dry cloth only.
- **Servicing:** Do not attempt to service this unit yourself. Refer all servicing to qualified service personnel.

3. PACKAGE CONTENTS

Please check that all the following items are included in the package:


- Panasonic SC-UA30 Urban Audio System (Main Unit)
- AC Power Cord
- FM Indoor Antenna

- Remote Control (with batteries)
- Operating Instructions (this manual)

4. SETUP

4.1. Placement

Place the unit on a flat, stable surface. For optimal sound dispersion, position the speaker in a central location within the room. Avoid placing it near walls or corners that might obstruct the side-emitting speakers.



The Panasonic SC-UA30 speaker can be easily placed in various settings, including outdoor areas like balconies, to provide powerful audio.

4.2. Power Connection

1. Connect the supplied AC power cord to the AC IN terminal on the rear of the unit.
2. Plug the other end of the power cord into a wall outlet.

4.3. Connecting Audio Sources

The SC-UA30 offers multiple connectivity options for your audio devices.

4.3.1. Bluetooth Connection

Pair your smartphone, tablet, or other Bluetooth-enabled device with the SC-UA30 for wireless audio streaming.



The Bluetooth logo signifies the wireless connectivity capability of the speaker.

4.3.2. USB Playback

Insert a USB flash drive containing audio files into the USB port on the unit.

4.3.3. AUX Input

Connect external audio devices (e.g., MP3 players, TVs) using a 3.5mm audio cable to the AUX IN port.

4.3.4. FM Radio Antenna

Connect the supplied FM indoor antenna to the FM ANT terminal for radio reception.

5. OPERATING INSTRUCTIONS

5.1. Basic Controls

- **Power On/Off:** Press the **[POWER]** button on the unit or remote control.
- **Volume Adjustment:** Use the **[VOLUME +/-]** buttons on the unit or remote control.
- **Input Selection:** Press the **[FUNCTION]** button repeatedly to cycle through Bluetooth, USB, AUX, and FM radio inputs.



Front view of the Panasonic SC-UA30, highlighting the speaker configuration and accessible control panel.



Angled view of the SC-UA30, illustrating its design and integrated handles for easy transport.



Side profile of the SC-UA30, demonstrating its vertical design.

5.2. Bluetooth Pairing

1. Turn on the SC-UA30 and select the Bluetooth function. The Bluetooth indicator will flash.
2. Enable Bluetooth on your smart device and search for available devices.

3. Select "SC-UA30" from the list of devices.
4. Once paired, the Bluetooth indicator will glow steadily. You can now stream audio wirelessly.

5.3. USB Playback

1. Insert a USB flash drive into the USB port.
2. Select the USB function. The unit will automatically begin playing compatible audio files.
3. Use the **[PLAY/PAUSE]**, **[SKIP]**, and **[STOP]** buttons to control playback.

5.4. FM Radio Tuning

1. Select the FM radio function.
2. Press the **[TUNE +/-]** buttons to manually tune to a station or press and hold to auto-scan for the next available station.

5.5. Karaoke Function

The SC-UA30 supports karaoke. Connect a microphone (not supplied) to the microphone input jack. Adjust the microphone volume and echo effects using the dedicated controls on the unit or remote control.



The SC-UA30 is suitable for social gatherings, providing entertainment for groups.



The speaker's design ensures sound fills the room, as depicted by the sound wave illustration.

6. MAINTENANCE

6.1. Cleaning

To maintain the appearance of your unit, wipe it with a soft, dry cloth. Do not use abrasive cloths, thinners, alcohol, or other chemical cleaning agents, as these may damage the finish.

6.2. Storage

If you do not plan to use the unit for an extended period, unplug it from the power outlet and store it in a cool, dry place, away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

If you experience issues with your SC-UA30, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
No power	Power cord not connected securely.	Ensure the power cord is firmly plugged into the unit and the wall outlet.
No sound	Volume is too low or muted. Incorrect input selected.	Increase the volume. Press the FUNCTION button to select the correct input source.
Bluetooth pairing fails	Device is out of range. Bluetooth is not enabled on your device.	Move the device closer to the speaker. Ensure Bluetooth is enabled on your device and try pairing again.
USB playback not working	USB drive is not formatted correctly or contains unsupported files.	Ensure the USB drive is formatted to FAT16 or FAT32. Check if audio files are in a supported format (e.g., MP3).

8. SPECIFICATIONS

Feature	Specification
Model Number	SC-UA30E-K
Brand	Panasonic
Speaker Output Power	300 Watts (Maximum)
Connectivity Technology	Auxiliary, Bluetooth
Audio Output Mode	Stereo
Speaker Type	Tweeter
Special Features	Bluetooth
Recommended Uses	Music
Compatible Devices	Laptop, Smartphone, Tablet
Color	Black
Item Weight	8 Kilograms
USB Ports	1

9. WARRANTY AND SUPPORT

This product is covered by Panasonic's standard warranty. Please refer to the warranty card included in your package or visit the official Panasonic website for detailed warranty terms and conditions specific to your region. For technical support, troubleshooting assistance, or service inquiries, please contact Panasonic customer support through their official website or the contact information provided in your product documentation.

Website: www.panasonic.com