**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## ICE-WATCH 016030

# ICE-WATCH ICE steel Black Watch 016030 User Manual

### Introduction

Thank you for choosing the ICE-WATCH ICE steel Black watch, model 016030. This manual provides essential information and instructions to help you understand, operate, and maintain your new timepiece. Please read this manual carefully before using your watch to ensure proper function and longevity.

The ICE steel Black watch is designed for durability and style, featuring a robust stainless steel case, a deep black dial, and a comfortable silicone strap. It is equipped with a reliable quartz movement and offers water resistance suitable for swimming and diving.






Front view of the ICE-WATCH ICE steel Black watch, showcasing the black dial, silver-tone case, and black silicone strap.

## Setup

### Setting the Time and Date

1. **Pull out the crown:** Gently pull the crown (located on the right side of the watch case) to position 2 for setting the date, or position 3 for setting the time.
2. **Set the time:** Rotate the crown in position 3 to move the hour and minute hands. Set the time to the current hour and minute. Ensure you differentiate between AM and PM if your watch has a date function that changes at midnight.
3. **Set the date:** If your watch has a date display, push the crown back to position 2. Rotate the crown to adjust the date. Avoid setting the date between 9 PM and 3 AM, as this can damage the movement.
4. **Push in the crown:** Once the time and date are set, push the crown back into position 1 (normal operating position) to start the watch and ensure water resistance.




Side view of the ICE-WATCH ICE steel Black watch, highlighting the crown for time and date adjustments.

## Operating

### Using the Unidirectional Rotating Bezel

Your ICE steel Black watch features a unidirectional rotating bezel, commonly used for timing events, especially in diving. The bezel rotates only counter-clockwise to prevent accidental increases in timed duration, which is a safety feature for divers.

1. **Align the bezel:** Rotate the bezel so that the zero mark (triangle or dot) aligns with the minute hand.
2. **Read elapsed time:** The minute hand will then indicate the elapsed time against the bezel's scale.

### Water Resistance

This watch is water resistant up to 100 meters (10 ATM), making it suitable for swimming, snorkeling, and recreational diving. Ensure the crown is fully pushed in before any contact with water to maintain water resistance. Do not operate the crown or pushers while the watch is wet or submerged.



Rear view of the ICE-WATCH ICE steel Black watch, displaying the stainless steel case back with water resistance rating and model information.

## Maintenance

### Cleaning Your Watch

- **Case and Crystal:** Wipe the watch case and crystal with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used, followed by rinsing with clean water and drying thoroughly.
- **Silicone Strap:** The silicone strap can be cleaned with mild soap and water. Rinse well and dry completely to prevent skin irritation or material degradation.

### Battery Replacement

Your watch is powered by a quartz movement, which requires a battery. When the watch stops or the second hand begins to jump erratically (indicating a low battery), it is time for a replacement. Battery replacement should be performed by a qualified watch technician to ensure the watch's water resistance is maintained.

### Water Resistance Care


- Always ensure the crown is fully pushed in before exposing the watch to water.
- Avoid operating the crown or pushers while the watch is submerged or wet.
- After exposure to saltwater, rinse the watch with fresh water and dry it thoroughly.
- Water resistance is not a permanent condition and may be affected by the aging of gaskets or accidental shocks to the crown. It is recommended to have the water resistance checked periodically by a professional.

## Troubleshooting

- **Watch not running:** Check if the crown is fully pushed in. If it is, the battery may need replacement.
- **Date not changing at midnight:** The time may be set to AM instead of PM. Advance the time by 12 hours.
- **Condensation under the crystal:** This indicates a loss of water resistance. Avoid further contact with water and have the watch inspected by a professional immediately.
- **Inaccurate timekeeping:** While quartz movements are highly accurate, significant deviations may indicate a low battery or a need for servicing.

## Specifications

| Feature | Detail |
|---|---|
| Model Number | 016030 |
| Watch Movement Type | Quartz |
| Power Source | Battery Powered |
| Water Resistance Depth | 100 Meters (10 ATM) |
| Sport Type | Swimming, Diving |
| Clasp Type | Buckle |
| Band Material Type | Silicone |
| Case Material Type | Stainless Steel |
| Dial Window Material Type | Mineral |
| Case Diameter | 40 Millimeters |
| Band Width | 20 Millimeters |
| Case Thickness | 11 Millimeters |
| Item Weight | 80 Grams |




An illustration detailing the different sizes available for ICE-WATCH models. The 016030 model has a 40mm case diameter, corresponding to a Medium (M) size.

## Warranty Information

ICE-WATCH products are manufactured to the highest quality standards and are covered by a limited warranty against manufacturing defects. The warranty period typically begins from the date of purchase. Please refer to the warranty card included with your watch for specific terms, conditions, and duration. The warranty generally covers the watch movement, hands, and dial. It does not cover the case, crystal, strap, or battery, nor does it cover damage resulting from improper handling, lack of care, accidents, or normal wear and tear.

## Support

For further assistance, service, or warranty claims, please contact ICE-WATCH customer support or visit the official ICE-WATCH website. You can find contact details and service center locations on the brand's official website or in the documentation provided with your purchase.

- **Official Website:** www.ice-watch.com
- **Customer Service:** Refer to your warranty card or the official website for regional contact information.

© 2023 ICE-WATCH. All rights reserved. This manual is for informational purposes only.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B07DCZ5SHL**

More documents and user manuals: **https://manuals.plus/**