

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [ZVOX](#) /
- › [ZVOX AccuVoice AV203 TV Speaker Instruction Manual](#)

ZVOX AV203 TV Speaker

ZVOX AccuVoice AV203 TV Speaker Instruction Manual

Model: AV203 TV Speaker | Brand: ZVOX

INTRODUCTION

The ZVOX AccuVoice AV203 TV Speaker is designed to significantly enhance dialogue clarity in television programs, movies, and other audio content. Utilizing patented hearing aid technology, this sound bar provides six levels of voice boost, ensuring every word is clear and easy to understand, even at low volumes. It also features PhaseCue virtual surround sound for a room-filling audio experience and Output Levelling to manage sudden volume changes.



Front view of the ZVOX AccuVoice AV203 TV Speaker, displaying 'AC 6' on its digital screen, indicating AccuVoice level 6 is active.

This manual provides detailed instructions for setting up, operating, and maintaining your AV203 TV Speaker, along with troubleshooting tips and product specifications.

SETUP AND INSTALLATION

What's in the Box

- ZVOX AccuVoice AV203 TV Speaker
- Remote Control
- Connecting Cables (Power cable, Optical audio cable)

Connecting Your AV203 TV Speaker

1. **Placement:** Position the AV203 TV Speaker directly in front of your television, ensuring it does not block the TV's remote sensor.
2. **Audio Connection:** Connect the supplied optical audio cable from the 'Optical Out' port on your TV to the 'Optical In' port on the AV203. If your TV does not have an optical output, use an analog audio cable (not included) to connect from your TV's 'Audio Out' (RCA or headphone jack) to the AV203's 'Analog In' port.
3. **Power Connection:** Plug the power adapter into the AV203's power input, then plug the other end into a wall outlet. The speaker will automatically turn on.
4. **TV Audio Settings:** Access your TV's audio settings menu and select the appropriate audio output (e.g., 'External Speakers' or 'Optical Out'). You may also need to disable your TV's internal speakers.



The ZVOX AV203 TV Speaker positioned below a television, demonstrating typical placement for optimal sound delivery.

OPERATING INSTRUCTIONS

Remote Control Functions




The ZVOX remote control, featuring clearly labeled buttons for easy operation of the sound bar's functions.

- **POWER:** Turns the AV203 on or off.
- **INPUT:** Cycles through available audio inputs (Optical, Analog).
- **ACCUVOICE:** Activates and adjusts the AccuVoice dialogue clarity feature. Press repeatedly to cycle through six levels of voice boost (AC 1 to AC 6).
- **SURROUND:** Toggles the PhaseCue virtual surround sound feature on or off.
- **MUTE:** Mutes or unmutes the audio output.
- **VOLUME (+/-):** Increases or decreases the overall volume level.
- **OTHER SETTINGS (PS):** Accesses advanced settings (refer to the full user manual for details).

AccuVoice Dialogue Clarity

The AV203 features ZVOX's patented AccuVoice technology, which uses a digital processor to lift voices out of background sounds, making dialogue exceptionally clear. There are six levels of AccuVoice boost. Press the **ACCUVOICE** button on the remote to increase the level. Each press will display the current level (AC 1 to AC 6) on the front panel. Experiment with different levels to find the one that best suits your hearing preference.



An illustration highlighting the benefit of AccuVoice technology, allowing users to hear dialogue clearly without needing subtitles.

PhaseCue Virtual Surround Sound

The PhaseCue feature creates a room-filling 3D sound experience from a single speaker cabinet. Press the **SURROUND** button on the remote to toggle this effect on or off. When active, the sound will appear to come from a wider area, enhancing immersion.

Output Levelling (OL)

Output Levelling automatically tames loud commercials and sudden volume spikes between channels or during program changes. This feature helps maintain a consistent listening volume, preventing jarring loud sounds.

MAINTENANCE

To ensure the longevity and optimal performance of your ZVOX AccuVoice AV203 TV Speaker, follow these simple maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the exterior of the speaker. Avoid using liquid cleaners, aerosols, or abrasive materials, as these can damage the finish or internal components.
- **Ventilation:** Ensure the speaker's vents are not obstructed to allow for proper airflow and prevent overheating.
- **Environment:** Keep the speaker away from direct sunlight, heat sources, and excessive moisture.
- **Remote Control:** Replace the remote control battery (1 12V battery) when its performance diminishes.

TROUBLESHOOTING

If you encounter issues with your AV203 TV Speaker, please refer to the following common problems and

solutions:

Problem	Possible Cause	Solution
No sound from the AV203.	<ul style="list-style-type: none">• Speaker is off or muted.• Incorrect input selected.• TV audio output settings are incorrect.• Loose audio cable connection.	<ul style="list-style-type: none">• Ensure the speaker is powered on and not muted.• Press the INPUT button on the remote to cycle through inputs.• Check your TV's audio settings to ensure external speakers or optical output is selected.• Verify all audio cables are securely connected.
Sound is distorted or unclear.	<ul style="list-style-type: none">• Volume too high.• Poor audio source quality.• AccuVoice level too high for some content.	<ul style="list-style-type: none">• Reduce the volume.• Try a different audio source to determine if the issue is with the source.• Adjust the ACCUVOICE level to a lower setting.
Remote control not working.	<ul style="list-style-type: none">• Battery is dead or inserted incorrectly.• Obstruction between remote and speaker.	<ul style="list-style-type: none">• Replace the remote control battery (1 12V battery) and ensure correct polarity.• Remove any objects blocking the line of sight between the remote and the speaker's front panel.
TV speakers are still playing.	TV internal speakers are not disabled.	Access your TV's audio settings menu and disable the internal speakers.

SPECIFICATIONS

Feature	Detail
Model Name	AV203
Speaker Type	Soundbar
Recommended Uses	Television audio enhancement, dialogue clarification
Compatible Devices	Television
Surround Sound Channel Configuration	2.0
Color	Black
Included Components	Remote control, connecting cables
Product Dimensions	7.75"D x 19.5"W x 4"H
Item Weight	5 Pounds

Feature	Detail
Control Method	Remote
Power Source	Corded Electric
Number of Power Levels (AccuVoice)	6
Speaker Maximum Output Power	25 Watts
Connectivity Technology	Optical
Audio Output Mode	Surround
Mounting Type	Bar Mount
UPC	882360020313

WARRANTY INFORMATION

The ZVOX AccuVoice AV203 TV Speaker comes with a **Limited Warranty**. For specific details regarding the duration and terms of your warranty, please refer to the warranty card included with your product packaging or visit the official ZVOX website. Keep your proof of purchase for warranty claims.

CUSTOMER SUPPORT

For further assistance, technical support, or to inquire about replacement parts, please contact ZVOX customer service. You can find contact information and additional resources on the official ZVOX website:

[Visit ZVOX Official Website](#)