



[Manuals.plus](#) /

› [HOOTEK](#) /

› [HOOTEK 3-Port USB Wall Charger \(Model PT-WC-20\) Instruction Manual](#)

HOOTEK PT-WC-20

HOOTEK 3-Port USB Wall Charger (Model PT-WC-20) Instruction Manual

Your guide to safe and efficient charging.

1. INTRODUCTION

Thank you for choosing the HOOTEK 3-Port USB Wall Charger. This device is designed to provide efficient and safe charging for multiple electronic devices simultaneously. Its compact design makes it ideal for both home use and travel. Please read this manual carefully to ensure proper usage and to maximize the lifespan of your charger.



Image 1: Two HOOTEK 3-Port USB Wall Chargers, showcasing their compact design and multiple USB ports.

2. PACKAGE CONTENTS

Upon opening your package, you should find the following items:

- 2 x HOOTEK 3-Port USB Wall Chargers (Model PT-WC-20)

3. PRODUCT FEATURES

- **Multi-Port Charging:** Equipped with three USB output ports, allowing you to charge up to three devices simultaneously.
- **High Output:** Provides a total output of 5V/3.1A, enabling efficient charging for various devices.
- **Compact and Portable Design:** Small dimensions (approximately 1.8 × 1.5 × 1.2 inches) make it easy to carry and store, ideal for travel.
- **Universal Voltage Input:** Supports AC100-240V input, suitable for international travel.
- **Advanced Safety Protection:** Features intelligent circuit design to protect against over-heating, over-currents, over-charging, and short-circuiting.

Portable Small Size Ideal For Travel



Image 2: The HOOTEK 3-Port USB Wall Charger, illustrating its compact size and dimensions (1.8 x 1.5 x 1.2 inches).

4. SETUP INSTRUCTIONS

1. **Unpack:** Carefully remove the HOOTEK 3-Port USB Wall Charger from its packaging.
2. **Inspect:** Check the charger for any visible damage. Do not use if damaged.
3. **Plug In:** Insert the charger into a standard AC wall outlet (100-240V).
4. **Connect Devices:** Use appropriate USB charging cables (not included) to connect your devices to the USB ports on the charger.

5. OPERATING INSTRUCTIONS

The HOOTEK 3-Port USB Wall Charger is designed for simple plug-and-play operation.

- Once plugged into a power outlet, the charger is ready to use.
- Connect your USB-powered devices (smartphones, tablets, e-readers, etc.) to any of the three available USB ports using their respective charging cables.
- The charger will automatically detect your device and begin charging.

- You can charge one, two, or three devices simultaneously. The total 3.1A output will be distributed among the connected devices.
- When charging is complete, disconnect your devices and unplug the charger from the wall outlet.



Image 3: The HOOTEK 3-Port USB Wall Charger in use, demonstrating simultaneous charging of two smartphones.

6. COMPATIBILITY

This charger is widely compatible with most USB-powered devices, including but not limited to:

- **Apple Devices:** iPhone (17/17 Pro/17 Pro Max/17 Air, 16/16 Pro/16 Pro Max/16 Plus, 15/15 Pro/15 Pro Max/15 Plus, 14/14 Pro/14 Pro Max, 13 Pro Max/13 Pro/13 mini, 12 Pro Max/12 Pro/12 mini/12, 11/11 Pro/11 Pro Max, XR/XS/XS MAX/X/8 Plus/SE), iPad Pro/Mini/Air.
- **Samsung Galaxy Devices:** S Series (S25/S25 Ultra/S25+, S24/S24 Ultra, S23 Ultra/S23+/S23, S22 Ultra 5G/S22+/S22, S21 FE/S21 Ultra/S21+/S21, S20 FE/S20/S10e/S10/S9/S8/S8+/S7/S6 Edge), A Series (A17 A16 A15 A55 A35 A90 A80 A72 A71 A70 A52s A52 A51 A50 A40 A32 A30 A20 A13 A20e A10e), Note Series (Note20 Ultra 5G).
- **Google Pixel Devices:** Pixel (9a/9/9 Pro/9 Pro XL/9 Pro Fold, 8a/8 Pro/8, 7a/7 Pro/7, 6/6 Pro, 5a 5G/5, 4a/4 XL).

- **Other Brands:** LG (G8 G7 V50 V40 V35 V30S ThinQ, G6 G5 G4 V10 V20 V30, Stylo 6 5 4), Motorola (Moto Z/Z2/Z3/Z4/E6/E5/Play/E4/E4 Plus/E3/X4/G9 Plus/G9/G8/G7/G6/G5S/G5/G4 Plus), HTC, OnePlus, Blackberry, Sony, Nokia.
- **Miscellaneous:** Android Cellphones, tablets, MP3/MP4/MP5 players, E-book readers, PSP, Digital cameras, power banks, Bluetooth speakers, and more.

Universal Compatibility

Perfect fit Apple Iphone,ipad,and samsung Blackberry android Devices ETC



Image 4: The HOOTEK 3-Port USB Wall Charger positioned among a variety of smartphones and tablets, illustrating its broad compatibility.

7. SAFETY INFORMATION

The HOOTEK 3-Port USB Wall Charger incorporates a Multi-Protect safety system to ensure the safety of both the charger and your connected devices. This includes:

- **Over-Voltage Protection:** Prevents damage from excessive voltage input.
- **Over-Current Protection:** Safeguards against excessive current flow.
- **Over-Charging Protection:** Automatically switches to protected mode once the battery is fully charged to prevent overcharging.
- **Over-Heating Protection:** Monitors internal temperature to prevent overheating.

- **Short-Circuit Protection:** Protects against short circuits.

Important Safety Precautions:

- Do not expose the charger to liquids, moisture, or extreme temperatures.
- Do not disassemble or attempt to repair the charger yourself.
- Keep out of reach of children.
- Unplug the charger when not in use or during electrical storms.

Smart IC Technology

Ensure safety charging your devices




Image 5: The HOOTEK 3-Port USB Wall Charger highlighting its "Smart IC Technology" and various protection features: Over Voltage, Over Current, Over Temperature, and Short Circuit Protection.

8. TROUBLESHOOTING

If you encounter issues with your HOOTEK 3-Port USB Wall Charger, please refer to the following common solutions:

- **Device not charging:**
 - Ensure the charger is securely plugged into a working wall outlet.
 - Verify that the USB cable is properly connected to both the charger and your device.
 - Try using a different USB cable to rule out a faulty cable.

- Test the charger with a different device to confirm charger functionality.
- Ensure your device is compatible with 5V USB charging.
- **Slow charging:**
 - Charging multiple devices simultaneously will distribute the total 3.1A output, potentially slowing down charging for individual devices.
 - Ensure the USB cable used is of good quality and capable of supporting the required current.
 - Some devices may have specific fast-charging protocols not supported by this standard 5V/3.1A charger.
- **Charger feels warm:**
 - It is normal for chargers to become slightly warm during operation, especially when charging multiple devices.
 - If the charger becomes excessively hot to the touch, disconnect it immediately and cease use. Contact customer support.

9. SPECIFICATIONS

Feature	Detail
Model Number	PT-WC-20
Material	Plastic outer shell
USB Output Ports	3
Input	AC100-240V, 50/60Hz, 0.5A
Output	DC 5V-3.1A (Total)
Product Dimensions	1.8 x 1.2 x 1.5 inches (46 x 32 x 38 mm)
Item Weight	1.6 ounces
Special Features	Lightweight Design, Short Circuit Protection, Travel-friendly

100—240V Universal input

make it ideal for home and international travel usage



MODEL:PT-WC-20
INPUT:AC100-240V

OUTPUT:DC5V 3.1A
50/60Hz0.5A

Image 6: The HOOTEK 3-Port USB Wall Charger displaying its universal input (100-240V) and output specifications (DC 5V 3.1A).

10. MAINTENANCE

- **Cleaning:** Disconnect the charger from the power outlet before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or aerosols.
- **Storage:** Store the charger in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Avoid dropping or subjecting the charger to strong impacts.

11. WARRANTY AND SUPPORT

HOOTEK stands by the quality of its products. If you encounter any issues or are not 100% satisfied with your HOOTEK 3-Port USB Wall Charger, please contact us via the Amazon Email Center. Our customer support team is committed to assisting you within 24 hours.

Please refer to your purchase documentation for specific warranty details.

